JVC

SERVICE MANUAL

COMPACT COMPORNENT SYSTEM

CA-D661T

Pick up	OPTIMA-150
CD signal Processor	MN35510



Area Suffix
J ... the U.S.A
C ... Canada

COMPACT disc DIGITAL AUDIO

Contents

Safety Precautions ---------- 1-2
Important for Laser Products ---------- 1-3
Instruction Book ---------- 1-4
Description ICs ---------- 1-23
Internal Connection of the Dispray ---------- 1-35
Disassembly Procedures ---------- 1-36
Connected an extension cord ---------- 1-54
Adjustment Procedures ---------- 1-55
Flow of Functional Operation Until TOC Read ---------- 1-59
Maintenance of Lazer Pickup ---------- 1-60
Self-diagnosis for pickup ---------- 1-61
Block diagram ---------- 1-63
Schematic Diagram ---------- 1-65
Printed Circuit Board 1-72
Parts List 2-1

COPYRIGHT © 1997 VICTOR COMPANY OF JAPAN, LTD.

No. 20609
Feb. 1997

Safety Precautions

1. The design of this product contains special hardware and many circuits and components specially for safety purposes. For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Services should be performed by qualified personnel only.
2. Alterations of the design or circuitry of the product should not be made. Any design alterations of the product should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacture of responsibility for personal injury or property damage resulting therefrom.
3. Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the Parts List of Service Manual. Electrical components having such features are identified by shading on the schematics and by (⚠) on the Parts List in the Service Manual. The use of a substitute repalcement which does not have the same safety characteristics as the recommended replacement parts shown in the Parts List of Service Manual may create shock, fire, or other hazards.
4. The leads in the products are routed and dressed with ties, clamps, tubings, barriers and the like to be separated from live parts, high temperature parts, moving parts and/or sharp edges for the prevention of electric shock and fire hazard. When service is required, the original lead routing and dress should be observed, and it should be confirmed that they have been returned to normal, after re-assembling.
5. Leakage currnet check (Electrical shock hazard testing)
   After re-assembling the product, always perform an isolation check on the exposed metal parts of the product (antenna terminals, knobs, metal cabinet, screw heads, headphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.
   Do not use a line isolation transformer during this check.
   - Plug the AC line cord directly into the AC outlet. Using a "Leakage Current Tester", measure the leakage current from each exposed metal parts of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground. Any leakage current must not exceed 0.5mA AC (r.m.s.).
   - Alternate check method
     Plug the AC line cord directly into the AC outlet. Use an AC voltmeter having, 1,000 ohms per volt or more sensitivity in the following manner. Connect a 1,500Ω 10 W resistor paralleled by a 0.15 µF AC-type capacitor between an exposed metal part and a known good earth ground.
     Measure the AC voltage across the resistor with the AC voltmeter.
     Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and meausre the AC voltage across the resistor.
     Now, reverse the plug in the AC outlet and repeat each measurement. Any voltage measured must not exceed 0.75 V AC (r.m.s.). This corresponds to 0.5 mA AC (r.m.s.).



Warning

1. This equipment has been designed and manufactured to meet international safety standards.
2. It is the legal responsibility of the repairer to ensure that these safety standards are maintained.
3. Repairs must be made in accordance with the relevant safety standards.
4. It is essential that safety critical components are replaced by approved parts.
5. If mains voltage selector is provided, check setting for local voltage.

Important for Laser Products

1. CLASS 1 LASER PRODUCT
2. DANGER : Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
3. CAUTION : There are no serviceable parts inside the Laser Unit. Do not disassemble the Laser Unit. Replace the complete Laser Unit if it malfunctions.
4. CAUTION : The compact disc player uses invisible laser radiation and is equipped with safety switches which prevent emission of radiation when the drawer is open and the safety interlocks have failed or are defeated. It is dangerous to defeat the safety switches.
5. CAUTION : If safety switches malfunction, the laser is able to function.
6. CAUTION : Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

VARNING : Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen.

VARO : Avattaessa ja suojalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen.

ADVARSEL : Usynlig laserstråling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

ADVARSEL : Usynlig laserstråling ved åpning, når sikkerhetsbryteren er avslott. unngå utsettelse for stråling.

REPRODUCTION AND POSITION OF LABELS

WARNING LABEL

(Except for the U. S. A.)

DANGER: invisible laser radiation when open and interlock failed or defeated. AVOID DIRECT EXPOSURE TO BEAM. (e)	VARNING: Osynling laser-stråling när denna del ä öppnad och spärren är urkoppled. Betrakta ej stålen. (s)	ADVARSEL: Usynling laser-stråling ved åbning, når sikkerhedsafbrydere er ude at funktion. Undgåudsæt-telse for stråling. (d)	VARO: Avattaessa ja suo-jalukitus ohitettaessa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen. (f)



Specifications

Amplifier Section	
Output Power	80 watts per channel, Min. RMS into 6 ohms at 1 kHz, with no more than 3% Total Harmonic Distortion.
Input Sensitivity/Impedance (1 kHz)	
VCR	300 mV/45 kohms
Speaker terminals	
Main speakers	6 - 16 ohms
Cassette Deck Section	
Frequency Response	
Type II (CrO_2) :	30 - 16,000 Hz
Type I (NORMAL) :	30 - 15,000 Hz
Wow And Flutter	0.15% (WRMS)
CD Automatic Changer Section	
CD Capacity	3 discs
Dynamic Range	93 dB
Signal-To-Noise Ratio	98 dB
Wow And Flutter	Unmeasurable
Tuner Section	
FM Tuner	
Tuning Range	87.5 - 108.0 MHz
AM Tuner	
Tuning Range	530 - 1,710 kHz
Dimensions	245 x 345 x 350.2 mm (W/H/D) (9-11/16 x 13-5/8 x 13-13/16 inches)
Mass	8.5 kg (18.8 lbs)
Accessories	
	AM Loop Antenna (1)
	Remote Control (1)
	Batteries R6P (SUM-3)/AA (15F) (2)
	FM Wire Antenna (1)
Power Specifications	
Power Requirements	AC 120 V ∿ , 60 Hz
Power Consumption	115 watts, 150 VA
	16 watts (in standby mode)

Design and specifications are subject to change without notice.

Thank you for purchasing the JVC Compact Component System.
We hope it will be a valued addition to your home, giving you years of enjoyment.
Be sure to read this instruction manual carefully before operating your new stereo system.
Here you will find all the information you need to set up and use the system.
For questions that are not be answered in the manual, please contact your dealer.

Features

COMPU PLAY

Here are some of the things that make your CA-D661T powerful and easy to use.

- ❑ The controls and operations have been redesigned to make them very easy to use so you can spend your time listening to music.
  - With the One Touch Operation feature of JVC's **COMPU PLAY** you can turn on the CA-D661T and start the radio, the Cassette Deck, or the CD Player with a single touch.
  - You can use the MULTI CONTROL stick to set the CD Player, Tuner, Timer, and Sound Mode operations.

Great sound

- ❑ To get such great sound from such a compact package the CA-D661T has:
  - Programmed sound mode includes live surround effects **D. CLUB, HALL,** and **STADIUM**. It also includes S.E.A (Sound Effect Amplifier) effects **ROCK, POP,** and **CLASSIC**. You can also register up to three customized settings.

Triple Tray

- ❑ CD changer function can operate 3 discs.
  - Discs can be changed during play using the **TRIPLE TRAY**.
  - Continuous, random or program play of 3 discs.

Three timers

- ❑ The three timers, **DAILY Timer, REC (Recording) Timer,** and **SLEEP Timer** are extremely easy to set.
- ❑ The Displays are large and clear. They are organized so you can tell at a glance what's happening because functions light up as you use them, and blink to tell you they are ready. They provide some important messages like "NO DISC", and other informations.

How This Manual Is Organized

In this manual we have incorporated some special features:

- Basic information that is the same for many different functions is grouped in one place, and not repeated in each procedure. For instance, in the section on playing a CD, we do not repeat the information about setting the volume and the sound conditions, which are discussed in the Using the Amplifier section.
- Name of buttons and controls are written in all capital letters like this: POWER.
- When we are talking about the Function, rather than the BUTTON or DISPLAY, only the first letter is capitalized.

The manual has a table of contents to help you quickly look up what you want to know.
We've enjoyed making this manual for you, and hope you will use it to enjoy the sound and many features built into your CA-D661T.

IMPORTANT CAUTIONS

1. **Installation of the Unit**
   - Select a place which is level, dry and neither too hot nor too cold. (Between 5°C and 35°C or 41°F and 95°F.)
   - Leave sufficient distance between the Unit and a TV.
   - Do not use the Unit in a place subject to vibrations.
2. **Power cord**
   - Do not handle the power cord with wet hands!
   - Some power (16 watts) is always consumed as long as the power cord is connected to the wall outlet.
   - When unplugging the Unit from the wall outlet, always pull the plug, not the power cord.
3. **Malfunctions, etc.**
   - There are no user serviceable parts inside. If anything goes wrong, unplug the power cord and consult your dealer.
   - Do not insert any metallic object into the Unit.

Getting Started

Accessories

Check that you have all of the following items, which are supplied with the CA-D661T.

AM Loop Antenna (1)
Remote Control (1)
Batteries (2)
FM Wire Antenna (1)

If any of these items is missing, contact your dealer immediately.

How To Put Batteries In the Remote Control

Match the polarity (+ and –) on the batteries with the + and – markings in the battery compartment.

R6P (SUM-3)/AA (15F)



CAUTION: Handle batteries properly.
To avoid battery leakage or explosion:

- Remove batteries when the Remote Control will not be used for a long time.
- When you need to replace the batteries, replace both batteries at the same time with new ones.
- Don't use an old battery with a new one.
- Don't use different types of batteries together.

Using the Remote Control

The Remote Control makes it easy to use many of the functions of the CA-D661T from a distance of up to 7m (23 feet) away.
You need to point the Remote Control at the remote sensor on the CA-D661T's front panel.



CAUTION: Make all connections before plugging the Unit into an AC power outlet.

Connecting the FM Antenna

Using the Supplied Feeder Antenna



Extend the supplied FM Wire Antenna horizontally.

Using an FM 75-Ohm Antenna Cable (Not Supplied)

If reception is poor, connect the outside antenna.



Before attaching a 75 ohm coaxial lead (the kind with a round wire going to an outside antenna), disconnect the supplied FM Wire Antenna.

CAUTION: To avoid noise, keep antennas away from metallic parts of the CA-D661T, connecting cord and the AC power cord.

Connecting the AM Antenna


AM antenna wire
If reception is poor, connect the outside antenna.
AM LOOP
GND
AM EXT
Note: Even when connecting an outside AM antenna, keep the indoor AM loop connected.
AM Loop Antenna
1
2
3
Turn the loop until you have the best reception
Snap the tabs on the loop into the slots of the base to attach the AM Loop.

CAUTION: Make all connections before plugging the Unit into an AC power outlet.

Connecting the Speakers *(Please refer to instructions for speakers as will when you connect speakers.)*

For each speaker, connect one end of the speaker wire to the speaker terminals on the back of the CA-D661T and the other end to the speaker.

1. Open each of the terminals and insert the speaker wires firmly (be sure to remove the insulation at the end of each wire first), then close the terminals.
2. Connect the red (+) and black (–) terminals of the right side speaker to the red (+) and black (–) terminals marked RIGHT on the CA-D661T.
   Connect the red (+) and black (–) terminals of the left side speaker to the red (+) and black (–) terminals marked LEFT on the CA-D661T.

Laying Out the Unit



1 cm (7/16") 1 cm (7/16")

Leave a space of at least 1 cm on both sides of the Unit and at least 10 cm at the back, for ventilation.



IMPORTANT: Use speakers with the correct impedance only. The correct impedance is indicated on the back panel.
CAUTION: If a TV is installed near speakers, the TV may display irregular colors. In this case, set the speakers away from the TV.

Connecting the SUB WOOFER

Connect the Sub-Woofer to the SUBWOOFER OUT terminal.



Connecting a VCR

Connect the VCR to the VCR terminal.



Now you can plug the AC power cord into the wall outlet, and your CA-D661T is at your command!

Using the Remote Control

Press the SOUND MODE button.
The display changes with each press of the button as shown below.

→D. CLUB→HALL→STADIUM→ROCK→POP→CLASSIC→MANUAL 1→MANUAL 2→ MANUAL 3→OFF→

Customizing a sound mode

You can change an existing sound mode to suit your own preferences. These changed setting can be stored in the CA-D661T's sound mode memory.

1. Select the sound mode you want to change.
If you select D. CLUB, HALL, or STADIUM, the surround effect remains unchanged, but you can adjust the S.E.A. effect.



2. Press the SEA CONTROL button.
"SEA CONT" appears in the display, then the low tone section of the tone equalizer is displayed and the MULTI CONTROL indicators light up to indicate the directions in which you can use the controller.



Note: If no adjustments are made for 5 seconds after the SEA CONTROL button is pressed, Sound mode appears on the display then reverts to the previous display.

3. Adjust the settings using the MULTI CONTROL stick.

- Adjust the level by adjusting the MULTI CONTROL stick up and down.
  The level can be set between +3 and -3 in seven steps.



- Select the tone range by adjusting the MULTI CONTROL stick left and right.
  You can select LOW, MID, or HIGH tones.

4. Press the SET button.
"MANUAL 1" appears on the display.

5. Select the memory number by adjusting the MULTI CONTROL stick left and right.
You can choose from "MANUAL 1" to "MANUAL 3".

6. Press the SET button again.
"MEMORY" appears on the display and the settings are stored in the memory number selected.

- The sound mode is set to the settings you have stored.
- If you store new settings to a memory number that has already been used, the new settings replace the existing setting.

Auto Power Off

When playing either a tape or a CD, Auto Power Off will shut the Unit off when the tape or CD comes to an end. Although Auto Power Off is very useful for shutting off the CA-D661T at night, you can also use it if you think you might forget to turn the Unit off when leaving the house or your room at other times of the day.

To Use Auto Power Off
Press the AUTO POWER OFF button, the AUTO POWER OFF button lights up.
To Cancel Auto Power Off
Press the AUTO POWER OFF button again, the AUTO POWER OFF button goes out.

Important Information On Using Auto Power Off

- The end of CD playback varies depending on the play mode of the CD Player. If the play mode is Continuous or "RANDOM", when all tracks on the disc set in the CD player end, the power is automatically turned off. If the play mode is "PROGRAM", the power is automatically turned off when the last track you programmed ends.
- Auto Power Off will still work even though you press the REPEAT button.
  Repeat Mode ("REPEAT ALL" indicator lights up on the display):
  This automatically turns off the power after all the tracks on the CDs in the CD Player have been played.
  Repeat 1 CD Mode ("REPEAT 1 CD" indicator appears on the display):
  This automatically turns the power off after all of the tracks on the CD have been played.
  Repeat 1 Mode ("REPEAT 1" indicator lights up on the display):
  This automatically turns the power off after the selected track has been played.
- If you press the AUTO POWER OFF button while the tape is playing:
  - If Reverse Mode is off, the Unit turns off when the current side finishes.
  - If Reverse Mode is on, the Unit will turn off when the tape finishes playing in the ◁ direction.

Using a VCR

Listening to a VCR

By playing the sound from VCR through the CA-D661T, you can gain control over how the music or program sounds. Once the connected equipment is playing through the CA-D661T, you can apply the sound effects.

- First make sure that the optional equipment is properly connected to the CA-D661T. (See page 5).

1. Set the VOLUME control to 0.



2. Press the VCR button.
When CA-D661T is in Standby mode, the Unit is automatically turned on and "VCR" appears on the display.



3. Start playing the equipment.

4. Adjust the VOLUME control to the desired listening level.

5. Select a sound effect mode, if you wish.

To Cancel the Setting
Change the source by starting any one of the CA-D661T's built-in sound sources, such as the Tuner or CD Player.

Recording to a VCR

To record to a VCR, start playback of the recording source of the CA-D661T and start recording on your VCR. (Refer to the VCR's instruction manual for details on the recording procedure for your VCR.)

- You cannot record using Sound mode effects.

Using the Tuner





Display



When the CA-D661T is being used, the display shows other items as well. However, we have only shown the items described in this section.

You can listen to both FM and AM stations. Stations can be tuned in manually, automatically, or from preset memory storage.

❑ Before listening to the radio:
- Check that both the FM and AM antennas are firmly connected. (See page 4).

One Touch Radio

COMPU PLAY

Just press the FM/AM button (or the TUNER button on the Remote Control) to turn on the Unit and start playing the most recent station tuned in.

❑ You can switch from any other sound source to the radio by pressing the FM/AM button (or the TUNER button on the Remote Control).

Tuning In a Station

Press the FM/AM button (or the TUNER button on the Remote Control) to turn on the radio. The Frequency of the previously selected channel appears on the display.

Switching between Frequency Bands

Press the FM/AM button.

Each time you press the button, the band alternates between FM and AM.

Selecting a radio station

❑ Select a frequency by adjusting the MULTI CONTROL stick up or down. The frequency changes in one step increments. "TUNED" appears on the display when a signal is found. This is called Manual Tuning.
The frequency increases when MULTI CONTROL stick is pressed upwards, and decreases when the MULTI CONTROL stick is pressed downwards.

❑ If the MULTI CONTROL stick is pressed up or down continuously for a few seconds, the frequency changes continuously until a signal is found, then "TUNED" appears on the display. This is called Auto Tuning.

❑ (Possible only after presetting stations.)

Using the Unit

Select a preset channel by adjusting the MULTI CONTROL stick left or right.

Using the Remote Control

1. **Press the TUNER button so that you can receive the most recent station tuned in.**
2. **Select the station by entering the preset number in the number keys of the Remote Control.**

❑ Example: for channel 5, press 5. For channel 15, press +10 then 5. For channel 20, press +10, then 10. For channel 32, press +10 three times, then 2.

Presetting Stations



You can store up to 40 of your favorite radio stations (FM and AM) in memory, giving you quick, easy access to the stations.

Note: In some cases, test frequencies have been already memorized for the tuner since the factory examined the tuner preset function before shipment. This is not a malfunction. You can preset the stations you want into memory by following the presetting method.

1. **Select a frequency band by pressing the FM/AM button.**
2. **Tune to a station by adjusting the MULTI CONTROL stick up or down.**
3. **Press the SET button .**
   On the display, "SET" will blink for 5 seconds.
   ❑ During these 5 seconds while "SET" is blinking, you can assign a channel number to the station and enter it into the memory.
4. **Select a preset number by adjusting the MULTI CONTROL stick left or right.**
5. **Press the SET button and the station will be assigned to the channel number showing on the display.**
   "MEMORY" appears in the display.

   MEMORY

   ❑ If a station has been previously stored using the same channel number, this will be erased and the newly selected station will be stored.
   ❑ If "SET" in the display goes off, start again from step 3.
6. **Repeat steps 1 - 5 for each station you want to store in memory with a preset number.**

CAUTION: If the Unit is unplugged or if a power failure occurs, the preset stations will be erased after a few days. If this happens, preset the station again.

To Change the FM Reception Mode

When an FM stereo broadcast is hard to receive or noisy, press the FM MODE button on the Remote Control so that the "AUTO" indicator goes off in the display. Reception improves, but there are no stereo effects, In this monaural mode, noise comes out while tuning in stations (since muting is also cancelled).

To restore the stereo effect, press the FM MODE button on the Remote Control so that the "AUTO" indicator lights up. In this stereo mode, no noise comes out while tuning in stations, and you can hear stereo sounds when a program is broadcast in stereo.

DEMO Mode

When the CA-D661T is connected to an AC power outlet, a DEMO mode displaying some of the system's features automatically starts.
The DEMO display cycles through the following items repeatedly.

- Scrolling display of "DEMO MODE START".
- Demo of MULTI CONTROL.
- Demo of Sound Modes.
- Demo of continuous play from DISC-1 to DISC-3.
- Scrolling display of "TUNER RANDOM 40CH PRESET".

To turn the DEMO display off, press any of the operation buttons. "DEMO OFF" appears on the display and the DEMO display automatically stops.

DEMO OFF

To turn the DEMO display on, press the DEMO button.

Note: The DEMO display automatically starts when the power cord is inserted into a wall outlet.

COMPU PLAY

COMPU PLAY is JVC's feature that lets you control the most frequently used functions of the CA-D661T with a single touch.
One Touch Operation starts playing a CD, turns on the radio, plays a tape, etc. with a single press of the play button for that function. What One Touch Operation does for you is to turn the power on, then start the function you have specified. If the Unit is not ready, such as no CD or tape in place, the Unit still powers on so you can insert a CD or tape.
How One Touch Operation works in each case is explained in the section dealing with that function.
The COMPU PLAY buttons are:

On the Unit

CD button
CD Player ▷/II button
CD Player DISC-1 to DISC-3 buttons
CD Player Open/Close (▲) buttons
FM/AM button
TAPE button
DECK CONTROL ◁, ▷ buttons
VCR button

On the Remote Control

TUNER button
VCR button
CD control ▶ button
CD control DISC 1 to DISC 3 buttons
CD control Open/Close (▲) buttons
Deck control ◀◀, ▶▶ buttons

Adjusting the Brightness of the Display

In Standby mode, you can adjust the brightness of the clock display.
Pressing the MULTI CONTROL stick in the upwards direction makes the display brighter.
Pressing the MULTI CONTROL stick in the downwards direction makes the display darker.

Using the Amplifier



When the CA-D661T is being used, the display shows other items as well. However, we have only shown the items described in this section.

Turning the Power On and Off

Turning the CA-D661T On

Press the POWER button.
The display comes on and the STANDBY indicator goes out.
The CA-D661T comes on ready to continue in the mode it was in when the power was last turned off.

- If the last thing you were doing was listening to a tape in Deck B, you are now ready to listen to a tape again in Deck B, or you can change to another source.
- If you were listening to the Tuner last, the Tuner comes on playing the station it was last set to.

Turning the CA-D661T Off

Press the POWER button again.
The STANDBY indicator lights up and the display is blank, except for the clock display.

- Some power (16 watts) is always consumed even though power is turned off (called Standby Mode).
- To switch off the Unit completely, unplug the AC power cord from the AC outlet. When you unplug the AC power cord, the clock will be reset to AM12:00 immediately, and preset Tuner stations will be erased after a few days.

Adjusting the Volume

Turn the VOLUME control clockwise to increase the volume or anticlockwise to decrease it.
Turning the VOLUME control quickly also adjusts the volume level quickly.
When using the Remote Control, press the VOLUME + button to increase the volume or press the VOLUME – button to decrease it.
You can adjust the volume level between 0 and 50.

or

❑ When the CA-D661T is turned on from Standby mode, the volume is set to 0 and automatically increases to the previous volume level. To stop this automatic volume adjustment, turn the VOLUME control slightly or press the VOLUME button on the Remote Control.

For private listening
Connect a pair of headphones to the PHONES jack. No sound comes out of the speakers.
Be sure to turn down the volume before connecting or putting on headphones.

FADE MUTING Function

Set the Volume Level to 0 by pressing the FADE MUTING button on the Remote Control. Press this button again to restore the Volume Level to its previous level.

Balance adjustment

You can use the Remote Control to adjust the left and right balance of the speakers.

1. **Press the SHIFT button.**
2. **Press the L BALANCE R buttons (10 or +10).**
   The display changes to show the balance adjustment.



Pressing the L button (10) moves the pointer to the left, pressing the R button (+10) moves the pointer to the right.

Display when set for no sound from the right speaker.



Display at the center position.



Display when set for no sound from the left speaker.

❑ The balance is normally set to the center position.

Note: If no adjustments are made for 5 seconds in balance adjustment mode, the display reverts to the previous display.

Reinforcing the Bass Sound

The richness and fullness of the bass sound is maintained regardless of how low you set the volume.
You can use this effect only for playback.

To get the effect, press the ACTIVE BASS EX. (Active Bass Extension) button. "BASS ON" appears in the display and the indicator lights up.



To cancel the effect, press the button again. The message "OFF" appears in the display and the indicator goes out.



Sound Modes

The CA-D661T has some preset sound effects that give you control of the way your music sounds, so you can tailor it for your room and for the quality of the source. We can give you some idea of how each one affects the music, but the only way to really tell is to try them yourself.
You can also create up to three of your own customized S.E.A. (Sound Effect Amplifier) settings and store them in the unit's memory.

❑ The preset sound modes include modes using surround effects and modes using S.E.A. effects.
❑ Sound Mode effects cannot be recorded.

Surround effect modes

D, CLUB (Dance Club)	Increases resonance and bass.
HALL	Adds depth and brilliance to the sound, like in a concert hall.
STADIUM	Adds clarity and spreads the sound, like in an outdoor stadium.

S.E.A. effect modes

ROCK	Boosts low and high frequencies.
POP	Good for vocal music.
CLASSIC	Set for wide and dynamic sound stereo systems.

Selecting a Sound Mode

Using the Unit



1. **Press the SOUND MODE button.**
   The currently selected Sound mode appears on the display.
   The MULTI CONTROL indicators light up to indicate the directions in which you can use the controller.



Note: If no adjustments are made for 5 seconds in Sound mode after the SOUND MODE button is pressed, the display reverts to the previous display.

2. **Press the MULTI CONTROL stick to the left or right to select a Sound mode.**
   Use the MULTI CONTROL stick to select a Sound mode while sound mode is displayed. If the display reverts to the previous display, press the SOUND MODE button again and use the MULTI CONTROL stick to select a mode.



❑ The display also displays the frequency for the selected mode.

Moving the MULTI CONTROL stick to the right →
←D, CLUB←→HALL←→STADIUM←→ROCK←→POP←→CLASSIC←→MANUAL 1←→MANUAL 2←→MANUAL 3←→OFF←→
← Moving the MULTI CONTROL stick to the left

To cancel Sound mode, select "OFF".

Unless sound mode "OFF" is selected, the red perimeter line around the SOUND MODE indicator is lit. If "OFF" is selected, the perimeter line goes out.

SOUND MODE ON

SOUND MODE OFF

Using the CD Player





Display



When the CA-D661T is being used, the display shows other items as well. However, we have only shown the items described in this section.



DISC indicator
Each of the Disc buttons acts as an indicator.
This indicator is off when the CD Player is checking that there is no disc in the disc tray for the corresponding disc number.
Pressing the ⏏ button turns the indicator on.
During playback, the disc indicator for the disc being played flashes.

Disc display
A red marker lights on the disc display for the disc number you have selected. This disc display blinks while a CD is being played.
The centre of the disc display is not lit while CD Player is checking that there is no disc in the disc tray for the corresponding disc number.

The CA-D661T's CD Player has an Automatic Changer with 3 disc trays. You can use Continuous, Random, Program or Repeat Play for the discs in DISC-1, DISC-2 and DISC-3. Repeat Play can repeat all the tracks on all the CD's, the tracks on one of the CD's or one track on one CD. There is also the Tray Lock function, which safely keeps discs in the trays.

Here are the basic things you need to know to play a CD and locate the different selections on it. Each selection is called a track, so when we are talking about locating a track, we are also talking about how you find a certain song or performance.

COMPU PLAY

The Quickest Way To Start a CD Is With the One Touch Operation

The power comes on, and operations are done automatically.

- ❑ Press the CD or ▷/II button (or the ► button on the Remote Control).
  - If there is a CD in the disc tray of the selected (lit) disc number, playback continues from the track where it was interrupted.
  - If there is no CD in any of the disc trays, the message "OPEN" appears in the display after a few seconds and the disc tray for the marked disc opens.
- ❑ Press a DISC button (1 to 3).
  - If there is a CD in the disc tray for the disc number you have selected, playback begins from the first track of that disc. If there is no CD in the disc tray, the message "OPEN" appears in the display after a few seconds and the disc tray opens.
- ❑ Press the ⏏ button.
  - The power turns on, and the tray opens automatically.

Basics of Using the CD Player — Continuous Play



You can play the discs continuously in the DISC 1 to DISC 3 trays.

To Insert Discs

1. **Press the ⏏ button on the left of the Disc button you want to insert the disc into.**
   The disc tray slides out automatically.
2. **Place a CD, with its label side up, onto the tray.**

   ATTENTION: *To avoid malfunctions when you play a CD, please set the CD in the right place at the centre of the tray.*



3. **Press the ⏏ button to close the tray.**
4. **Repeat steps 1 to 3 to insert other discs into other trays.**
   - To continue putting discs into other trays. even if a tray is open, by pressing the ⏏ button of another disc tray, the open tray will close automatically, and the new disc tray will slide out.

- ❑ To put an 8 cm CD into a tray, insert it so that it is aligned with the groove in the tray's centre.
- ❑ "OPEN" appears in the display when a tray opens, and "CLOSE" when a tray closes.
- ❑ If a tray is open when the CA-D661T switches to Standby mode, the tray is closed automatically.

Note: When the CD Player is reading a disc, "- - - -" appears in the display. While this is being displayed, the ⏏ button or DISC button cannot be used. Once the display changes from "- - - -" to another display, the ⏏ button and DISC button can be used.

To Play a Disc

This function plays the disc in the Unit continuously.



1. **Prepare the discs.**
2. **Press the DISC button (1-3) of the disc you want to play.**
   The first track of the selected disc will begin playing.
   When the selected disc finishes playing, the next disc will begin playing automatically.
   When the last disc has finished playing, the Unit will stop automatically.

❑ When a DISC button is pressed while a tray is open, the open tray will close automatically and Continuous Play playback begins from the first track of the disc.

To use Continuous Play from the first track of the disc selected by the disc marker, you do not need to press a DISC button (1-3), just press the ▷/II or CD button (or ► button on the Remote Control).

Playing order of discs

❑ When playback starts from DISC-1, the playing order is DISC-1 → DISC-2 → DISC-3. When DISC-3 has finished, the CD Player selects DISC-1 (the disc marker is on) and stops.
❑ When playback starts from DISC-2, the playing order is DISC-2 → DISC-3 → DISC-1. When DISC-1 has finished, the CD Player selects DISC-2 (the disc marker is on) and stops.
❑ When playback starts from DISC-3, the playing order is DISC-3 → DISC-1 → DISC-2. When DISC-2 has finished, the CD Player selects DISC-3 (the disc marker is on) and stops.
  • If any of the disc trays are empty, the CD Player skips that disc tray and continues through the remaining disc trays in the order shown above.

Note: If there is no CD in disc tray for the DISC button you pressed, the message "OPEN" appears in the display and the disc tray automatically opens. If there is no disc in the disc tray for the selected disc number, when the ▷/II or CD button (or the ► button on the Remote Control) is pressed, playback begins from the next disc.

To stop play the disc, press the ■ button.
To stop play and remove the disc, press the ▲ button for the disc being played.
To pause, press the ▷/II button. The Disc display will blink. (The Pause function cannot be used with the ► button on the Remote Control.)
To cancel pause, press the ▷/II button again (or press the ► button on the Remote Control). Play continues from the point where it was paused.

RESUME

When the ■ button is pressed during playback, and the source is changed, the track number is memorized even when the power is turned off. The next time the ▷/II or CD button (or the ► button on the Remote Control) is pressed, play resumes from the track where it was interrupted.
❑ To start playback from the first track, press the DISC button.

To Change Discs While Playing

You can replace a CD in a tray not being used, while another CD is playing.

1. **Press the ▲ button of the tray not being used.**
   The tray opens.
2. **Replace the disc in the tray.**
3. **Press the ▲ button to close the tray.**

To Select a Disc, Track Or Passage Within a Track

Press the DISC button (1-3) for the disc tray containing the track you want to listen to.
Playback starts from the first track of the disc you selected.
❑ Example: for the third disc, press 3.

To Select a Track

Using the Unit

Select a track by adjusting the MULTI CONTROL stick left or right.
❑ The MULTI CONTROL stick adjustments step through the tracks on the CD one track at a time.
  • Moving the MULTI CONTROL stick to the right selects the next track.
  • Moving the MULTI CONTROL stick to the left select the previous track.
❑ If the MULTI CONTROL stick is held down continuously, the CD Player skips through the tracks on the CD continuously in the selected direction.

Using the Remote Control

Press the |◄◄ or ►►| button to select the track.
❑ Each time you briefly press and release the |◄◄ or ►►| button, the track changes by one.
  • Press and release the ►►| button to go ahead one track at a time.
  • Press and release the |◄◄ button to go back one track at a time.
❑ Holding down the |◄◄ or ►►| button allows you to change tracks continuously.

To Select a Passage Within a Track

While a CD is playing, press the MULTI CONTROL stick up or downwards continuously.
❑ If the MULTI CONTROL stick is pressed upwards the CD is played forwards quickly, if the controller is press downwards the CD is played backwards quickly. Release the controller when the CD reaches the passage you want to hear.
Note: You cannot perform these fast forwards or fast backwards operation with the remote control.

Locating a Track With the Remote Control Directly

Using the number keys on the Remote Control allows you to go directly to the beginning of any track.

1. **Press the DISC button (1-3) for the disc tray containing the track you want to listen to.**
   ❑ Example: for the third disc, press 3.
2. **Enter the number of the track you want to listen to with the number keys.**
   The selected track starts playing.
   ❑ Example: for track 5, press 5. For track 15, press +10 then 5. For track 20, press +10, then 10. For track 32, press +10 three times, then 2.

Programming the Playing Order of the Tracks

You can change the order in which the discs and tracks play, and select only the discs and tracks you want from among those loaded in the CD Player.
❑ You can program up to 32 steps in any desired order from among the discs in the player.
❑ You can only make or change a program when the CD Player is stopped.

Using the Unit

1. **Press the PROGRAM/RANDOM button.**
   The message "PROGRAM" appears on the display and the PROGRAM indicator comes on.
   If you have already created a program, the last step of the previous program is displayed.

❑ The display changes with each press of the PROGRAM/RANDOM button, as shown below.
→ **PROGRAM** → **RANDOM** → Off (Continuous Play) → (back to the beginning)



2. Select a disc with the DISC buttons (1 to 3).
The display changes to the Program Entry display and the disc number and track number sections blink for a few seconds.



❑ While the display is blinking, perform the operations in steps 3 to 4. When the blinking display changes to the "PROGRAM" display, repeat the operations in steps 2 to 4.

3. Select a track for the program by adjusting the MULTI CONTROL stick left or right.
The track number appears on the display.



4. Press the SET button.
The blinking disc number and track number changes to a steady light, and the step number is displayed.



5. Repeat steps 2 to 4 to select the other tracks for the program.
❑ To select another track from the same disc, repeat the procedure from step 3.

6. Press the ▷/II or CD button.
The Unit plays the tracks in the order you have programmed them.

Using the Remote Control

1. Press the PROGRAM/RANDOM button on the Unit.
The message "PROGRAM" appears in the display and the PROGRAM indicator comes on.
If you have already created a program, the last step of the previous program is displayed.

❑ The display changes with each press of the PROGRAM/RANDOM button, as shown below.
→ **PROGRAM** → **RANDOM** → Off (Continuous Play) → (back to the beginning)

2. Select a disc with the DISC buttons (1-3).
The display changes to the Program Entry display and the disc number and track number sections blink for a few seconds.



❑ While the display is blinking, perform the operations in step 3. When the blinking display changes to the "PROGRAM" display, repeat the operations in steps 2 to 3.

3. Press the number keys (1 to 10 and +10) to select the track to program.
❑ Example: For track 5, press 5. For track 15, press +10 then 5. For track 20, press +10 then 10. For track 32, press +10 three times, then 2.
The blinking disc number and track number changes to a steady light, and the step number is displayed.



4. Repeat steps 2 to 3 to select the other tracks for the program.

5. Press the ► button.
The Unit plays the tracks in the order you have programmed them.

❑ If you try to program a 33rd step, the CA-D661T lets you know that the program is full by displaying the message "FULL" on the display.
❑ If you try to program an disc tray that is empty, or a track number that does not exist on a disc (for example, selecting track 14 on a disc that only has 12 tracks), the selected disc or track are skipped when the program is played.
❑ You can skip to a particular program step during program play. To do this from the unit, move the MULTI CONTROL stick left or right, to do so from the remote control press the |◄◄ or ►►| buttons.
❑ To play the programmed tracks over and over, press the REPEAT button . The Repeat mode indicators light up in sequence with each press of the REPEAT button.

To stop playing, press the ■ button.
To delete all the tracks in a program, keep pressing the CANCEL button on the Unit until all the tracks in the program have been deleted, or press the ▲ button for each disc in the program.
To exit Program Mode, press the PROGRAM/RANDOM button twice to change to Continuous Play mode.

To Check the Program

While the CD Player is stopped, use the |◄◄ or ►►| buttons on the remote control to check the contents of the program.
Each time you press the ►►| button, the program contents are shown on the display in the programmed order. Pressing the |◄◄ button displays the previous step in the program.

To Modify the Program

Modify the contents of a program while the CD Player is stopped.
Press the CANCEL button on the Unit, the last track in the program is deleted.
Each time you press the button, the last track listed in the program is deleted from the program.
To add a track to the program, follow the procedure above (on either the Unit or the Remote Control). The news tracks are added to the end of the program.

Random Play

The tracks will play in no special order when you use this mode.

1. Press the PROGRAM/RANDOM button while the CD Player is stopped to change to the Random Mode display.

❑ The display changes with each press of the PROGRAM/RANDOM button, as shown below.
→ **PROGRAM** → **RANDOM** → Off (Continuous Play) → (back to the beginning)

2. Press the ▷/II or CD button (or the ► button on the Remote Control)
The tracks are played in random order.
When all of the tracks have been played, the CD Player stops.

Note: Press the DISC buttons (1-3), or the number keys, to cancel Random play and begin playback in Continuous Play mode.

- Press the REPEAT button before or during random play to instruct the CA-D661T to continue with a different random track selection after the last selection is played.

To cancel random play, press the ■ button, then press the PROGRAM/RANDOM button to select another mode.

Repeating a Selection or the Discs

You can have all the discs, the program or the individual selection currently playing repeat as many times as you like.

Press the REPEAT button on the CA-D661T.
The display changes with each press of the button, as shown below.
→ **REPEAT ALL** → **REPEAT 1 CD** → **REPEAT 1** → blank display → (back to the beginning)

REPEAT ALL: Repeats all the tracks on the CD's in the CD Player, or all the tracks in the program.
REPEAT 1 CD: Repeats all the tracks on one CD.
REPEAT 1: Repeats one track on a CD.

- "REPEAT ALL" and "REPEAT 1" remain on the display even when you change the play mode.
- The three Repeat Modes above can be selected during Continuous Play, however, during Program Play and Random Play, you can only select REPEAT ALL or REPEAT 1.

To exit Repeat Mode, press the REPEAT button until the Repeat mode indicator on the display goes out.

Tray Lock Function

In order to safely keep the discs in the CD Player, the three trays can be electronically locked in a single operation.
When the electronic lock is on, the trays cannot be opened even if the ▲ button is pressed.
This function can only be accessed by using the buttons on the Unit itself.

Locking the Electronic Lock



1. **Put the CA-D661T's power into STANDBY mode.**
2. **While pressing the ■ button, press the ▲ button for DISC 1's tray on the Unit.**
"LOCKED" appears on the display to let you know that the trays have been locked.

LOCKED

When the CD Player trays are locked, pressing the ▲ buttons displays the message "LOCKED" on the display and the trays do not open. But, the ▲ button can be used to automatically turn on the power.

Unlocking the Electronic Lock

1. **Put the CA-D661T's power into STANDBY mode.**
2. **While pressing the ■ button, press the ▲ button for DISC 1's tray on the Unit.**
When the unlock operation is done, "UNLOCKED" appears in the display to show that the lock has been taken off.

UNLOCKED

The trays can now be opened by pressing the ▲ buttons.
The ▲ button can also be used to automatically turn on the power.

Using the Cassette Deck (Listening to a Tape)





Cassette Deck control buttons

Display



◁▷ : Tape Direction indicator
⊂⊃ : Reverse Mode indicator
DD : DOLBY B NR indicator

Tape Direction Indicator on the Display
The Tape Direction indicator tells you which direction the selected tape deck will use for playback.
During playback, the direction indicator blinks slowly.
During fast left or fast right, the indicator blinks quickly.
During Music Scan mode, the direction indicator alternates between blinking slowly and quickly repeatedly.

When the CA-D661T is being used, the display shows other items as well. However, we have only shown the items described in this section.

The Cassette Deck allows you to play, record and dub audio tapes.

- Most tapes are now recorded with the Dolby NR system, so first check which type of the Dolby NR system has been used on the tape. Only Dolby B NR is incorporated into the CA-D661T.
- With Automatic Tape Detection, you can listen to type I or II tapes without changing any settings.

The use of tapes longer than 120 minutes is not recommended, since characteristic deterioration may occur and these tapes easily jam in the pinch-rollers and the capstans.

One Touch Play

COMPU PLAY

- ❑ Press the TAPE button.
  The power comes on and "TAPE" lights up on the display . If there is a tape in the deck corresponding to the Deck Indicator DECK A/B, that tape starts to playback. If there is no tape in the deck corresponding to the Deck Indicator, the CA-D661T automatically turns on the power and displays "TAPE" then the message "NO TAPE" and waits for you to insert a tape or select another function.
- ❑ Press the ◅ or ▻ button (or the ◄◄ or ►► button on the Remote Control).
  The power comes on and "TAPE" appears in the display. When a tape is already in the tape deck, the tape is played in the direction of the button pressed. If there is no tape in the deck corresponding to the Deck Indicator, the CA-D661T automatically turns on the power and displays "TAPE" then the message "NO TAPE" and waits for you to insert a tape or select another function.

Regular Play

If the power is already on, you can use this basic procedure:

1. **Press the ▲ button for the deck you want to use.**
2. **When the cassette holder opens, put the cassette in, with the exposed part of the tape down, toward the base of the CA-D661T.**
   - ❑ If the cassette carrier does not open, turn the Unit off, then back on and press the ▲ button again.
3. **Close the holder gently.**
   When both Deck A and Deck B contain a tape, the last deck to have a tape inserted is selected.
   To change the selected deck, press the DECK A/B button.
   When using the Remote Control, press the A or B button.
4. **Press the ◅ or ▻ button (or ◄◄ or ►► button on the Remote Control).**
   The tape is played in the direction of the button pressed for the selected deck.
   - ❑ The Cassette Deck automatically stops when one side of a tape has finished playing.

DECK A/B

To stop playing, press the ■ button.
To remove the tape, stop the tape, and press the ▲ button.
To change deck while playing a tape, press the ◅ or ▻ button after pressing the DECK A/B button on the Unit or press the ◄◄ or ►► button after pressing the A or B button on the Remote Control.

Fast Left and Fast Right

- ❑ While the tape is stopped, press the ◄◄ button and the tape will wind rapidly onto the left side of the cassette without playing.
- ❑ While the tape is stopped, press the ►► button and the tape will wind rapidly onto the right side of the cassette without playing.

Note: Deck A and Deck B cannot be used for playback at the same time.

Music Scan

To find the beginning of a music track during play, use the Music Scan function. Music Scan searches for blank portions that usually separate selections, then plays the next selection.

To Find the Beginning of the Current Selection

Press the ◄◄ or ►► button during play.

- ❑ Make sure that you press the ◄◄ or ►► button in the opposite direction to that in which the tape is playing. Searching stops at the beginning of the current selection, and the current selection starts automatically.

To Find the Beginning of the Next Selection

Press the ◄◄ or ►► button during play.

- ❑ Make sure that you press the ◄◄ or ►► button in the same direction as that in which the tape is playing. Searching stops at the beginning of the next selection, and the next selection starts automatically.

Music Scan works by detecting a 4-second long blank at the beginning of each selection, so it won't work well if your tape has:

- No blank at the beginning of a selection .
- Noise (often caused by much use or poor quality dubbing) which fills the blank with noise.
- Long, very soft passages or pauses in a selection. The scan will detect these as 4-second long blanks. If this happens, just scan again until you reach the selection you want.

Other Useful Features of the Cassette Deck

REVERSE MODE

- ❑ Use **Reverse Mode** to make the tape automatically reverse at the end of a side and start playing the other side. Press the REVERSE MODE button to change from Reverse Mode on to Reverse Mode off, or from off to on.

Reverse Mode ON

Reverse Mode OFF

DOLBY B NR

- ❑ **Continuous Play:** With the Reverse Mode indicator on, when tape playback in the ◄ direction finishes, the Unit always checks to see if a tape is in the other deck. If there is, it automatically starts playing. This Continuous Play function works regardless of which deck starts first.
- ❑ Press the DOLBY B NR button to switch Dolby B Noise Reduction on (the indicator lights up) or off (the indicator goes off). If a tape is recorded with the Dolby B NR system, playing it back with the Dolby NR on will reduce tape noise and improve the clarity of the sound.

Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
"DOLBY" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

Using the Cassette Deck (Recording)



Recording onto a cassette from any of the sound sources is simple. Just place a tape in Deck B, have the source ready, make one or two settings, and you're ready to record. For each source the procedure is a little different and now we'll explain just what to do for each one. If you forget, just come back to the section which has the specific procedures you need. But first, here are a few things to make your recordings better.

Things To Know Before You Start Recording

- **It may be unlawful to record or play back copyrighted material without the consent of the copyright owner.**
- Press the DOLBY B NR button — the indicator lights up — to reduce tape hiss, except when dubbing tapes, since Dolby NR is inactive in Dubbing Mode regardless of the setting of DOLBY B NR. The dubbed tape automatically contains the same processing as the source tape.
- When you want to record onto both sides of a tape, you can set Reverse mode on to do so. However, recording automatically stops after recording in the ◄ direction in Reverse mode. Therefore, make sure that the tape direction is ► when recording with Reverse mode on.
- The recording level, which is the volume at which the new tape is being made, is automatically set correctly, so it is not affected by the VOLUME control on the CA-D661T. Thus, during recording you can adjust the sound you are actually listening to without affecting the recording level.
- Two small tabs on the back of the cassette tape, one for side A and one for side B, can be removed to prevent accidental erasure or re-recording. To record on a cassette with the tabs removed, you must cover the holes with adhesive tape first. However, when a type II tape is used, only cover part of the hole as shown, since the other part of the hole is used to detect the tape type.

- When recording, you can hear Sound Mode effects through the speakers or headphones. However, the sound is recorded without Sound Mode effects.
- Type I and Type II tapes can be used for recording.

Note: At the start and end of cassette tapes, there is leader tape which cannot be recorded onto. Depending on the recording source, the first part of the recording may be missing because of the leader. When recording CDs or radio broadcasts, to get the beginning of the recording on the tape, first wind on the leader before beginning recording.

CAUTION: If recordings you have made have excessive noise or static, the Unit may be too close to a TV which was on during the recording. Either turn off the TV or increase the distance between the TV and the CA-D661T.

Standard Recording

This is the basic method for recording any source. The CA-D661T also has special ways for recording CD to tape, and tape to tape, which save you time and effort, as well as give you some special effects. However, when you need to add a selection to a tape you have made, or are combining selections from several sources on one tape, use the method described below; just substitute the source you want into this procedure, such as a tape in Deck A, a CD, or the Tuner. You can also record from VCR with this procedure.

To Record Any Sound Source To Tape

Follow these steps to record from any sound source onto a tape in Deck B.

Using the Unit

1. **Insert a blank or erasable tape into Deck B.**
2. **Press the REVERSE MODE button if you want to record on both sides of the tape.**
   Reverse Mode comes on.
   - When using Reverse Mode, insert the tape so that it will be recorded in the forwards ► direction.
3. **Check the recording direction for the tape.**
   Check that the Tape Direction indicator is the same as that for the tape in the tape deck. If the directions are different, press the ■ button after pressing the ◅ or ▻ button to set the tape direction.
   - When using Reverse Mode to record both sides of a tape, check that the Tape Direction indicator is in the forwards ► direction. If the direction indicator is not in the forwards ► direction, press the ▻ button then press the ■ button.
4. **Prepare the source, by, for example, tuning in a radio station, loading CDs, or turning on connected equipment.**



5. **Press the REC START/STOP button.**
   The Recording indicator light comes on and the CA-D661T begins recording.

Using the Remote Control

1. **Insert a blank or erasable tape into Deck B.**
2. **Press the REC PAUSE button.**
   The Recording indicator light comes on.
3. **Press the REVERSE MODE button on the Unit if you want to record on both sides of the tape.**
   Reverse Mode comes on.
   - When using Reverse Mode, insert the tape so that it will be recorded in the forwards ► direction.
4. **Prepare the source by, for example, tuning in a radio station, loading CDs, or turning on connected equipment.**

5. **Press the ◄ or ► button.**
   Recording starts in the direction of the button pressed.
   - When using Reverse Mode to record both sides of a tape, press the ► button.

CAUTION: Operations other than using AUTO POWER OFF, the SLEEP timer or changing the CD for the other disc trays, may cause the recording source to be changed.

Notes for using Reverse Mode for recording
When recording in Reverse Mode, the CA-D661T automatically stops when it reaches the end of the reverse ◄ direction. To record on both sides of a tape, make sure that the recording direction for the tape inserted into Deck B is forwards ►, and that the Tape Direction indicator is also forwards ►, before you start recording.

To Pause at Any Time During the Recording Process
Press the REC PAUSE button on the Remote Control. Then press either the ◄◄ or ►► button on the Remote Control or REC START/STOP button on the Unit to restart recording.
To Stop at Any Time During the Recording Process
Press the REC START/STOP button on the Unit again, or press the ■ button.

CD Direct Recording

Everything on the CD goes onto the tape in the order it is on the CD, or according to the order you have set in a program.

1. Prepare CDs. (See page 15.)
Check that the CD Player is not playing a CD.

2. Insert a cassette in Deck B to record on.
❑ When you want to record on both sides of a tape, press the REVERSE MODE to turn Reverse Mode on. Check that the recording direction for the tape and the Tape Direction indicator are correct. (See "Notes for using Reverse Mode for recording" earlier on this page.)



3. Press the CD REC START button.
"CD REC" is displayed on the display then the Unit plays the CD and starts recording.

At the end of the tape, the CA-D661T automatically goes back to the beginning of the last selection and re-records it, this time gently fading out at the end. If you selected Reverse Mode, "TAPE SIDE-B STANDBY" scrolls through the display then the reverse side starts with the last selection of the first side. The last selection of the first side will fade out at the end. (A 10 second blank is created at the beginning of the reverse side.)
When the recording is finished, the message "CD REC FINISHED" scrolls by on the display. The CD Player and Cassette Deck stop.

To Stop at Any Time During the Recording Process
Press the REC START/STOP button or the ■ button on the Cassette Deck or CD Player (or the ■ button on the Remote Control).

Notes:
- When the Auto Power Off function is turned on while recording a CD, the power will automatically turn off when the CD finishes. Be careful when the Auto Power Off function is turned on while recording a CD in Repeat Mode, as repeat will be cancelled and the power will automatically turn off with Repeat Mode ("REPEAT ALL", "REPEAT 1 CD", or "REPEAT 1"). (Page 11)
- When making SLEEP timer settings while doing CD Direct recording, set the time so that there is enough leeway to finish the recording before the power goes off. If the time is set to about the length of the CD, the power may go off before recording finishes.

For CD Direct Recording using more than one disc, use a blank tape. If you use a prerecorded tape, prerecorded material may not be erased between newly-recorded tracks.

Auto Edit Recording

Using Auto Edit, you can record the CD tracks to fit the tape, so a selection isn't cut off. Auto Edit is one of the best ways to copy all of a CD onto a tape.
Auto Edit programs the CD tracks in numerical order. To prevent the end of the last track on the front side from being cut off, the last track on the front side is selected to fit on the remaining tape length.

1. Prepare CDs. (See page 15.)

2. Press the EDIT button on the Unit.
"DISC-" appears in the display.





3. Press the DISC button for the disc you want to record.
After "TAPE C - -" appears on the display, the optimum tape length for the disc you want to record is displayed.



❑ You can select a different length of tape, depending on the actual size of the tape you are using, from eleven possibilities programmed into the CA-D661T: 40, 46, 50, 54, 60, 64, 70, 74, 80, 84, 90. Select the tape length that corresponds to the length of tape you are using, or the nearest length to it, by adjusting the MULTI CONTROL stick left or right.
- If you pick a tape length shorter than the total playing time of the CD, the last tracks on both sides of the tape will be faded out as the tape ends.

4. Press the SET button.
The tracks to be recorded on side B of the tape appear on the display.

❑ To display the tracks that will be recorded on side A of the tape, press the SET button again. The Unit switches between side A and side B with each press of the SET button.
❑ To check the tracks that will be recorded, press the |◄◄ or ►►| buttons on the Remote Control.

5. Insert a cassette in Deck B to record on.
When you want to record on both sides of a tape, press the REVERSE MODE button to turn Reverse mode on.



6. Press the CD REC START button.
The Unit plays the CD and starts recording. If the tape has not been rewound, the Unit rewinds the tape before starting to record the CD.

When the tape is ready, to prevent the start of a track being cut, the CA-D661T creates a blank period of 10 seconds before it starts to record the CD. While a blank period is being created, "TAPE SIDE-A STANDBY" scrolls through the display. (The CA-D661T also creates a 10 second blank period at the start of side B of the tape. While a blank period is being created, "TAPE SIDE-B STANDBY" scrolls through the display.)

When the recording is finished, the message "CD REC FINISHED" scrolls by on the display. The CD Player and Cassette Deck stop.

To stop at any time while recording, press the ■ button (CD control or Cassette Deck control) or the REC START/STOP button. If you press the CD control ■ button, the Cassette Deck creates a four second blank space after the CD Player stops. If you press any other button to stop the recording, the CD Player and Cassette Deck stop at the same time.

To cancel Auto Edit, press the ▲ button for disc number being recorded, or press the PROGRAM/RANDOM button while the CD Player is stopped.

Note: When making SLEEP timer settings while doing Auto Edit recording, set the time so that there is enough leeway to finish the recording before the power goes off. If the time is set to about the length of the CD, the power may go off before recording finishes.

Tape to Tape Recording (Dubbing)

Recording from one tape to another is called dubbing.
You can dub tapes simply, with just a single button.

- ❑ When dubbing tapes, make sure that the playback direction of Deck A and Deck B are the same.
- ❑ When you want to record both sides of a tape, press the REVERSE MODE button to turn Reverse mode on.
- ❑ It is preferable that the type of tape (Type I or Type II) you record from be the same as the type you record onto.

How to Use the DUBBING Button



1. **Insert the source cassette you want to copy from into Deck A for playback.**
2. **Insert the blank or erasable cassette you want to copy onto in to Deck B for recording.**
3. **Press the DUBBING button.**
   Deck A and Deck B will start simultaneously.

To stop dubbing, press the ■ button or REC START/STOP button.

- ❑ Dolby NR is inactive in dubbing mode regardless of the setting of DOLBY B NR. The dubbed tape automatically contains the same processing as the source tape.
- ❑ When doing dubbing with the DUBBING button, you can hear Sound Mode effects through the speakers or headphones. However, the sound is dubbed without Sound Mode effects.

Using the Timers





Display



When the CA-D661T is being used, the display shows other items as well. However, we have only shown the items described in this section.

The timers lets you control recording and listening functions automatically.
Three types of timers are available:

- ❑ **DAILY Timer** — Use this timer to set wake up everyday to music from any source, instead of an alarm clock.
- ❑ **REC (Recording) Timer** — Unattended recording of radio broadcasts. You can set the starting time and length of the recording.
- ❑ **SLEEP Timer** — Fall asleep and have your CA-D661T turn off automatically after a certain length of time.

Setting the Clock



The timers depend on the clock: the clock must be right for the timers to work as you expect.
You can set the clock whether the Unit is on or off.
Note that the clock must be set, or the timers cannot be set.

1. **Press the TIMER/CLOCK button.**
   The "CLOCK" indicator and the hour digits blink on the display.
2. **Set the hour by adjusting the MULTI CONTROL stick left or right.**
   Adjust the MULTI CONTROL stick to the right to advance the hour setting, adjust it to the left to decrease the setting. Press the MULTI CONTROL stick continuously to increase or decrease the hour setting rapidly.
3. **Press the SET button.**
   The minute digits blink on the display.
4. **Set the minute by adjusting the MULTI CONTROL stick left or right.**
   Adjust the MULTI CONTROL stick to the right to advance the minute setting, adjust it to the left to decrease the setting. Press the MULTI CONTROL stick continuously to increase or decrease the minute setting rapidly in 10 minute steps.
5. **Press the SET button.**
   "CLOCK OK" appears on the display, and the clock starts at zero seconds from the set time.

CAUTION: If there is a power failure, the clock loses its setting. The display shows "AM 12:00", and the clock must be reset.

Setting the DAILY Timer

With this timer you can wake up to music from a CD, tape, your favorite radio program, or other source.

❑ You can set the DAILY Timer whether the Unit is on or off.



Procedure For Setting the DAILY Timer

1. Press the TIMER/CLOCK button so that "DAILY Timer" appears in the display.
The message "DAILY" blinks and the DAILY indicator light blinks on the display.



❑ The display changes with each press of the button, as shown below.
DAILY (blinks) → **ON TIME** (blinks) → **REC** (blinks) → **ON TIME** (blinks) → **CLOCK** (blinks) (Clock setting mode) → original display before the TIMER/CLOCK button was pressed → (back to the beginning)

Note: If the clock has not been set, even if the TIMER/CLOCK button is pressed you cannot select the DAILY Timer.



2. Press the TIMER/CLOCK button again.
The display changes to the On Time display.



3. Set the time you want the Unit to turn on.
Set the time by adjusting the MULTI CONTROL stick left or right in the same way you set the time for the clock. Press the SET button to set the on time.



The "OFF time" hour setting starts to blink after the "ON time" minute setting is set.

4. Set the time you want the Unit to turn off.
Set the time by adjusting the MULTI CONTROL stick left or right in the same way you set the time for the clock. Press the SET button to set the off time.

❑ When the off time has been set, the display changes to the source selection display.



5. Select the source you want to listen to.

To use the Tuner as the source:

1. Adjust the MULTI CONTROL stick left or right until "TUNER" blinks in the display.

2. Adjust the MULTI CONTROL stick up or down to select the preset channel you want to listen to.



3. Press the SET button.

To use a CD as the source:

1. Adjust the MULTI CONTROL stick left or right until "- CD - - -" blinks in the display.



2. Adjust the MULTI CONTROL stick up or down to select the disc tray containing the CD you want to play.



3. Press the SET button.
If you press the SET button without selecting a disc, the last disc played by the CA-D661T will be used.

4. Adjust the MULTI CONTROL stick up or down to the select the starting track of the CD.
You can only select upto 20 tracks.



5. Press the SET button.
If you press the SET button without selecting a track, playback will start from the first track on the CD.

To use a Cassette Deck as the source:

1. Adjust the MULTI CONTROL stick left or right until "TAPE" blinks in the display.

2. Press the SET button.

To use another source:
Use this to select a radio station that has not been preset.

1. Adjust the MULTI CONTROL stick left or right until "- - - -" blinks in the display.



2. Press the SET button.
The last source used is selected.

6. Setting the Volume Level.
Adjust the MULTI CONTROL stick left or right to set the volume level.

VOLUME - A: Sets the volume level to 10.
VOLUME - B: Sets the volume level to 15.
VOLUME - C: Sets the volume level to 20.
VOLUME - - : Sets the volume to the last volume setting used.

7. Press the SET button.
The "DAILY" indicator changes from a blinking display to a steady display. The ON TIME, OFF TIME, PLAYBACK SOURCE (including the disc number and track number if a CD source is selected) are displayed then the display reverts to the previous display, before the Timer was set.
Turn the power off if you made the timer settings with the power turned on.

- A few seconds before the start for the timer, the CA-D661T automatically turns on the power, and the "DAILY TIMER" blinks on the display. When the set time is reached, playback starts using the selected source. After the finish time for the timer is reached, the power is automatically turned off again.
- If a button is pressed when the DAILY Timer is operating, recording continues but the timer is cancelled.

Before Turning Off the Unit
- If the source is a CD, make sure that there is a CD in the selected disc number.
- If the source is a tape:
  - The tape in the deck corresponding to the Deck Indicator mark is played. Make sure that there is a tape in the selected Cassette Deck.
  - Check that the tape direction is correct. This is important especially when Reverse Mode is off.
  - Set Reverse Mode on if you want to play both sides of the tape.
- Select the Sound Mode if you want to listen using a Sound Mode effect.

To change the DAILY Timer setting
To change the settings for the DAILY Timer, repeat the setting procedure from the beginning.

Turning the DAILY Timer On and Off

Once the DAILY Timer has been set it will be activated at the same time every day until the setting is turned off.
To turn the DAILY Timer off, press the TIMER/CLOCK button until "DAILY" appears in the display. Press the CANCEL button, "OFF" appears in the display and the DAILY indicator goes out.
To turn the DAILY TIMER on again, press the TIMER/CLOCK button until "DAILY" appears in the display, then press the SET button. The Timer ON TIME, OFF TIME, PLAYBACK SOURCE (including the disc number and track number if a CD source is selected) are displayed on the display.

CAUTION: If the CA-D661T is unplugged, or a power failure occurs, the timer setting will be erased in a few days. If the settings are erased in this way, reset the timer settings.

Setting the REC (Recording) Timer

With the Recording Timer you can make a tape of a radio broadcast automatically whether or not you are home. For the timer to work correctly, you need to make sure of the following in addition to setting the time for the Tuner and Cassette Deck to come on:
- You can set the REC Timer whether the Unit is on or off.
- The tape you want to record onto must be in Deck B.



Procedure for Setting the REC Timer

1. Press the TIMER/CLOCK button so that "REC Timer" appears in the display.
The message "REC" blinks and the REC indicator light blinks on the display.



- The display changes with each press of the button, as shown below.
  DAILY (blinks) → **ON TIME** (blinks) → **REC** (blinks) → **ON TIME** (blinks) → **CLOCK** (blinks) (Clock setting mode) → original display before the TIMER/CLOCK button was pressed → (back to the beginning)

Note: If the clock has not been set, even if the TIMER/CLOCK button is pressed you cannot select the REC Timer.



2. Press the TIMER/CLOCK button again.
The display changes to the On Time display.



3. Set the time you want the Unit to be turned on.
Set the time by adjusting the MULTI CONTROL stick left or right in the same way you set the time for the clock. Press the SET button to set the on time.

4. Set the time you want the Unit to be turned off.
Set the time by adjusting the MULTI CONTROL stick left or right in the same way you set the time for the clock. Press the SET button to set the off time.

5. Select the radio station you want to record.
Set the radio station you want to record by adjusting the MULTI CONTROL stick up or down.

6. Press the SET button.
The "REC" indicator changes from a blinking display to a steady display. The ON TIME, OFF TIME, and preset channel number are displayed then the display reverts to the previous display, before the Timer was set.
Turn the power off if you made the timer settings with the power turned on.

- A few seconds before the start time for the recording, the CA-D661T automatically turns on the power, and "REC TIMER" blinks on the display. When the start time is reached, recording starts using the selected source. After the finish time for the recording is reached, the power is automatically turned off again.
- If a button is pressed when the REC Timer is operating, recording continues but the timer is cancelled.

Before the Timer Starts
- Check that tape direction is correct. This is important especially when Reverse Mode is off.
- Set Reverse Mode on if you want to record on both sides of the tape.
- The VOLUME control is automatically set to 0 when REC Timer is recording.

It is very easy, and can be very disappointing, to forget to put in a tape, or to accidentally leave a tape in Deck B you don't want recorded over. Although this happens to almost everyone at one time or another, we hope it won't happen to you!

To Change the Recording Timer Setting
To change the settings for the REC Timer, repeat the setting procedure from the beginning.

Turning the REC Timer On and Off

Once the REC Timer has been used to record a source, the setting is maintained but the Timer is set to OFF.
To record at the same time again, press the TIMER/CLOCK button until "REC" appears in the display, then press the SET button. The ON TIME, OFF TIME, channel frequency, and preset channel number are displayed then the display reverts to the previous display, before the Timer was set.
To turn the REC Timer off before the timer starts, press the TIMER/CLOCK button until "REC" appears in the display, then press the CANCEL button. "OFF" appears in the display and the REC indicator goes out.

CAUTION: If the CA-D661T is unplugged, or a power failure occurs, the timer setting will be erased in a few days. If the settings are erased in this way, reset the timer settings.

Setting the SLEEP Timer

Use the Sleep Timer to turn the Unit off after a certain number of minutes when it is playing. By setting this timer, you can fall asleep to music and know your Unit will turn off by itself rather than play all night.
❑ You can only set the Sleep Timer when the Unit is on and a source is playing.

To set the SLEEP Timer, follow this procedure:

SLEEP

1. With the CA-D661T on and a source playing, press the SLEEP button on the Remote Control.
The message "SLEEP" appears on the display.



2. Set the length of time you want the source to play before shutting off.
❑ Each time you press this button while the "SLEEP" indicator is blinking, it changes the number of minutes shown on the display in this sequence:

→ **10** → **20** → **30** → **60** → **90** → **120** → Cancelled → (back to the beginning)

When the number of minutes you want shows on the display, just wait 5 seconds until the indicator stops blinking, and is lighted steadily.
The Unit is now set to turn off after the number of minutes you set.

To Change the SLEEP Timer Setting
Press the SLEEP button until the number of minutes you want appears on the display.
To Cancel the SLEEP Timer Setting
Press the SLEEP button until the "SLEEP" indicator goes off on the display.
Turning off the Unit also cancels the SLEEP Timer.

Timer Priority

Since each timer can be set independently, you may wonder what happens if the settings overlap. Here are the priorities for each timer:
❑ The REC Timer always has priority. This means that:
- If another timer is set to come on during a time when the REC Timer is operating, the other timer just won't come on at all, so you will always get the entire program on tape.
- If the REC Timer is set to come on while another timer is operating, the other timer will shut off 10 seconds before the REC Timer is set to turn on, and the REC Timer will then take over.

❑ The SLEEP Timer has the least priority. This means that if the SLEEP Timer is set while the DAILY Timer is operating, the DAILY Timer settings are cancelled. However, if the DAILY Timer is set to come while the SLEEP Timer is operating, the SLEEP Timer setting will be cancelled and the Unit will use the settings from the DAILY Timer.

Example 1



The REC Timer has priority.

Example 2



The REC Timer has priority.

Care And Maintenance

Compact Discs

Handle your compact discs, cassette tapes, and Cassette Deck carefully, and they will last a long time.

- Remove the CD from the case by holding it at the edges while pressing the center hole lightly.
- Do not touch the shiny surface of the CD, or bend the CD.

- Put the CD back in its case after use to prevent warping.
- Be careful not to scratch the surface of the CD when placing it back in the case.
- Avoid exposure to direct sunlight, temperature extremes, and moisture.

- A dirty CD may not play correctly. If a CD does become dirty, wipe it with a soft cloth in a straight line, from center to edge.

CAUTION: Do not use any solvent (for example, conventional record cleaner, spray thinner, benzine, etc.) to clean a CD.

Moisture Condensation

Moisture may condense on the lens inside the Unit in the following cases:

- After starting the heating in the room.
- In a damp room.
- If the unit is brought directly from a cold to a warm place.

Should this occur, the Unit may malfunction. In this case, leave the unit turned on for a few hours until the moisture evaporates, unplug the AC power cord, and then plug it in again.

General Notes

In general, you will have the best performance by keeping your tapes, CDs, and the mechanism clean.

- Store tapes and CDs in their cases, and keep them in cabinets or on shelves.
- Keep the Cassette Deck's tape holder and the CD trays closed when not in use.

Cassette Tapes

- If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels and rotating.
- If the tape is loose, it may get stretched, cut, or caught in the cassette.

- Do not touch the tape surface.

- Do not store the tape:
  - In dusty places
  - In direct sunlight or heat
  - In moist areas
  - On a TV or speaker
  - Near a magnet

Cassette Deck

- If the heads, capstans, and pinch-rollers of the Cassette Deck become dirty, the following will occur:
  - Loss of sound quality
  - Discontinuous sound
  - Fading
  - Incomplete erasure
  - Difficulty recording
- Clean the heads, capstans, and pinch-rollers using a cotton swab moistened with alcohol.



- If the heads become magnetized, the Unit will produce noise or lose high frequencies.
- To demagnetize the heads, turn off the Unit, and use a head demagnetizer (available at electronics and record shops).

Troubleshooting

- If you are having a problem with your CA-D661T, check this list for a possible solution before calling for service.
- If you cannot solve the problem from the hints given here, or the Unit has been physically damaged, call a qualified person, such as your dealer, for service.

Symptom	Possible Cause	Action
No sound is heard.	Connections are incorrect, or loose.	Check all connections and make corrections. (See pages 4 - 5.)
Unable to record.	Cassette record protect tabs are removed.	Cover holes on back edge of cassette with tape.
Poor radio reception	• The antenna is disconnected. • The AM Loop Antenna is too close to the Unit. • The FM Wire Antenna is not properly extended and positioned.	• Re-connect the antenna securely. • Change the position and direction of the AM Loop Antenna. • Extend FM Wire Antenna to the best reception position.
The CD skips.	The CD is dirty or scratched.	Clean or replace the CD.
Unable to operate the Remote Control.	• The path between the Remote Control and the sensor on the Unit is blocked. • The batteries have lost their charge.	• Remove the obstruction. • Replace the batteries.
The CD tray cannot be opened.	The main AC power cord is not plugged in.	Plug in the AC power plug.
The CD does not play.	The CD is upside down.	Put the CD in with the label side up.
Operations are disabled.	The built-in microprocessor has malfunctioned due to external electrical interference.	Unplug the Unit then plug it back in.
The cassette door cannot be opened.	During tape playing, the power cord was unplugged.	Plug in the power cord, press the POWER button, and then the ⏏ button.

Description of ICs

■ MN172412JAAW(IC902) : TUNER / DISPLAY Controller

1. Terminal layout



2. Terminal Function

Pin No.	Symbol	I/O	Functions and Operations	Pin No.	Symbol	I/O	Functions and Operations
1	7G	O	FL grid control	49	RDS RST	I	Reset signal from IC
2	8G	O	FL grid control	50	/TUNED	I	TUNED indication control
3~15	P1~P13	O	FL anode control	51	/STEREO	I	STEREO indication control
16	P14	O	FL anode control	52	MUTE	O	Muting of tuner sound
17	P15	O	FL anode control	53	DCSOUT	O	Compulink signal output
18	P16	O	FL anode control	54	DCSIN	I	Compulink signal input
19	P20	O	FL anode control	55	CS2	I	chip select terminal input
20	P19	O	FL anode control	56	KI1	I	Key matrix input
21	P18	O	FL anode control	57	KI2	I	Key matrix input
22	P17	O	FL anode control	58	KI3	I	Key matrix input
23	-BP	--	Power supply for FL display	59	KI4	I	Key matrix input
24	P36	O	FL anode control	60	IFDATA	I	Data from PLL synthesizer
25	P35	O	FL anode control	61	CE	O	Chip enable signal for PLL synthesizer
26	P34	O	FL anode control	62	CK	O	Clock for PLL synthesizer
27	P33	O	FL anode control	63	TUDATA	O	Data for PLL synthesizer
28	P32	O	FL anode control	64	CS1	I	chip select terminal input
29	P31	O	FL anode control	65	C-REQ	I	Communication request data to IC301
30	P30	O	FL anode control	66	C-CLK	O	Communication data clock to IC301
31	P29	O	FL anode control	67	C-DATA	O	Communication data to IC301
32	P28	O	FL anode control	68	/RESET	I	RESET signal input
33	P27	O	FL anode control	69	GND	--	Connected to GND
34	P26	O	FL anode control	70	X1	--	Non connection
35	P25	O	FL anode control	71	X2	--	Connected to GND
36	P24	O	FL anode control	72	OSC2	I/O	Clock oscillation terminal
37	P23	O	FL anode control	73	OSC1	I/O	Clock oscillation terminal
38	P22	O	FL anode control	74	VDD	---	Power supply (+ B5V)
39	P21	O	FL anode control	75	T-REQ	I	Request signal to IC901
40	FOUT	O	Clock frequency	76	T-CLK	O	Clock signal to IC901
41	SPISTB	O	Strobe signal for IC303	77	T-DATA	O	Data for IC901
42	SPIDT1	O	Data input from IC303	78	NC	--	Non connection
43	SPIDTO	O	Data output for IC303	79	1G	O	FL grid control
44	SPICSB	O	Chip select output for IC303	80	2G	O	FL grid control
45	RDS CK	O	Clock input from IC	81	3G	O	FL grid control
46	RDS DATA	O	Data signal from IC	82	4G	O	FL grid control
47	RDS RST	O	Reset signal for IC	83	5G	O	FL grid control
48	/TUINH	I	Inhibit signal Input	84	6G	O	FL grid control

■ MN17P3222JAAX(IC301) : DECK/CD Controller

1. Terminal layout



3. Terminal Function

Pin No.	Symbol	I/O	Functions and Operations	Pin No.	Symbol	I/O	Functions and Operations
1	/APACK	I	APACKswitch detect input	49	/RESTSW	I	Traverse REST sw input
2	AEQ	O	It is "L" when CrO2 tape is in deck A	50		--	Connected to GND
3	DECKAI	O	DECKA indicater control	51		--	Connected to GND
4	DECKBI	O	DECKB indicater control	52	/RST	O	CD Lsi reset signal output
5		--	Non connection	53	MLD	O	Command load signal output to CD Lsi
6		--	Non connection	54	MDATA	O	Command data output to CD Lsi
7	RECI	O	Indication control	55	MLCK	O	Command clock signal output to CD Lsi
8	PON IND	O	Power indicater control	56	DATA	O	Communication data to changer μ-com
9	DISC1IND	O	DISC1 indicater control	57	SCK	O	Communication clock signal to changer μ-com
10	DISC2IND	O	DISC2 indicater control	58	CHST	I	Strobe signal to changer μ-com
11	DISC3IND	O	DISC3 indicater control	59	REQ1	I	Request signal to changer μ-com
12	PBEQ	O	Play back	60		--	Connected to GND
13	MSIN	I	music scan signal input	61		--	Connected to GND
14	NR	O	NR control signal	62		--	Connected to GND
15	/CAPN	O	Capstan (ON/OFF) control	63	CS	--	Connected to GND
16	BPLZ	O	B mecha. solenoide control	64		--	Connected to GND
17	APLZ	O	A mecha. solenoide control	65		--	Connected to GND
18		--	Connected to GND	66		--	Connected to GND
19		--	Non connection	67		--	Connected to GND
20	BMT	O	It is 'H'when Deck B is not playing	68	/RESET	I	CD reset signal input
21	OMT	O	Deck PB Mute control signal	69	GND	--	Connected to GND
22	RMT	O	Recording mute signal output	70	NC	--	Non connection
23		--	Non connection	71	GND	--	Connected to GND
24	/PB/REC	O	Rec. P.B select signal output	72	OSC	I	Osilaltion terminal
25	REC	O	It is "H" when recording	73	OSC	--	Osilaltion terminal
26	BIAS	O	REC bias ON/OFF control	74	VDD	--	+ 5V
27~39		--	Connected to GND	75	DCS IN	I	DCS signal input
40	C-REQ	O	Communication request data output to IC902	76	DCS OUT	O	DCS signal output
41	C-CLK	I	Clock signal input from IC902	77	APLS	I	A mech. reel palse input
42		--	Non connection	78	BEQ	O	Play equalizer control
43	C-DATA	I	Command data output to IC902	79	/PSWB	I	B mech. play switch input
44		--	Connected to GND	80	BPLS	I	B mech.pranger control output
45	SQCK	O	Outside lock for sub-code Q resister output	81	/FREC	I	FREC switch detect input
46	SUBQ	I	Sub code and Q register signal input	82	/RREC	I	RREC switch detect input
47	LSION	O	CD Lsi on signal output	83	/BPACK	I	BPACKswitch detect input
48	STAT	O	STATUS signal (CRC,CUE,CLVS,TTSTOP,ECLV,SQOK)	84	/PSWA	O	A mech. play switch input

■ HD404719A71FS(IC901) : AMP Controller

1. Terminal layout



2. Terminal Function

Pin No.	Symbol	I/O	Functions and Operations	Pin No.	Symbol	I/O	Functions and Operations
1	IN6	I	Key input (A/D convert)	40		--	Not use
2	/INH	I	Inhibit signal input	41	CDI	O	CD indication control
3	/PRT	I	Protector signal input	42	TUI	O	TUNED indication control
4	AD GND	--	Connected to GND	43	TAPEI	O	TAPE indication control
5	RESET	I	Reset signal input	44	VCRI	O	VCR indication control
6	OSC1	I/O	Clock oscillation terminal	45		--	Not use
7	OSC2	I/O	Clock oscillation terminal	46	APOI	O	APO indication control
8	GND	--	Connected to GND	47	BASSI	O	BASS indication control
9		--	Connected to GND	48	STUNDBYI	O	STNDBY indication control
10		--	Not use	49		--	Connected to GND
11	/TEST	O	Pull up	50~57		--	Not use
12	VCC	--	Power supply	58	SCK	O	Clock for IC401
13	RDS	O	Chip select teminal	59	SDA1	O	Data for IC401
14	PROLOGIC	O	Chip select teminal	60		--	Not use
15	KARAOKE	O	Chip select teminal	61	/RMIN	I	Remote control signal input
16	ECHO	O	Chip select teminal	62		--	Not use
17	SABASS	O	Chip select teminal	63	T-DATA	I	Communication data from IC302
18	HPIN	I	Head phone detect	64	T-REQ	O	Communication request data to IC302
19	CDRESET	O	CD servo Lsi reset signal outrput	65	T-CLK	O	Communication data clock from IC302
20	/TUINH	O	Tuner Inhibit signal output	66~68		--	Not use
21	TURESET	O	Tuner reset signal outrput	69	JOG2	I	Input 2 Jog pulse
22	DCSIN	I	Compulink signal data input	70	JOG1	I	Input 1 Jog pulse
23	DCSOUT	O	Compulink signal data output	71		--	Not use
24	ACO	O	Power suplly control signal	72	SMUTE	O	Source Mute control signal
25	CONT.A	O	KARAOKE on/off control signal	73	ECHO2	O	Echo2 signal output
26,27		--	Not use	74	ECHO1	O	Echo1 signal output
28	RERAY1	O	Speaker relay on/off signal output	75	AD Vcc	---	Power supply (+ B5V)
29		--	Not use	76	IN1	I	Key input (A/D convert)
30	SURR	O	Surrund ON/OFF control signal	77	IN2	I	Key input (A/D convert)
31		--	Not use	78	IN3	I	Key input (A/D convert)
32~38		--	Not use	79	IN4	I	Key input (A/D convert)
39		--	Not use	80	IN5	I	Key input (A/D convert)

■ MN35510 (IC603) : DIGITAL SERVO & DIGITAL SIGNAL PROCESSER

1. Terminal Layout



2. Block Diagram



3. Description

Pin No.	symbol	I/O	Description	Pin No.	symbol	I/O	Description
1	BCLK	O	Bit clock output pin SRDATA	41	TES	O	Tracking error shunt signal output (H;shunt)
2	LRCK	O	L/R distinction signal output	42	PLAY	—	Not used
3	SRDATA	O	Serial data output	43	WVEL	—	Not used
4	DVDD1	—	Power supply(Digital)	44	ARF	I	RF signal input
5	DVSS1	—	Connected to GND (Digital)	45	IREF	I	Reference current input pin
6	TX	O	Not use	46	DRF	—	Connected to GND
7	MCLK	I	μ-com command clock signal input (Data is latched at signal's rising point)	47	DSLF	I/O	Loop filter pin for DSL
8	MDATA	I	μ-com command data input	48	PLLF	I/O	Loop filter pin for PLL
9	MLD	I	μ-com command load signal input	49	VCOF	—	Connected to GND
10	SENSE	O	Not used	50	AVDD2	—	Power supply (Analog)
11	FLOCK	O	Not used	51	AVSS2	—	Connected to GND(Analog)
12	TLOCK	O	Not used	52	EFM	—	Not used
13	BLKCK	O	Subcode · block · clock signal output	53	PCK	—	Not used
14	SQCK	I	Outside lock for sub-code Q resister input	54	PDO	—	Not used
15	SUBQ	O	Sub-code Q-code output	55	SUBC	—	Not used
16	DMUTE	—	Connected to GND	56	SBCK	—	Not used
17	STATUS	O	Status signal (CRC,CUE,CLVS,TTSTOP,ECLV,SQOK)	57	VSS	—	Connected to GND(for X'tal cscillation circuit)
18	RST	I	Reset signal input (L :Reset)	58	X1	I	Input of 16.9344MHz X'tal oscillation circuit
19	SMCK	—	Not used	59	X2	O	Output of X'tal oscillation circuit
20	PMCK	—	Not used	60	VDD	—	Power supply(for X'tal cscillation circuit)
21	TRV	O	Traverse enforced output	61	BYTCK	—	Not used
22	TVD	O	Traverse drive output	62	CLDCK	—	Not used
23	PC	—	Not used	63	FCLK	—	Not used
24	ECM	O	Spindle motor drive signal (Enforced mode output) 3-State	64	IPPLAG	—	Not used
25	ECS	O	Spindle motor drive signal (Servo error signal output)	65	FLAG	—	Not used
26	KICK	O	Kick pulse output	66	CLVS	—	Not used
27	TRD	O	Tracking drive output	67	CRC	—	Not used
28	FOD	O	Focus drive output	68	DEMPH		Not used
29	VREF	I	Reference voltage input pin for D/A output block(TVD,FOD,FBAL,TBAL)	69	RESY	—	Not used
30	FBAL	O	Focus Balance adjust signal output	70	IOSEL	—	Pull up
31	TBAL	O	Tracking Balance adjust signal output	71	TEST	—	Pull up
32	FE	I	Focus error signal input(Analog input)	72	AVDD1	—	Power supply (Digital)
33	TE	I	Tracking error signal input(Analog input)	73	OUT L	O	Lch audio output
34	RF ENV	I	RF envelope signal input(Analog input)	74	AVSS1	—	Connected to GND
35	VDET	I	Vibration detect signal input(H : detect)	75	OUT R	O	Rch audio output
36	OFT	I	Off track signal input(H : off track)	76	RSEL	—	Pull up
37	TRCRS	I	Track cross signal input	77	CSEL	—	Connected to GND
38	RFDET	I	RF detect signal input (L : detect)	78	PSEL	—	Connected to GND
39	BDO	I	BDO input pin (H : drop out)	79	MSEL	—	Connected to GND
40	LDON	O	Laser ON signal output (H : on)	80	SSEL	—	Pull up (+ 5V)

■ AN8806SB (IC601) : RF & SERVO AMP

1. Terminal Layout



2. Block Diagram



3. Functions

Pin No.	Symbol	I/O	Functions and operations
1	PD	I	APC amp input terminal
2	LD	O	APC amp output terminal
3	LD ON	I	APC ON/OFF control terminal
4	LDP	--	Connected to ground
5	VCC	--	Power supply
6	RF-	I	Inverse input pin for RF amp
7	RF OUT	O	RF amp output
8	RF IN	I	RF input
9	C.AGC	I/O	Connecting pin of AGC loop filter
10	ARF	O	RF output
11	C.ENV	I/O	A capacitor is connected to this terminal to detect the envelope of RF signal
12	C.EA	I/O	A capacitor is connected to this terminal to detect the envelope of RF signal
13	CS BDO	I/O	A capacitor is connected to detect the lower envelope of the RF signal
14	BDO	O	BDO output pin
15	CS BRT	I/O	A capacitor is connected to detect the lower envelope of the RF signal
16	OFTR	O	Of-track status signal output
17	/NRFDET	O	RF detection signal output
18	GND	--	Ground
19	ENV	O	Envelope output
20	VREF	O	Reference voltage output
21	LD OFF	--	Connect to ground
22	VDET	O	Vibration detection signal output
23	TE BPF	I	Input pin of tracking error through BPF
24	CROSS	O	Tracking error cross output
25	TE OUT	O	Tracking error signal output
26	TE-	I	Inverse input pin for tracking error amp
27	FE OUT	O	Output pin of focus error
28	FE-	I	Inverse input pin for focus error amp
29	FBAL	I	Focus balance control
30	TBAL	I	Tracking balance control
31	PDFR	I/O	F I-V amp gain control
32	PDER	I/O	E I-V amp gain control
33	PDF	I	I-V amp input
34	PDE	I	I-V amp input
35	PD BD	I	I-V amp input
36	PD AC	I	I-V amp input

■ LC72131 (IC121) : PLL Synthesizer

1. Terminal Layout



2. Block Diagram



3. Pin Functions

Pin No.	Symbol	I/O	Functions	Pin No.	Symbol	I/O	Functions
1	X in	I	Crystal oscillator (7.2MHz).	12	FM/AM IF	I	Universal counter input
2		--	Not nse	13	IF REQ	O	Output the "IF-signal request" to IC102
3	PLLCE	I	Fix the chip enable to "H" when inputting(DI) and outputting (DO) the serial data	14		I	Not use
4	PLLDA	I	Receive the control data from the controller (IC201).	15	AMOSC		Input the local oscillator signal of AM.
5	PLLCK	I	This clock is used to synchronize data when transmitting the data of DI and DO.	16	FM OSC	I	Input the local oscillator signal of FM.
6	IFDATA	O	Transmit the data from LC72131 to the controller which is synchronized with CK.	17	VDD	O	This is a terminal of power supply.
7	$\overline{\text{FM}}$	O	It is "L" on FM mode.	18	PD	O	PLL charge pump output : When the local oscillator signal frequency is higher than the reference frequency high level signals will output. When it is lower than the reference frequency, low level signals will output. When it is same as reference frequency signals, it will be floating.
8	$\overline{\text{AM}}$	O	It is "L" on MW mode.	19	LPF IN	I	Transistor used for the PLL active low-pass filterr
9	LW	O	It is "L" on LW mode.	20	LPF OUT	O	Transistor used for the PLL active low-pass filterr
10	$\overline{\text{AUTO}}$ MONO	O	It is "L" on monaural, "H" on auto.	21	VSS	--	Connected to GND
11	$\overline{\text{POWER}}$	O	Regulator control singal P ON "H", STANDBY "L"	22	X out	O	Crystal oscillator (7.2MHz).

■ LA1837 (IC102) : FM AM IF AMP & detector, FM MPX Decorder

1. Terminal Layout



3. Pin Function

Pin No.	Symbol	I/O	Function
1	FM IN	I	This is an input terminal of FM IF Signal.
2	AM MIX	O	This is an output terminal for AM mixer.
3	FM IF	I	Bypass of FM IF
4	AM IF	I	Input of AM IF Signal.
5	GND	—	This is the device ground terminal.
6	/TUNED	O	When the set is tunning ; this terminal becomes "L".
7	STEREO	O	Stereo indicator output. Stereo : "L", Mono : "H"
8	VCC	—	This is the power supply terminal.
9	FM DET	—	FM detect transformer.
10	AM SD	—	AM ceramic filter terminal
11	FM VSM	O	Fix the sensitivity of FM tuned
12	AM VSM	O	Fix the sensitivity of AM tuned
13	MUTE	O/I	When the signal of IF REQ of IC121(LC72131) appear, the signal of FM/AM IF output. //Muting control input.
14	FM/AM	I	Change over the FM / AM input. "H" : FM, "L" : AM
15	MONO/ST	O	Stereo : "H", Mono : "L"
16	L OUT	O	Left channel signal output.
17	R OUT	O	Right channel signal output
18	L IN	I	Input terminal of the Left channel post AMP.
19	R IN	I	Input terminal of the Right channel post AMP.
20	R OUT	O	Mpx Right channel signal output.
21	L OUT	O	Mpx Left channel signal output.
22	IF IN	I	Mpx input terminal.
23	FM OUT	I	Voltage controlled oscillator terminal.
24	AM DET	—	AM low cut adjustment.
25	AM AGC	I	This is an AGC voltage input terminal for AM.
26	AFC	—	This is an output terminal of voltage for FM-AFC.
27	AM RF	I	This is an input terminal for AM RF signal.
28	REG	—	Control of desides the frequency width
29	AM OSC	—	This is a terminal of AM Local oscillation circuit.
30	OSC BUFFER	O	AM Local oscillation Signal output.

2. Block Diagram



■ UPD65612GB-165(IC801) : Changer Controller

1. Terminal Layout



2. Pin Functions

Pin No.	Symbol	I/O	Function	Pin No.	Symbol	I/O	Function
1	NC	--	Non connection	23	2SSW	I	TRAY2 switch input signal
2	NC	--	Non connection	24	1SSW	I	TRAY1 switch input signal
3	NC	--	Non connection	25	NC	--	Non connection
4	OS1I	I	Oscillation terminal	26	CAM0	I	Cam switch input signal for LCAM
5	OS1O	O	Oscillation terminal	27	CAM1	I	Cam switch input signal for LCAM
6	OS2I	I	Oscillation terminal	28	CAM2	I	Cam switch input signal for LCAM
7	OS2O	O	Oscillation terminal	29	CAM3	I	Cam switch input signal for LCAM
8	NC	--	Non connection	30	CAM4	I	Cam switch input signal for RCAM
9	C25IN	I	Connected to C25OUT	31	CAM5	I	Cam switch input signal for RCAM
10	C25OUT	O	Connected to C25IN	32	CAM6	I	Cam switch input signal for RCAM
11	RESET	I	Reset signal input	33	CAM7	I	Cam switch input signal for RCAM
12	REQ	O	Output the "mecha. data request"	34	FIT	O	Connected to C50
13	DATA	I/O	Control,Status data I/O	35	C50	I	Connected to FIT
14	ST	I	Strobe signal input	36	LMUP	O	L motor control signal
15	CKS	I	Clock input	37	LMDWN	O	L motor control signal
16	SELECT	--	Connected to GND	38	C25	--	Non connection
17	GND	--	GND	39	VDD	--	Power supply terminal
18	CK	--	Connected to GND	40	C100	--	Non connection
19	1MSW	I	TRAY1 switch input signal	41	RMUP	O	R motor control signal
20	2MSW	I	TRAY2 switch input signal	42	RMDWN	O	R motor control signal
21	3MSW	I	TRAY3 switch input signal	43	NC	--	Non connection
22	3SSW	I	TRAY3 switch input signal	44	NC	--	Non connection

■ XR1099(IC903) : 7-channel graphic equalizer filter with A/D converter

1.Internal Block Diagram



2.Terminal Layout



3.Terminal Description

Pin No	Symbol	I/O	Function	Pin No	Symbol	I/O	Function
1	CSB	I	Chip select	9	TEST	--	TEST Terminal
2	STB	I	Strobe signal	10	VSS	--	- 5V
3	SPIDTO	I	Data input	11	RIN	I	Connected to GND
4	SPIDTI	O	Data output	12	LIN	I	Sound signal input
5		--	Non connection	13	GND	--	GND
6		I	Connected to GND	14		I	Connected to GND
7	L A/D	I	Connected to GND	15	CLK	I	A resister is connected
8	R A/D	I	Connected to GND	16	VCC	--	+ 5V

■ HA12136A(IC231) : NR amplifier



■ BA6897FP(IC602) : 4channel driver



T.S.D : sermal shat down
D.BUF : Drive buffer

■ GP1U271X (IC904) : Receiver for remote controller



Internal Connection of the Display

■ QLF0012-001(DI901)

1. Terminal Layout



2. Segment connection

	1G	2G	3G	4G	5G	6G	7G	8G
P1	9j	—	—	—	—	—	C	5−3
P2	10j	—	—	—	—	—	EON	4−3
P3	11j	4a	4a	4a	4a	6−k	RDS	3−3
P4	12j	4b	4b	4b	4b	6−j	—	2−3
P5	5j	4k	4k	4k	4k	6−e	7−2	1−3
P6	6j	4j	4j	4j	4j	6−f	—	5−2
P7	7j	4h	4h	4h	4h	6−g	7−6	4−2
P8	8j	4f	4f	4f	4f	6−h	7−8	3−2
P9	1j	4g	4g	4g	4g	6−i	7−7	2−2
P10	2j	4m	4m	4m	4m	6−a	7−10	1−2
P11	3j	4c	4c	4c	4c	6−b	7−9	5−1
P12	4j	4n	4n	4n	4n	6−c	7−1	4−1
P13	SOURCE	4p	4p	4p	4p	6−d	CD	3−1
P14	OFF	4r	4r	4r	4r	—	1	2−1
P15	ON	4e	4e	4e	4e	—	—	1−1
P16	CLOCK	4d	4d	4d	4d	—	ALL	S3
P17	16j	—	—	s	—	MHz	REPEAT	1−4
P18	15j	—	—	t	—	—	RANDOM	2−4
P19	14j	—	—	—	—	SET	PROGRAM	3−4
P20	13j	—	—	—	—	kHz	TA	4−4
P21	—	5d	5d	5d	5d	1a	—	5−4
P22	1−a	5e	5e	5e	5e	1b	NEWS	1−5
P23	1−b	5r	5r	5r	5r	1f	INFO	2−5
P24	1−c	5p	5p	5p	5p	1g	J	3−5
P25	2−a	5n	5n	5n	5n	1c	7−5	4−5
P26	2−b	5c	5c	5c	5c	1e	TUNED	5−5
P27	2−c	5m	5m	5m	5m	1d	STEREO	1−6
P28	3−a	5g	5g	5g	5g	CH	AUTO	2−6
P29	3−b	5f	5f	5f	5f	2a	7−3	3−6
P30	3−c	5h	5h	5h	5h	2b	7−11	4−6
P31	S1	5j	5j	5j	5j	2f	—	5−6
P32	—	5k	5k	5k	5k	2g	—	1−7
P33	1−d	5b	5b	5b	5b	2c	SOUND MODE	2−7
P34	REC	5a	5a	5a	5a	2e	7−4	3−7
P35	DAILY	—	—	—	—	2d	PRO LOGIC	4−7
P36	SLEEP	—	—	—	—	VOL	3CH LOGIC	5−7

3. Terminal connection

TERMINAL NO.	1	2	3	4	5	6	7	8	9	10	11								
ELECTRODE	F	F	NP	NP	1G	2G	3G	4G	5G	6G	7G								
TERMINAL NO.	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
ELECTRODE	8G	NX	P 1	P 2	P 3	P 4	P 5	P 6	P 7	P 8	P 9	P 10	P 11	P 12	P 13	P 14	P 15	P 16	P 17	P 18
TERMINAL NO.	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51
ELECTRODE	P 19	P 20	NX	NX	NX	P 36	P 35	P 34	P 33	P 32	P 31	P 30	P 29	P 28	P 27	P 26	P 25	P 24	P 23	P 22
TERMINAL NO.										52	53	54	55	56	57	58	59	60	61	62
ELECTRODE										P 21	NX	NX	NX	NX	NX	NX	NP	NP	F	F

Notes F: Filament NP: No Pin
G: Grid NX: No Extend Pin
P: Anode

Main parts Layout






Power amp P.C.B
Regulater P.C.B
Speaker out P.C.B
Source selector &
SEA P.C.B
Power Transe
Power supply P.C.B
Cassette deck
control P.C.B
Tuner P.C.B
Capstan motor
control P.C.B


Front Panel Ass'y
Front P.C.B
Cassette deck
control P.C.B
Capstan motor

Disassembly Procedures

(1) Removing the top cover

1. Remove 2 screws (A) fastening both sides of top cover, and 6 screws (A) fastening the rear side.
2. Remove the top cover.



Fig.1

(2) Removing the changer mechanism ass'y

1. Remove 2 screws(B)fastening up side (Fig. 2).
2. Remove 2 screws(C)fastening rear side.
3. Remove 2 screws(B) holding the PCB's.
4. Disconnect the CN811,CN614,CN613
5. Remove the changer mechanism ass'y(Fig.3).



Fig.2



Fig.3

(3) Removing the rear panel and Tuner PCB

1. Remove 9 screws(D)fastening rear side and remove the heat sink cover(Fig. 5).
2. Remove3 screws(D)holding the heat sink.
3. Remove the rear panel and Tuner PCB.



Fig.4



Fig.5

(4) Removing the Front panel ass'y

1.Remove the CDchanger mechanism.
2.Disconnect the CN411,CN412 and CN915,CN322.
3.Remove 2 screws(D)hololding the Front panel ass'y.
4.Remove the 2 hooks fastening both sides of Front panel ass'y.



Fig.6

(5) Removing the Cassette deck control PCB.

1.Remove the Front panel Ass'y
2.Disconnect the CN331,CN332.
3.Remove 2 screws(D)holding the Cassette deck control PCB.



Fig.7

(6) Removing the Cassette deck mech. ass'y

1.Remove the Front panel Ass'y.
2.Remove the Cassette deck control PCB.
3.Remove 4 screws(E) and 4 screws(F) holding the Cassette mecanism ass'y.



Fig.8

(7) Removing the Amp /Speaker out/Source select PCB

1.Remove the CD changer mech. and rear panel.
2.Disconnect the CN411,CN412,CN701,and Take the Source select PCB on the Power supply PCB.
3.Disconnect the CN915,and Take the Power amp and



Fig.9

(8) Removing the Power supply PCB

1.Remove the CD changer mech. and rear panel, and take the Source select PCB,Amp PCB and Speaker out PCB.
2.Disconnect the CN009,CN111.
3.Remove the 3 screws(D) holding the Power supply PCB.
4.Remove the Power supply PCB.

(9) Removing the Power Trans.

1.Remove the CD chenger mech.
2.Disconnect the CN009,CN111.
3.Remove the 4 screws(G)holding the Power Trans.
4.Remove the Power Trans..



Fig.10

(10) Removing the Front PCB

1.Remove the Front panel Assy.
2.Remove the deck control PCB.
3.Remove the 4 screws(H)holding the Bracket.
4.Remove the 9 screws(H)holding the Front PCB.
5.Remove the 5 screws(H)holding the deck sw and main volume PCB.



Fig.11



Fig.12

(11) Removing the Power IC

1.Remove the Amp PCB and Regulator PCB with the heatsink.
2.Remove 3 screws(G)holding the Amp PCB and Remove it.
3.Unsolder the Power IC terminals.
4.Remove the Power IC.



Fig.14



Fig.13

(12) Removing the Capstan motor control PCB

1.Remove the cassette mechanism ass'y.
2.Remove the 2 screws (J)holding the capstanmotor control PCB.
3.Remove the capstan motor control PCB.



Fig.15

(13) Removing the Cassette door

1.Remove the cassette mechanism ass'y
2.Push the Cassette door holder both side.
3.Remove the cassette door.(See Fig.16)



Fig.16

(14) Fix the Cassette Holder spring

Fix holder spring before fix guide . and cassette mech.(See Fig.17)



Fig.17



Cassette Mech. Ass'y removal

(15) Head assembly removal
1. Remove the Cassette mech. ass'y .
2. Remove the flexible wire from the cassette deck and remove the 3 screws Ⓚ holding the head ass'y.



Fig.18 Cassette mechanism top view

(16) Head assembly
1. The direction of the head is changed with the direction lever .When servicing ,install the direction lever according to the direction of the head assembly .



Fig.19-A Head ass'y side view

(17) Pinch roller (FWD/REV) removal
1. Remove the cassette mech. assembly.
2. Remove the hook holding the pinch roller.
3. Remove the pinch roller ass'y.



Fig. 20 Cassette mechanism bottom view



Fig.19-B A distance of between head older and azimuth screw

(18) Capstan motor removal.

1. Remove the cassette mechanism.
2. Remove the cassette deck control PCB.
3. Remove the 6 screws Ⓛ holding the bracket.
4. Remove the hooks (■) of the bracket.
5. Put the cutting on the flywheel A together the bracket's pall as shown in fig. 22(Flywheel A) and check that the flywheel B is removed from the bracket's pall (fig. 22-Flywheel B).
6. Remove the capstan motor with the bracket.
7. Unsolder the broken flat wire of the capstan motor.
8. Remove the 2 screws fixing the motor and the bracket.

* To remove the bracket, it is easier to remove mech."B" first.
Vice versa, assembling mech."A" is easier for reassembly.



Fig. 21 Capstan motor pulley installation

(19) Flywheel removal

1. Remove the cassette mechanism assembly.
2. Remove the cassette amp PCB.
3. Remove the 6 screws Ⓛ and the bracket.
4. Remove the 4 hooks of the bracket.
5. Remove the bracket.
6. Remove the flywheels.

*The oil on the capstan must be wiped out after reassembling.



Fig. 22-A



Fig. 22-B

(20) How to install the belts

1. Install the flywheels and belts as shown in the figure below. (Fig. 23)
   When putting the belts, put the long belt first.
2. Install the main reels to put the belts on the flywheels.



Fig. 23-A Install the Bracket and flywheels



Fig. 23-C Install the cassette mech.



REEL BELTS → After hooking reel belts, no twist.





Fig. 23-B Install the Belts

(21) Switch PCB removal

1. Remove the flywheel.
2. Remove the 1 screw Ⓜ .
3. Unsolder the broken solenoid.
4. Release the 4 hooks holding the Switch PCB.
5. Remove it.



When attach the FM bracket, Install the reel belt on the stud (See fig. 23)

Fig. 24

(22) Control cam removal

1. Remove the FM bracket and flywheel.
2. Pull out the main pulley .
3. Remove the trigger arm.
   While opening the two tabs ⓐ under the trigger arm, pull out the trigger arm from the shaft.
4. Pull out the elevator ring.
5. Remove the FWD/REV arm assembly.
   a. Remove the FWD/REV arm spring.
   b. While opening the four FWD/REV arm retaining tabs ⓑ outwards, pull out the FWD/REV arm.
6. Pull out the control cam.
   While pulling the shaft stopper section of the control cam in the central direction, pull out the control cam.

When attaching the control cam

While pressing the FWD/REV arm in the direction of the sorrow, pull the head the front.



Fig. 25-c



Position of the hole of cam and top of the arm after fixing the FR arm ass`y.

Fig. 25-a



Fig. 25-b

After preforming the procedure shown above, the studs under the control cam move as shown.



Fig. 25-d

(23) How to assemble

1. Move the FWD/REV arm in the direction of the arrow.
2. In step 1, pull the head base forward.
3. In step 2, after inserting the cam into the shaft, move the head base and FWD/REV arm slightly until the cam is fully inserted and it clicks to inform when it has been locked.
4. Rotate the cam counterclockwise to check if the cam rotates smoothly and the spring clicks according to the forward/backward movement of the head base.
5. After checking the rotation of the cam, rotate the cam until the notch section comes to the right so that the FWD/REV arm assembly can be attached.
6. Attach the FWD/REV arm assembly while observing the positioning of:
   the hole and stud
   the cam hole and arm edge
   shown in the figure 25-a.
   After attachment, move the FWD/REV arm in the direction of the arrow to check if it moves back to the original position.
7. Attach the elevator ring.
8. Attach the trigger arm.
   After attachment, move the trigger arm in the direction of the arrow to check if it moves back to the original position.

Working confirmation:
If the control cam rotates counterclockwise, the assembly was successful: if it does not rotates. It must be reassembled.



Fit the control cam its notch located as shown. (Engage with the gear of the control cam while moving the FWD/REV arm and head base slightly.)

Fig. 26-a



Attach the FWD/REV arm with the control cam rotated up to the position shown.

Fig. 26-b

CD Changer mech. Ass'y removal

(24) CD Tray assembly removal

1. Disassemble the changer mech..
2. Remove the screw Ⓒ holding the stopper bracket.(See Fig.27) ---- (U.S.A only)
3. Remove the rod from both ends' hooks which are secured on T.Bracket ⓐ and clamper baseⓑ. [See Fig. 27)
4. Remove 3 screwsⓁ securing T.Bracket.(See Fig. 29.)
5. Remove a screw Ⓝsecuring center of the clamper ass'y. (See Fig. 28)
6. Remove the clamper ass'y from ★ screw fixing side.
7. Remove a screw Ⓛwhich secures the return spring and lock levers from the chassis ass'y.(See Fig. 30.)
8. Remove 2 pallsⓓ which slightly secure the return spring to remove it.
9. Remove 3 lock levers.
10. Check that the lifter unit stopper is inserted into hole ⓔ located on CD tray ass'y. (See Fig. 31.)
11. Check that the driver unit elevator is seen from a hole (marked ⑤) on left side of the CD changer mech..(See Fig. 32 and 33.)
    [NOTE] Set the elevator in correct position (Fig. 33) by rotating the pulley gear with finger if it is not positioned correctly (Fig. 34.).
12. Rotate the motor pulley clockwise with finger until the lifter unit's stopper is lowered from ⓔhole located on the CD tray ass'y. (See Fig. 34.)
13. And, pull all 3 CD tray assemblies forward until they stop. (See Fig. 32.)
14. Press 2 pawls (f, f') located rear side of the CD tray ass'y according to an arrowⓗ to remove the CD tray ass'y. (See Fig. 35.)
    At first, removing the lowest tray is easier.



Fig. 27



Fig.28



Fig.29



Fig.30



Fig. 31



Fig. 32



Fig. 33



Fig. 34



Fig. 35

(25) CD mechanism removal

1. Remove the CD tray ass,y .
2. Rotate the Cam R1, R2 ass'y counterclockwise so that CD mech. ass'y's shaft ⓗ is positioned as shown in Fig. 36.
3. Remove 4 screws Ⓙ securing CD mech. ass'y. (See Fig. 36.)

*How to replace pick-up unit

1. If CD mech. is removed without disassembling CD mech. ass'y, rotate the Cam R1, R2 ass'y clockwise to set the CD mech. ass'y's shaft(L) as shown in Fig. 37.
2. Lift the CD mech. ass'y toward the direction ⓘ to remove it from the lifter unit. (See Fig. 38.)



Fig. 36



Fig. 37



Fig. 38

(26) Actuator motor board removal

1. Unsolder 4 soldered point ⓘ for both motors. (See Fig. 39.)
2. Remove a screw Ⓒ securing the CD servo board. (See Fig. 39.)
3. Press the hook and release it to remove the CD servo board.
4. Remove 2 screws Ⓙsecuring the actuator motor board. (See Fig. 39.)
5. Remove 2 screws Ⓙsecuring the tray select switch board. (See Fig. 40.)



Fig. 39



Fig. 40

(27) Cam unit removal

1. Disassemble CD mech. ass'y.
2. Rotate the Cam gear L so that the drive unit's pole ⓚ is positioned as shown in Fig. 41.
3. Remove the drive unit and cylinder gear. (See Fig.42.)
4. Rotate the Cam gear L so that the select gear's Ⓘ is positioned as shown in Fig.43.
5. Remove 4 screws Ⓘ securing the cam unit which includes the cam gear L and Cam R1, R2 ass'y. (See Fig 43.)



Fig. 41



Fig. 42



Fig. 43

(28) Removal for actuator motor and belt

1. Remove 2 screws ⓟ securing the gear bracket. (See Fig. 44.)
2. Press the pawl Ⓜ securing the gear bracket to the arrow in the figure to remove the gear bracket. (See Fig. 44.)
3. Remove the gear bracket from the chassis ass'y's ⓝ securing top of the gear bracket. (See Fig. 45.)
4. Remove each belts from the both actuator motor pulleys and the pulley gears. (See Fig.44.)
5. Reverse the chassis ass'y and widen 4 poles ⓞ which secure both actuator motors to its arrows to remove the actuator motors. (See Fig.46 .)

[NOTE] The pulley gears and other gears which consist the gear unit may drop separately if the chassis ass'y is reversed without gear bracket and belt. See Fig. 47 to assemble them again.



Fig. 44



Fig. 45



Fig. 46



Fig. 47

(29) Removal of cam R1, R2 ass'y and cam gear L

1. Remove the slit washer securing Cam R1, R2 ass'y. (See Fig. 48.)
2. Remove 2 poles Ⓟ securing Cam R1 to remove Cam R2 from Cam R1.
3. Remove the slit washer securing Cam gear L.
4. Remove Cam gear L from the C.G. base ass'y.



Fig. 48

(30) Removal of C.G. base ass'y

Remove 3 screws Ⓝ securing the C.G. base ass'y. (See Fig. 48 and 49.)

[NOTE] Set the drive unit's pawl Ⓡ so that it is positioned as shown in Fig. 49.
Confirm that the cam gear L engages with the gear unit by rotating the cam gear L.



Fig. 49

(31) Removing the Pickup
1. Remove the CD mech. assembly.
2. Release the shaft to remove the pickup.



Fig. 50

(32) Spindle motor installation
1. Tighten the 2 screws to the same torque.
2. Fasten the spindle and feed motor P.C. board with the screw and solder.
3. Install the turntable.When installing, press straight down at the center of the turntable until the distance from the surface of the mech. base to the turntable is exactly 19.4±0.1mm.



Fig. 51

(33) Removing the Spindle motor
1. Remove the CD mech. assembly.
2. Remove the turntable, and remove the 2 screws Ⓧ retaining the spindle motor.
3. Remove the screw retaining the spindle and feed motor circuit board and unsolder it.



Fig. 52

(34) After inserting the turntable, bond the motor shaft and turntable together (at the section marked by an arrow in fig 53 on the left below).



Fig. 53

(35) Use "LOCKTITE" #460 bonding agent, and apply as little as possible.

Take care not to allow any excess bonding agent to get onto the turntable.

Be extremely careful not to allow bonding agent to adhere to the motor bearing (the section marked by an allow in fig. 53 on the right).

Connected an extension cord

1.Remove the CD changer mechanism ass'y.
2.Disconnect the 7pin wire from the CN613(Source selector & SEA P.C.B)and disconnect the 7pin wire.
3.Connected the extension cord CN603 to CN613.



Changer mechanism Ass'y

Adjustment procedures

■ Tuner section



Fig.1



ENC-136-2
(Deck control PCB)

Clock Adjustment

1. After connecting B863 and B864 with some wire as shown in the figure below, connect the AC power cord into an AC outlet.
2. Confirm that the display is off and remove the wire.
3. Connect a frequency counter to TP303 B262 and B808.
4. Confirm the frequency 50000±0.29Hz.

(1) Tuning voltage

Confirm the voltages at TP101 is within the standard values shown in the table below. If the voltages are not satisfied, replace T111 for MW 5or FE101 for FM.

FM Tuning voltage (Unit : V)

Area	Frequency	
	87.5MHz	108MHz
USA,Canada	1.6±1.0 (V)	8.0±2.0 (V)

AM Tuning voltage (Unit : V)

Area	Frequency (MW)						
	522KHz	530KHz	531KHz	1600KHz	1602KHz	1629KHz	1710KHz
USA,Canada	—	>0.8	—	—	<7.9	—	<8.8

(2) FM center meter

Receive a broadcast which understanding the frequency by using the function of 'MANUAL SEARCH'. Adjust T141 (detector coil) so that the voltage at TP102 becomes 0±1.5mV.

■ Deck Adjiust point



Fig.1





Speed Control PCB Fig.2

Deck section

1. Measuring instruments

Audio frequency signal generator (0dbs output at the 600 ohm output terminal from 50Hz to 20KHz)
Electronic voltmeter
Frequency counter
Wow & Flutter meter
Distortion Meter with band pass filter
Attenuator (600 ohm impedance)
A resistor with 600Ω

Tape No.	Frequency	Level (Wow & Flutter)	Purpose
VTT-703L	10kHz	– 10dBs	Head azimuth , Frequency Response
VTT-712	3000Hz	0dBs 0.025%WRMS	Tape Speed , Wow & Flutter
VTT-724	1kHz	– 4dBs	Standard Level
TMT-6447	–	–	Blank Skip
TMT-6247 , TMT-6237	–	–	Music Scan
TMT-7088S	–	–	Recording standard Normal : UR
AC-712	–	–	Recording standard METAL :MA
AC-513	–	–	Recording standard CrO_2 : SA
TW-2111, TW-2121	–	–	Forward / reverse play torque measuring
TW-2231	–	–	Feed forward / rewind torque measuring
C-120 Tape	–	–	Confirming the tape running

2.Adjustment and repairing the mechanism

Item	Adjustment method	Standard value	Remarks
Head azimuth	Deck A 1. Connect an electronic voltmeter to the NR TP901(figure 2) to playback VTT-703L. 2. Adjust screw Ⓐ so that the indication of the voltmeter becomes maximum when PLAY (▶) is pressed. 3. Adjust screw Ⓑ so that the indication of the voltmeter becomes maximum when PLAY (◀) is pressed. Deck B 4. Adjust screw Ⓒ so that the indication of the voltmeter becomes maximum when PLAY (▶) is pressed. 5. Adjust screw Ⓓ so that the indication of the voltmeter becomes maximum when PLAY (◀) is pressed. 6. After making the adjustment,apply screw lock to prevent screws Ⓐ, Ⓑ, Ⓒ and Ⓓ coming loose.	Maximum	1. **Refer to figure 3.** 2. When the specified characteristic cannot be obtained because of head wear, excessive magnetization, etc., replace the head assembly and adjust the head azimuth. Also, perform the electric adjustment. 3. When there is the difference of more than 3 ~ 4 dB between left and right output levels, replace the head assembly to avoid complaints.
Playback torque	1. Measure the torque in the playback mode by the torque meter.	26 ~ 72 g-cm	When the standard torque cannot be obtained, replace the FR arm assembly or motor.
Fast forward torque	1. Measure the torque in the fast forward mode by the torque meter.	75 ~ 175 g-cm	When the standard torque cannot be obtained,replace the FR arm assembly or motor.
Rewind torque	1. Measure the torque in the rewind mode by the torque meter.	75~ 175 g-cm	When the standard torque cannot be obtained, replace the FR arm assembly or motor.
Wow & flutter	1. Connect the wow & flutter meter to the DOLBY TP(figure 2) and play back VTT-712. 2. Its reading should be within 0.25% (WTD).	Less than 0.25%	As a complaint may occur if the wow & flutter fluctuates by 0.1% even though it is allowed in the standard, repairing is required.



Deck A



Deck B

Fig.3

3. Electrical Adjustments (Make the following adjustments after adjusting the head azimuth.)

In principle, the adjustments should be made in the following sequence.
Set the NR switch to OFF and the BEAT CUT switch to "1".
Adjustments marked with an asterisk (*) should always be made after the head is replaced

0dBs = 0.775V

Item	Adjustment Method	Adjustment Location	Standard Value	Remarks
Tape Speed	1. Connect a frequency counter to the NR TP 901 (figure 2) and play back VTT-712. 2. Adjust the semi-fixed resistor VR901 on ENH-292 - 1 (figure 2).	VR233	3,000 Hz ± 10Hz	Connect a wow & flutter meter with a built-in frequency counter to the speaker terminals.
* Standard level (Playback Level)	1. Connect an electronic voltmeter to the NR TP901(figure 2). Play back VTT-724 (1 kHz : – 4dBs) to adjust the semi - fixed resistors.	**Deck A** L: VR301 R: VR302 **Deck B** L: VR303 R: VR304	488mV (– 4dBs)	1) The playback level varies when the head is replaced so should be adjusted. Use an electronic voltmeter with an impedance of 100 kΩ or more.
* Playback Frequency Response	1. Connect an electronic voltmeter to the NR TP 901(figure 2). 2. Play VTT-703L (10kHz : – 10dBs) and adjust semi-fixed resistors to obtain the standard values.	**Deck A** L: VR305 R: VR306 **Deck B** L: VR307 R: VR308	245mV (– 10dBs)	—
* Recording Bias Frequency	1. Connect a frequency counter to the BIAS TP(figure 2), and perform a recording to adjust bias frequency.	L301	105 kHz ± 5 kHz	
* Record / Play Frequency Response (Bias current)	1. Supply 1kHz and 12.5kHz with 30mV signals to AUX terminals respectively to record them. 2. Connect an electronic voltmeter to the NR TP901 (figure 2) to confirm the recorded values. 3. If the values are not satisfied, adjust the semi-fixed resistors and record the signal again to confirm the recorded values.	L : VR309 R : VR310	0 ± 2 dB with 1 kHz as the standard.	**Refer to figure 4 below.** 1) The recording and playback frequency response of a cassette deck are adjusted by adjusting the bias. 2) Perform the adjustment with normal tape and confirm that the values are within the range for metal tape.



Fig.4

Flow of Functional Operation Until TOC is Read


Check Points
Power ON
Play key
Slider turns REST SW ON.
Confirm that the voltage at the pin 5 of CN604 (ENN-488-1) is "L"→"H"→"L".
Automatic tuning of TE offset
Laser ON
Confirm that the voltage at the pin40 of IC603 is +5V.
Detection of a disc
Automatic tuning of Focus offset
Automatic measurement of Focus S-curve amplitude
Confirm that the Focus error S-curve signal at the pin27 of IC601 is approx. 2Vp-p.
Disc is rotated
Confirm that the signal from pin24 of IC603 is 0V as a accelerated pulse during approx. 400ms.
Focus servo ON (Tracking servo ON)
Automatic measurement of Tracking error amplitude
Confirm the waveform of the Tracking error signal (see fig-1).
Automatic tuning of Tracking error balance
Automatic tuning of Focus error balance
Automatic tuning of Focus gain
Automatic tuning of Tracking gain
TOC Reading
Confirm the eye-pattern at TP602 (ENC-488-1).
Play a Disc
■ Tracking error waveform at TOC reading
pin25 of IC601 (TE)
Approx. 3sec
Approx. 1.8V
VREF
tracking servo off status
tracking servo onstatus
Disc to be braked to stop
Disc starts to rotate
TOC reading finishes
Automatic measurement of TE amplitude and automatic tuning of TE balance
500mv/div
2ms/div
Fig-1

Maintenance of Laser Pickup

(1) Cleaning the pick up lens

Befor you replace the pick up, please try to clean the lens with a alcohol soaked cotton swab.

(2) Life of the laser diode (Fig.1)

When the life of the laser diode has expired, the following symptoms will appear.

(1) The level of RF output (EFM output: ampli tude of eye pattern) will be low.



(Fig.1)

(3) Semi-fixed resistor on the APC PC board

The semi-fixed resistor on the APC printed circuit board which is attached to the pickup is used to adjust the laser power. Since this adjustment should be performed to match the characteristics of the whole optical block, do not touch the semi-fixed resistor.

If the laser power is lower than the specified value, the laser diode is almost worn out, and the laser pickup should be replaced.

If the semi-fixed resistor is adjusted while the pickup is functioning normally, the laser pickup may be damaged due to excessive current.

Replacement of Laser Pickup


Turn off the power switch and, disconnect the power cord from the ac outlet.
Replace the pickup with a normal one. (Refer to "Pickup Removal" on the previous page)
Plug the power cord in, and turn the power on. At this time, check that the laser emits for about 3seconds and the objective lens moves up and down.
Note: Do not observe the laser beam directly.
Play a disc.
Check the eye-pattern at TP2.
Finish.

Self-diagnosis for pickup

From DCS output, this model reads automatically adjusted data for CD so that the pickup can be judged defective or not. Following shows its details.

1. Necessary items

① DCS → 232C Converting board (No.EBSJ1022)
② 232C cord (straight)
③ Floppy disc for self-diagnosis (No.EBSJ1022)
④ DCS cord
⑤ Power supply DC 6.3V (AA-SV11U)
⑥ Cord of Power supply E407992-001
⑦ CD (without scratches or damage)

2. Connection



3. Procedure to use CD self-diagnosis jig by IBM PC

Two com pins are frequently adopted in recent IBM AT and its substitute RS232C port.
This jig can also use both COM1 and COM2.
DEFAULT is COM1. Indicate "2" to the option only for COM2.

When COM1 is used,···

I AUTO 01

When COM2 is used,···

I AUTO 02

[NOTE] Press ESC key to stop processing during the operation.
Contents of the attached floppy IBM self-diagnosis program VER.1.00 Execution file.
(Mistake the conection/Mistake the polarity)

4. Judgment

To judge whether pickup is defective or not, firstly process of automatic adjustment is checked by automatic adjustment flag. And, the value(automatic adjustment value for focus gain) displayed on the screen is used for its final judgment.

It is supposed that the pickup is defective or the signal path is faulty if the Flag1 or Flag0 indicates not "F" but a figure.
(See the following example.)

Flag1	Flag0	Details	Supposed cause
0	0	Automatic adjustment for tracking offset is failed.	The automatic adjustment is not completed. (Trouble in circuit.)
0	1	Automatic adjustment for focus offset is failed. (Disc does not rotate.)	The lens does not move. (Power supply is not turned on. Wire is cut.)
0	3	Automatic rough adjustment for focus gain is failed.	
0	7	Automatic rough adjustment for tracking gain is failed. (The focus and tracking gain are not locked though the disc rotates.)	Laser deterioration (low RF signal output). Offset beam.
0	F	Disc rotates, focus and tracking gain are locked and automatic rough adjustment for tracking gain is also completed though automatic adjustment for tracking balance is failed.	Laser deterioration (low RF signal output). Offset beam.
1	F	Automatic adjustment for focus balance is failed. (TOC is not read tough the disc rotates.)	RF signal output is low. Tracking loop is not turned on. RF jitter is too much.
3	F	Automatic rough adjustment for focus gain is failed.	
7	F	Automatic rough adjustment for tracking gain is failed.	
F	F	All automatic adjustments are completed.	

The pickup is judged defective though the Flag0 and Flag1 indicate "F" and those adjustments are completed if the adjustment value exceeds 19dB.

Block Diagrams



— MEMO —

P1-65-a P1-65-b


Schematic Diagrams
■ Front Section
Notes:
1. indicates main signal path.
2. indicates rec signal path.
3. When replacing the parts in the dotted line are (Pb-free) and those marked with ⚠ be sure to use the designated parts to ensure safety.
4. This is the standard circuit diagram. The design and contents are subject to change without notice.
CA-D661T
1-65

P1-65-c P1-65-d



* MARK LIST

	D601T				D631T	D651TR	D661T
	U, UT, UP, VS, UB	A	EF, EN, G, BS	VX	EF, EN, G	EF, EN, G	J, C
B401	USED	USED	NONE	NONE	NONE	NONE	NONE
B411, 431	NONE	NONE	NONE	NONE	NONE	NONE	USED
B426	USED	USED	USED	USED	USED	NONE	USED
B428	NONE	USED	USED	USED	NONE	USED	NONE
B429	NONE	USED	USED	USED	USED	USED	USED
C921~923	USED	NONE	NONE	NONE	NONE	NONE	USED
CN402	NONE	NONE	NONE	NONE	NONE	USED	NONE
D913~916	NONE	NONE	NONE	NONE	NONE	USED	NONE
D931	USED	NONE	NONE	USED	NONE	NONE	NONE
D932	NONE	NONE	NONE	USED	NONE	NONE	USED
D933	USED	USED	NONE	NONE	NONE	NONE	USED
D935	USED	NONE	NONE	NONE	NONE	NONE	USED
D936	NONE	NONE	NONE	NONE	NONE	USED	NONE
D941	USED	NONE	NONE	NONE	NONE	NONE	USED
IC903	USED	NONE	NONE	NONE	NONE	NONE	USED
R915	USED	NONE	NONE	NONE	NONE	NONE	USED
R953~956	NONE	NONE	NONE	NONE	NONE	USED	NONE
R980~986	USED	NONE	NONE	NONE	NONE	NONE	USED
R991	NONE	NONE	NONE	NONE	NONE	USED	NONE
R993	USED	NONE	NONE	NONE	USED	NONE	NONE
R994	USED	NONE	NONE	NONE	NONE	NONE	NONE
R940~943	NONE	NONE	NONE	NONE	NONE	USED	NONE
S927~930	NONE	NONE	NONE	NONE	NONE	USED	NONE
TW222	NONE	USED	USED	USED	NONE	USED	USED

Notes:

1. ➡ indic
2. ⇨ indic
3. When replac
   are ( )
   to use the
4. This is the
   The design
   change with

Schematic Diagrams

■ Front Section





* MARK LIST

	D601T				D631T	D651TR	D661T
	U, UT, UP, VS, UB	A	EF, EN, G, BS	VX	EF, EN, G	EF, EN, G	J, C
B401	USED	USED	NONE	NONE	NONE	NONE	NONE
B411, 431	NONE	NONE	NONE	NONE	NONE	NONE	USED
B426	USED	USED	USED	USED	USED	NONE	USED
B428	NONE	USED	USED	USED	NONE	USED	NONE
B429	NONE	USED	USED	USED	USED	USED	USED
C921~923	USED	NONE	NONE	NONE	NONE	NONE	USED
CN402	NONE	NONE	NONE	NONE	NONE	USED	NONE
D913~916	NONE	NONE	NONE	NONE	NONE	USED	NONE
D931	USED	NONE	NONE	USED	NONE	NONE	NONE
D932	NONE	NONE	NONE	USED	NONE	NONE	USED
D933	USED	USED	NONE	NONE	NONE	NONE	USED
D935	USED	NONE	NONE	NONE	NONE	NONE	USED
D936	NONE	NONE	NONE	NONE	NONE	USED	NONE
D941	USED	NONE	NONE	NONE	NONE	NONE	USED
IC903	USED	NONE	NONE	NONE	NONE	NONE	USED
R915	USED	NONE	NONE	NONE	NONE	NONE	USED
R953~956	NONE	NONE	NONE	NONE	NONE	USED	NONE
R980~986	USED	NONE	NONE	NONE	NONE	NONE	USED
R991	NONE	NONE	NONE	NONE	NONE	USED	NONE
R993	USED	NONE	NONE	NONE	USED	NONE	NONE
R994	USED	NONE	NONE	NONE	NONE	NONE	NONE
R940~943	NONE	NONE	NONE	NONE	NONE	USED	NONE
S927~930	NONE	NONE	NONE	NONE	NONE	USED	NONE
TW222	NONE	USED	USED	USED	NONE	USED	USED

Notes:

1. ➡ indic
2. ⇨ indic
3. When replac
   are ( )
   to use the
4. This is the
   The design
   change with


FROM CN322 OF ENC-136-2 (SHEET4/11)
CN403
C-REQ
C-CLK
C-DATA
DCS
ECHO1
ECHO2
CDRESET
REC1
DECKA1
DECKB1
DISC1
DISC2
DISC3
CS1
TUTEST
FOUT
RA901 2.2KX6
D626 1SS133
PRT
R905 10K
R904 2.2K
X901 4.19MHz
R901 1M
C901 100/10
D901 1SS119
C903 0.047F
C902 1.5
R903 22
R902 10K
IC901 MD404719A71FS
AMP CONTROL
RESET
OSC1
OSC2
TEST
VCC
RDS
PROLOGIC
KARAOKE
ECHO
S2BASS
HPIN
CDRESET
TUNR
TURESET
DCSIN
DCSOUT
DCS
ACO
AD GND
GND
CS
IN6
TNR
IN5
IN4
IN3
IN2
IN1
ECHO1
ECHO2
SMUTE
JOG1
JOG2
T-CLK
AD VCC
DSPRST
T-REQ
T-DATA
RMTN
SDA1
SCK
R907 220
R906 220
STANDBY1
BASS1
APO1
VCR1
TAPE1
TU1
CD1
CONT.A
RELAY1
SURR
J.L.1
J.D.1
J.R.1
J.U.1
R900
R987
RMTN
+5V
D.GND
DATA
VCC
GND
REMOCON DETECTOR
C905 100 /6.3
C904 0.022
IC904 GP1U271X
DISC1
DISC2
DISC3
R957 180
R958 180
R959 180
D917 SLR-342MCA47
D918 SLR-342MCA47
D919 SLR-342MCA47
J.U.1
J.R.1
J.D.1
J.L.1
*R953 220
*R954 180
*R955 180
*R956 180
*D913 SLR-342MCA47
*D914 SLR-342MCA47
*D915 SLR-342MCA47
*D916 SLR-342MCA47
APO1
CD1
TU1
TAPE1
VCR1
Q901 KRC102M
Q902 KRC102M
Q903 KRC102M
Q904 KRC102M
D904 SLR-342DCA47
R944 180
R945 180
R946 180
R947 180
R948 180
R949 180
R950 180
R951 180
R952 180
D905 SLR-342MCA47
D906 SLR-342MCA47
D907 SLR-342MCA47
D908 SLR-342MCA47
D909 SLR-342MCA47
D910 SLR-342MCA47
D911 SLR-342MCA47
D912 SLR-342MCA47
IN2
IN3
IN4
R918 430 JOG V S901
R919 430 JOG ^ S902
R920 560 CD OPEN1 S903
R921 750 CD OPENZ S904
R922 1.3K CD OPEN3 S905
R923 2.2K DISC1 S906
R924 5.1K DISC2 S907
DISC3 S908
R925 430 JOG < S909
R926 430 JOG > S910
R927 560 SET S911
R928 750 CD ▷/II S912
R929 1.3K CD □ S913
R930 2.2K PLAY MODE S914
R931 5.1K REPEAT S915
EDIT S916
R932 430 VCR S917
R933 430 TAPE S918
R934 560 TUNER S919
R935 750 CD S920
R936 1.3K TIMER S921
R937 2.2K SEA CONT S922
R938 5.1K SOUND MODE S923
CANCEL S924
R939 430 DEMO S925
*R940 430 AUTO P.OFF S926
*R941 560 PTY SEARCH *S927
*R942 750 TA/NEWS /INFO *S928
*R943 1.3K RDS EON *S929
DISPLAY MODE *S930

P1-66-a P1-66-b



P1-66-c P1-66-d


ENH-302-41
CN002
CN003
CN004
CN005
CN006
CN007
CN012
CN013
CN014
CN015
CN016
CN017
CN018
CN019
CN020
CN021
CN022
CN023
CN024
CN025
CN026
CN027
CN028
CN029
CN030
CN031
CN032
CN033
CN034
CN035
CN036
CN037
CN038
CN039
CN040
CN041
CN042
CN043
CN044
CN045
CN046
CN047
CN048
CN049
CN050
CN051
CN052
CN053
CN054
CN055
CN056
CN057
CN058
CN059
CN060
CN061
CN062
CN063
CN064
CN065
CN066
CN067
CN068
CN069
CN070
CN071
CN072
CN073
CN074
CN075
CN076
CN077
CN078
CN079
CN080
CN081
CN082
CN083
CN084
CN085
CN086
CN087
CN088
CN089
CN090
CN091
CN092
CN093
CN094
CN095
CN096
CN097
CN098
CN099
CN100
CN101
CN102
CN103
CN104
CN105
CN106
CN107
CN108
CN109
CN110
CN111
CN112
CN113
CN114
CN115
CN116
CN117
CN118
CN119
CN120
CN121
CN122
CN123
CN124
CN125
CN126
CN127
CN128
CN129
CN130
CN131
CN132
CN133
CN134
CN135
CN136
CN137
CN138
CN139
CN140
CN141
CN142
CN143
CN144
CN145
CN146
CN147
CN148
CN149
CN150
CN151
CN152
CN153
CN154
CN155
CN156
CN157
CN158
CN159
CN160
CN161
CN162
CN163
CN164
CN165
CN166
CN167
CN168
CN169
CN170
CN171
CN172
CN173
CN174
CN175
CN176
CN177
CN178
CN179
CN180
CN181
CN182
CN183
CN184
CN185
CN186
CN187
CN188
CN189
CN190
CN191
CN192
CN193
CN194
CN195
CN196
CN197
CN198
CN199
CN200
CN201
CN202
CN203
CN204
CN205
CN206
CN207
CN208
CN209
CN210
CN211
CN212
CN213
CN214
CN215
CN216
CN217
CN218
CN219
CN220
CN221
CN222
CN223
CN224
CN225
CN226
CN227
CN228
CN229
CN230
CN231
CN232
CN233
CN234
CN235
CN236
CN237
CN238
CN239
CN240
CN241
CN242
CN243
CN244
CN245
CN246
CN247
CN248
CN249
CN250
CN251
CN252
CN253
CN254
CN255
CN256
CN257
CN258
CN259
CN260
CN261
CN262
CN263
CN264
CN265
CN266
CN267
CN268
CN269
CN270
CN271
CN272
CN273
CN274
CN275
CN276
CN277
CN278
CN279
CN280
CN281
CN282
CN283
CN284
CN285
CN286
CN287
CN288
CN289
CN290
CN291
CN292
CN293
CN294
CN295
CN296
CN297
CN298
CN299
CN300
CN301
CN302
CN303
CN304
CN305
CN306
CN307
CN308
CN309
CN310
CN311
CN312
CN313
CN314
CN315
CN316
CN317
CN318
CN319
CN320
CN321
CN322
CN323
CN324
CN325
CN326
CN327
CN328
CN329
CN330
CN331
CN332
CN333
CN334
CN335
CN336
CN337
CN338
CN339
CN340
CN341
CN342
CN343
CN344
CN345
CN346
CN347
CN348
CN349
CN350
CN351
CN352
CN353
CN354
CN355
CN356
CN357
CN358
CN359
CN360
CN361
CN362
CN363
CN364
CN365
CN366
CN367
CN368
CN369
CN370
CN371
CN372
CN373
CN374
CN375
CN376
CN377
CN378
CN379
CN380
CN381
CN382
CN383
CN384
CN385
CN386
CN387
CN388
CN389
CN390
CN391
CN392
CN393
CN394
CN395
CN396
CN397
CN398
CN399
CN400
CN401
CN402
CN403
CN404
CN405
CN406
CN407
CN408
CN409
CN410
CN411
CN412
CN413
CN414
CN415
CN416
CN417
CN418
CN419
CN420
CN421
CN422
CN423
CN424
CN425
CN426
CN427
CN428
CN429
CN430
CN431
CN432
CN433
CN434
CN435
CN436
CN437
CN438
CN439
CN440
CN441
CN442
CN443
CN444
CN445
CN446
CN447
CN448
CN449
CN450
CN451
CN452
CN453
CN454
CN455
CN456
CN457
CN458
CN459
CN460
CN461
CN462
CN463
CN464
CN465
CN466
CN467
CN468
CN469
CN470
CN471
CN472
CN473
CN474
CN475
CN476
CN477
CN478
CN479
CN480
CN481
CN482
CN483
CN484
CN485
CN486
CN487
CN488
CN489
CN490
CN491
CN492
CN493
CN494
CN495
CN496
CN497
CN498
CN499
CN500
CN501
CN502
CN503
CN504
CN505
CN506
CN507
CN508
CN509
CN510
CN511
CN512
CN513
CN514
CN515
CN516
CN517
CN518
CN519
CN520
CN521
CN522
CN523
CN524
CN525
CN526
CN527
CN528
CN529
CN530
CN531
CN532
CN533
CN534
CN535
CN536
CN537
CN538
CN539
CN540
CN541
CN542
CN543
CN544
CN545
CN546
CN547
CN548
CN549
CN550
CN551
CN552
CN553
CN554
CN555
CN556
CN557
CN558
CN559
CN560
CN561
CN562
CN563
CN564
CN565
CN566
CN567
CN568
CN569
CN570
CN571
CN572
CN573
CN574
CN575
CN576
CN577
CN578
CN579
CN580
CN581
CN582
CN583
CN584
CN585
CN586
CN587
CN588
CN589
CN590
CN591
CN592
CN593
CN594
CN595
CN596
CN597
CN598
CN599
CN600
CN601
CN602
CN603
CN604
CN605
CN606
CN607
CN608
CN609
CN610
CN611
CN612
CN613
CN614
CN615
CN616
CN617
CN618
CN619
CN620
CN621
CN622
CN623
CN624
CN625
CN626
CN627
CN628
CN629
CN630
CN631
CN632
CN633
CN634
CN635
CN636
CN637
CN638
CN639
CN640
CN641
CN642
CN643
CN644
CN645
CN646
CN647
CN648
CN649
CN650
CN651
CN652
CN653
CN654
CN655
CN656
CN657
CN658
CN659
CN660
CN661
CN662
CN663
CN664
CN665
CN666
CN667
CN668
CN669
CN670
CN671
CN672
CN673
CN674
CN675
CN676
CN677
CN678
CN679
CN680
CN681
CN682
CN683
CN684
CN685
CN686
CN687
CN688
CN689
CN690
CN691
CN692
CN693
CN694
CN695
CN696
CN697
CN698
CN699
CN700
CN701
CN702
CN703
CN704
CN705
CN706
CN707
CN708
CN709
CN710
CN711
CN712
CN713
CN714
CN715
CN716
CN717
CN718
CN719
CN720
CN721
CN722
CN723
CN724
CN725
CN726
CN727
CN728
CN729
CN730
CN731
CN732
CN733
CN734
CN735
CN736
CN737
CN738
CN739
CN740
CN741
CN742
CN743
CN744
CN745
CN746
CN747
CN748
CN749
CN750
CN751
CN752
CN753
CN754
CN755
CN756
CN757
CN758
CN759
CN760
CN761
CN762
CN763
CN764
CN765
CN766
CN767
CN768
CN769
CN770
CN771
CN772
CN773
CN774
CN775
CN776
CN777
CN778
CN779
CN780
CN781
CN782
CN783
CN784
CN785
CN786
CN787
CN788
CN789
CN790
CN791
CN792
CN793
CN794
CN795
CN796
CN797
CN798
CN799
CN800
CN801
CN802
CN803
CN804
CN805
CN806
CN807
CN808
CN809
CN810
CN811
CN812
CN813
CN814
CN815
CN816
CN817
CN818
CN819
CN820
CN821
CN822
CN823
CN824
CN825
CN826
CN827
CN828
CN829
CN830
CN831
CN832
CN833
CN834
CN835
CN836
CN837
CN838
CN839
CN840
CN841
CN842
CN843
CN844
CN845
CN846
CN847
CN848
CN849
CN850
CN851
CN852
CN853
CN854
CN855
CN856
CN857
CN858
CN859
CN860
CN861
CN862
CN863
CN864
CN865
CN866
CN867
CN868
CN869
CN870
CN871
CN872
CN873
CN874
CN875
CN876
CN877
CN878
CN879
CN880
CN881
CN882
CN883
CN884
CN885
CN886
CN887
CN888
CN889
CN890
CN891
CN892
CN893
CN894
CN895
CN896
CN897
CN898
CN899
CN900
CN901
CN902
CN903
CN904
CN905
CN906
CN907
CN908
CN909
CN910
CN911
CN912
CN913
CN914
CN915
CN916
CN917
CN918
CN919
CN920
CN921
CN922
CN923
CN924
CN925
CN926
CN927
CN928
CN929
CN930
CN931
CN932
CN933
CN934
CN935
CN936
CN937
CN938
CN939
CN940
CN941
CN942
CN943
CN944
CN945
CN946
CN947
CN948
CN949
CN950
CN951
CN952
CN953
CN954
CN955
CN956
CN957
CN958
CN959
CN960
CN961
CN962
CN963
CN964
CN965
CN966
CN967
CN968
CN969
CN970
CN971
CN972
CN973
CN974
CN975
CN976
CN977
CN978
CN979
CN980
CN981
CN982
CN983
CN984
CN985
CN986
CN987
CN988
CN989
CN990
CN991
CN992
CN993
CN994
CN995
CN996
CN997
CN998
CN999
CN1000

■ Amp/Power Supply Section



* MARK	D661T	
	J	C
C713, 714	NONE	0.1
C715, 716	NONE	0.1
C717, 718	0.047	NONE
J082	USED	USED
R006	3.3 UNF.C (1/6W)	3.3 UNF.C (1/6W)
R007	NONE	NONE
R047-049	USED	USED
R060	18 (1W)	18 (1W)
R061	18 (1W)	18 (1W)
R069	22 (1/2W)	22 (1/2W)
R070	33 (1/2W)	33 (1/2W)
R074	18 (1/2W)	18 (1/2W)
R075	22 (1/2W)	22 (1/2W)
R079	12 (2W)	12 (2W)
R083	15 (1W)	15 (1W)
R002	USED	NONE
TH002	NONE	USED


ENH-302-1
ENB-248-4
SEE POWER SUPPLY SECTION (SHEET1/12)
RELAY1
SURR
SUB WOOFER
CN015
CN095
CN111
CN013
PW101
EP001
D011-014:1SS424-20
D001-004:1N5404-20

10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20

* MARK

	D661T		D601T			D631T	D651TR
	J	C	U, UB, UD, UP, UT	A	EN, EF, G, VX, 6S	EN, EF, G	EN, EF, G
C713, 714	NONE	0.1	0.1	0.1	0.1	0.1	0.1
C715, 716	NONE	0.1	0.1	0.1	0.1	0.1	0.1
C717, 718	0.047	NONE	NONE	NONE	NONE	NONE	NONE
J082	USED	USED	NONE	NONE	NONE	NONE	NONE
R006	2.2 UNF.C. (1/4W)	2.2 UNF.C. (1/4W)	4.7 F.RES (1/4W)	4.7 F.RES (1/4W)	4.7 F.RES (1/4W)	4.7 F.RES (1/4W)	4.7 F.RES (1/4W)
R007	NONE	NONE	4.7 F.RES (1/4W)	4.7 F.RES (1/4W)	4.7 F.RES (1/4W)	4.7 F.RES (1/4W)	4.7 F.RES (1/4W)
R047-049	USED	USED	NONE	NONE	NONE	NONE	NONE
R060	18 (1W)	18 (1W)	SHORT	SHORT	SHORT	SHORT	SHORT
R061	18 (1W)	18 (1W)	NONE	NONE	NONE	NONE	NONE
R069	22 (1/2W)	22 (1/2W)	SHORT	SHORT	SHORT	SHORT	SHORT
R070	33 (1/2W)	33 (1/2W)	SHORT	SHORT	SHORT	SHORT	SHORT
R074	16 (1/2W)	16 (1/2W)	SHORT	SHORT	SHORT	SHORT	SHORT
R075	22 (1/2W)	22 (1/2W)	NONE	NONE	NONE	NONE	NONE
R079	12 (2W)	12 (2W)	SHORT	SHORT	SHORT	SHORT	SHORT
R083	15 (1W)	15 (1W)	SHORT	SHORT	SHORT	SHORT	SHORT
R002	USED	NONE	NONE	NONE	NONE	NONE	NONE
TH002	NONE	USED	USED	USED	USED	USED	USED





P1-67-a P1-67-b



P1-67-c P1-67-d


REC OUT
BEAT OUT
*S490
*R490 220
BCUT
RECR
RECL
VCRI
Q482 2SC4744S (VW)
Q483 KRC102M
Q481 2SC4744S (VW)
R492 2.2K
R486 10K
R485 10K
R491 2.2K
R483 220
R484 220
C482 220P
C481 220P
R414 1K
82K
AUXR
C431 2.2/50
SOURCE SELECT, INPUT BUFFER, SEA & E.VOL
VINL
COMR
VINR
C432 2.2/50
C426 0.018
C428 0.022
C422 0.1
C424 0.1
C421 0.1
C423 0.1
C427 0.022
C425 0.018
C429 0.0056
C430 0.0056
R420 2.7K
R418 5.6K
R417 5.6K
R419 2.7K
INL
INR
MINR
MOUTR
BINR
BOUTR
BINL
BOUTL
MOUTL
MINL
TREBLEL
TREBLER
D.GND
SCL
SDA
LOUT
ROUT
A.GND
VS
CREF
SCK
SDA1
IC401 TDA7439
C415 10/25
C407 10/25
C417 10/25
C411 10/25
C412 10/25
C418 10/25
C408 10/25
C416 10/25
C433 1/50
C434 1/50
C420 2.2/25
C419 10/25
COML
AUXL
CDL
FBL
TUL
TUR
FBR
CDR
AUXR
VOL
VOR
*R425 15K
*C438 10/25
*R424 15K
SPI AMP
*IC403 BA15218 (1/2)
*R427 15K
*C439 0.02
*R423 30K
*C437 10/25
*C436 10/25
*R426 30K
*C435 10/25
*R447 15K
*C454 10P
*C455 10/25
*R448 100K
*R428 100K
*C440 10/25
R421 100K
SPI
R422 100K
*R429 470
*C441 10/25
KARAOKE
CONT.A
VSS
VEE
INH
VDD
*IC404 TC40528P
*B404
*B403
KARAOKE ON/OFF SELECT
IC404 KARAOKE
L ON
H OFF
*D402 MTZ5.1JB
*C442 10/25
*R430 470
R432 100K
R431 100K
C443 10/25
*C444 10/25
R434 5.6K
*C452 10/25
*R444 20K
*R436 20K
*R435 20K
*C451 10/25
*R443 20K
R433 5.6K
IC405 BA15218 (1/2)
R440 4.3K
R438 4.7K
C446 100P
*R446 30K
C448 10/25
*C453 10/25
R437 4.7K
C445 100P
*R445 30K
C447 10/25
R441 100K
R442 100K
RECR
RECL
VINR
VINL
+9V
D.GND
A.GND
VOR
VOL
R454 100K
R453 100K
IC407 BA15218 (1/2)
VOL. AMP

■ Source Select Section




VOL AMP
IC407 BA15218 (1/2)
VOL
VOR
S.MUTE
Q401 2SD2144S (VW)
Q403 KRA102M
Q402 2SD2144S (VW)
C474 47/25
C475 10/25
C476 10/25
C473 47/25
C471 100P
C472 100P
C477 R465 4.7/50 1K
R453 100K
R454 100K
R455 10K
R456 10K
R457
R458
R459 100K
R460 100K
R461 220
R462 220
R463 10K
R464 10K
CN701
S.MUTE
FRONTL
A.GND
FRONTR
FROM FW401 OF ENH-302-2 (SHEET2/11)
CN016
B.GND
M.GND
+8V
+10V
+5.6V
D.GND
A.GND
+9V
-12V
+12V
FROM CN006 OF ENH-302-1 (SHEET2/11)
& ECHO MIX
IC914 BA7725S
IC915 BU9252S
X1101 400KHz
R1117 12K
R1118 10K
R1119 10K
R1121 4.7K
R1123 10K
R1124 10K
R1122 10K
R1111 22K
R1113 75K
R1112 27K
R1114 56K
R1115 5.6K
R1131 220
R1132 330
R1133 220
C1121 0.018
C1122 0.1M
C1123 0.01
C1129 0.1M
C1131 100/16
C1138 100/16
D1101 MTZS.1JB
Q1101 KRC104M
Q1102 KRC104M
ECHO1
ECHO2
+12V
ECHO LEVEL
CONT
OFF
1
2
3
ECHO1 H L H L
ECHO2 H H L L
FOR D631T ONLY
ENB-248-6
MIC1 JACK
MIC2 JACK
J1101
J1102
TW002
D1146 MTZ2.4JB
C1146 0.01
C1147 0.001
C1148 0.001
R1101 4.7K
R1102 4.7K
C1114 330P
R1103 39K
R1104
R1105
C1115 10/25
C1144 10/25
C1145 10/25
C1143 10/25
C1112 150P
R1137 100K
R1136 560
R1135 47K
C1142 100P
C1141 100P
C1140 10/25
R1134 22K
C1139 0.001
VR302 10K
R1133 220
IC912 VC4580D (1/2)
MIC VOL
MIC
A.GND
-12V
+12V
FW412
TO CN422 OF ENC-136-2 (SHEET4/11)

10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20

* MARK LIST

CIRCUIT	SYMBOL NO.	D601T U, US, UP, UT, UB	D601T A	D601T BS, EF, EN, G, VX	D631T EF, EN, G	D651TR EF, EN, G	D661T J, C
MIC	C453~455	USED	NONE	NONE	NONE	NONE	USED
	R445, 446	USED	NONE	NONE	NONE	NONE	USED
	R447	USED	SHORT	SHORT	SHORT	SHORT	USED
	R448	USED	NONE	NONE	NONE	NONE	USED
MIX	C437~442	USED	NONE	NONE	USED	NONE	NONE
	D401, 402	USED	NONE	NONE	USED	NONE	NONE
	IC403	USED	NONE	NONE	USED	NONE	USED
	IC404	USED	NONE	NONE	USED	NONE	NONE
	R423~425	USED	NONE	NONE	USED	NONE	NONE
	R426, 427	USED	NONE	NONE	USED	NONE	SHORT
	R428~430	USED	NONE	NONE	USED	NONE	NONE
	R403, 404	NONE	USED	USED	NONE	USED	USED
MIC MIX	C451, 452	USED	NONE	NONE	USED	NONE	NONE
	R443, 444	USED	NONE	NONE	USED	NONE	NONE
	R435, 436	4.7K	3.9K	3.9K	4.7K	3.9K	3.9K
GAIN	R409, 410	4.7K	3.3K	3.3K	3.3K	3.3K	4.7K
	R457, 458	7.5K	7.5K	7.5K	7.5K	7.5K	5.6K
MIC CUT	S490	NONE	NONE	USED	USED	USED	NONE
	R490	NONE	NONE	USED	USED	USED	NONE



P1-68-a P1-68-b



P1-68-c P1-68-d


ENC-136-2
IC301
MN173222JAAX
DECK/CD sCOM
END-107
CA-D601T (A, EF, EN, G, BS, VX)
CA-D661T, CA-D651TR ONLY
TO CN412 OF ENC-136-1 (SHEET3/11)
FROM FW412 OF ENB-248-6 (SHEET 3/11)
TO CN504 OF ENN-488-1 (SHEET 10/11)
TO CN801 OF VMM1377 (SHEET 11/11)
TO CN403 OF ENB-248-1 (SHEET 5/11)
TO TW222 OF ENB-248-2 (SHEET4/11)

■ Deck Section





0 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20



* MARK

	CA-D601T			CA-D561T	CA-D631T	CA-D551TR
	U, UB, U, UT, UP	A	EF, EN, G, BS, VX	J, C	EF, EN, G	EF, EN, G
C319	NONE	NONE	0.022	NONE	0.022	0.022
C327	NONE	NONE	560P	NONE	560P	560P
C328	NONE	NONE	0.022	NONE	0.022	0.022
D303	NONE	NONE	1SS133	NONE	1SS133	1SS133
FW292	NONE	USED	USED	USED	NONE	USED
JT201	USED	NONE	NONE	NONE	NONE	NONE
JT202	USED	NONE	NONE	NONE	USED	NONE
K301~303	SHORT	SHORT	ENZ8101-007	SHORT	ENZ8101-007	ENZ8101-007
K321	SHORT	SHORT	ENZ8101-007	SHORT	ENZ8101-007	ENZ8101-007
K392	SHORT	SHORT	ENZ8101-007	SHORT	ENZ8101-007	ENZ8101-007
Q330	NONE	NONE	2SC1740S (R, S)	NONE	2SC1740S (R, S)	2SC1740S (R, S)
Q331	NONE	NONE	KRA104M	NONE	KRA104M	KRA104M
R298	NONE	NONE	560	NONE	560	560
R365, 366	SHORT	SHORT	47	SHORT	47	47
R383, 384	SHORT	SHORT	47	SHORT	47	47
R288	UNF.F	UNF.F	UNF.F	UNF.C	UNF.F	UNF.F
TW843	NONE	USED	USED	USED	NONE	USED

P1-69-a P1-69-b



P1-69-c P1-69-d


IC602
BA6897FPW
BTL DRIVER
CN602
CN603
TP602 (ARF)
TP601 (GND)
Q601
2SA952 (L, K)
REST SW
SPINDLE
FEED
FM-
SM+
SM-
FM+
F+
F-
T+
T-
SM-
SM+
FM-
FM+
M.GND
A.GND
CD+8V
CD+8V
CDIR
A.GND
CDIL
FROM CN613 OF ENC-136-1 (SHEET 3/11)
CD +5V
D631
MTZ5.6JB
LDON
BDO
OFT
RFDET
ARF
TES
PLAY
WVEL
VREF
FBAL
TBAL
FE
TE
RFENV
VDET
TRCRS

■ CD Section


EMW20008
OPTIMA-6
LT022MSA
OR
RLD-78MA
PN3Q4K-(SL)
FOCUS COIL
TRACKING COIL
E406755
E406982
ENN-488-1
CN601
TW601
MECHA GND
IC601
AN8806SB
RF & SERVO AMP
TBAL
FBAL
FE
TE
RFENV
TRCRS
VDET
TRV
TVD
PC
ECM
ECS
KICK
TRD
FOD
VREF
RST
STAT


A.GND
CD+8V
CD+8V
CDIR
A.GND
CDIL
CN603
R632 150
D631 MTZ5.6JB
Q632 2SC2060 (Q, R)
C630 22 /10
C635 100 /10
CD +5V
C679 100/10
C662 0.1TF
C661 470P
R662 2.7M
R661 68K
R663 120K
R664 470
C663 0.022
C664 0.022
C665 0.1TF
IC603 MN35510
DIGITAL SERBO PROCESSER
TES
PLAY
WVEL
ARF
IRFE
DRF
DSLF
PLLF
VCOF
AVDD2
AVSS2
EFM (XCLK)
PCK
TOFS
SUBC
SBCK
VSS
X1
X2
VDD
C651 12P
C652 12P
X651 ECX0169-344EF
R692 270
C671 0.0022
C672 0.0022
R671 1K
R672 1K
R666 22
C673 220 /10
C674 0.022
TRD
FOD
VREF
FBAL
TBAL
FE
TE
RFENV
VDET
OFT
TRCRS
RFDET
FDO
LDON
R660 1K
AVSS1
OUTL
AVDD1
TEST
IOSEL
RESY
DEMPH
CRC
CLVS
FLAG
IPFLAG
FCLK
CLDCK
BYTCK


11
12
13
14
15
16
17
18
19
20
RST
STAT
SUBQ
SQCK
BLKCK
MLD
MDATA
MCLK
SRDATA
LRCK
BCLK
C655
0.1MY
C632
220
/10
C653
0.022
R651
1K
R652
1K
R653
1K
R691
1K
R693
100
R694
100
R695
100
CN604
NC
RESTSW
MLD
MDATA
MCLK
RST
STAT
SQCK
SUBQ
A.GND
A.GND
FROM CN614 OF
ENC-136-2
(SHEET 4/11)
IC603
MN35510
DIGITAL SERBO
&
PROCESSER
TRV
TVD
PC
ECM
ECS
KICK
TRD
FOD
VREF
FBAL
SSEL
MSEL
PSEL
CSEL
RSEL
OUTR
AVSS1
OUTL
AVDD1
TEST

P1-70-a P1-70-b



P1-70-c P1-70-d


N
M
L
K
J
I
H
G
MW RF&OSC
T111
EQR71121-007
C103
0.022
TP101
V.TUNE
R129
2.2K
R119
10K
C111
0.022
C112
12P
R115
100K
C130
100/25
C109
22/25
R128
4.7K
* R130
R134
1K
R184
10K
R183
10K
R182
10K
R133
8.2K
D121
1SS133
D123
1SS133
C180
100/25
CN111
IFDATA
CE
TUNERDATA
CK
MUTE
TUNED
STEREO
+12V
+5.6V
LOUT
GND
ROUT

■ Tuner Section





VERSION CODES

J : U.S.A.
C : CANADA
A : AUSTRALIA
UP : KOREA
UB : HONGKONG
US : SINGAPORE
UT : TAIWAN
U : UNIVERSAL EXCEPT ALL OF ABOVES

11	12	13	14	15	16	17	18	19	20



* MARK

	J, C	U, A
C137	680P	560P
C139, 140	0.033TF	0.022TF
CF101, 102	QAX0284 -001Z	QAX0285 -001Z
R130	68 UNF.C. (1/4W)	68 UNF.F. (1/4W)
R147	15K	27K

RF101
EAF2207-001



P1-71-a P1-71-b P1-71-c



■ Changer Section



TABLE 1 CAM PATTERN LIST

CAM NO / POSITION	LCAM 0	1	2	3	ON	RCAM 4	5	6	7	POSITION
MAIN TRAY1	0	1	1	1	0	1	1	1	0	EMERGENCY
SUB TRAY1	0	0	1	1	0	1	1	0	0	TRAY1 STANDBY
CAMR 1	0	1	0	1	0	1	0	1	0	TRAY1 CHECKING
MAIN TRAY2	1	0	0	1	0	1	0	0	1	TRAY2 STANDBY
SUB TRAY2	1	1	1	0	0	0	1	1	1	TRAY2 CHECKING
CAMR 2	1	0	1	0	0	0	1	0	1	TRAY3 STANDBY
MAIN TRAY3	1	1	0	0	0	0	0	1	1	TRAY3 CHECKING
SUB TRAY3	1	0	0	0	0					
OFF	1	1	1	1	0	1	1	1	1	OFF

0=0V
1=5V


TO CN811 OF
FMH-005-1
(SHEET 2/8)
CNB01
*WAB
DATA
CKS
SWBV
MGND
SW5V
DGND
REG
DATA
ST
CKS
SAFETY
L804
VQP0033-100Z
L801
VQP0018-100Y
C801
100/10
C804
0.01
C805
0.01
R832
180
R834
1K
AMDWN
AMUP
C808
0.001
R810
1M
R811
1M
C803
0.001
R839
3.3k
R840
5.6k
C802
4.7/25
IC801
UPD65612GB-165
NC
OSD1
OSD2
C25IN
C25OUT
RESET
SELECT
GND
CK
1MSW
2MSW
3MSW
CFIL
CAM7
CAM6
CAM5
CAM4
CAM3
CAM2
CAM1
CAM0
1SSW
2SSW
R826
R825
R824
R823
R822
R821
R820
R819
R818
R817
R805
R806
R807
R808
C821
C809
C813
0.001
R813
R814
R815
R816
C815
C816
C817
R833
LMDWN
LMUP
VMW1377

16
17
18
19
20
7

Printed Circuit Boards

■ Power Supply & Amp Board (ENH-302)




CN014
S001
R1091
R1092
R1093
F102
F101
F002
F001
F003
TB001
TB002
R001
FW101
CN701
C799
Q757
5
6
7
8
9
10

Location List(ENH-302)

Symbol	X	Y
C001	2	E
C002	3	E
C003	3	E
C004	3	G
C004A	2	F
C005	3	F
C005A	2	G
C011	3	E
C012	4	E
C013	3	E
C014	4	G
C015	4	F
C016	2	D
C017	1	D
C018	2	D
C019	1	D
C020	1	E
C021	1	E
C022	1	E
C023	2	D
C024	2	D
C030	2	J
C031	2	J
C032	2	I
C033	4	D
C034	3	D
C035	3	D
C060	3	B
C061	3	B
C062	3	B
C063	5	B
C064	5	B
C065	5	A
C066	5	B
C067	5	B
C068	5	A
C069	4	B
C070	4	B
C071	4	B
C072	4	B
C073	4	B
C074	4	B
C091	1	G
C092	1	F
C093	1	I
C094	1	G
C095	1	H
C096	1	G
C097	1	I
C101	6	D
C1017	8	C
C1018	4	J
C102	6	D
C103	7	B
C1061	7	C
C1062	8	C
C1073	5	I
C1074	5	I
C703	7	C
C704	8	C
C705	7	C
C706	8	C
C707	7	C
C708	8	C
C709	7	C
C710	8	C
C711	7	D
C712	8	D
C713	7	A
C714	7	A
C715	6	A

Symbol	X	Y
C716	7	A
C717	7	A
C718	7	A
C721	6	D
C722	6	D
C726	8	A
C729	8	B
C751	9	B
C752	9	B
C753	9	B
C754	8	B
C755	9	C
C756	8	C
C757	9	C
C758	8	C
C770	9	H
C781	9	E
C782	9	E
C783	10	F
C784	10	G
C785	10	G
C786	10	H
C787	10	F
C788	10	G
C789	10	F
C790	10	G
C791	10	F
C792	10	G
C793	10	I
C794	10	I
C795	10	I
C796	9	I
C797	10	I
C798	10	I
C799	8	E
CH001	7	I
CH002	3	I
CH003	5	I
CH004	7	J
CN002	3	I
CN003	3	H
CN004	4	I
CN005	6	I
CN005B	6	I
CN006	2	H
CN007	2	E
CN009	4	F
CN012	2	B
CN013	9	C
CN014	10	J
CN019	7	E
CN111	4	D
CN505	1	F
CN703	6	D
CN704	9	E
CN915	6	A
D001	2	E
D002	2	E
D003	2	E
D004	3	E
D011	3	E
D012	3	E
D013	3	E
D014	4	E
D015	4	I
D016	4	I
D017	2	D
D018	2	D
D019	2	D
D020	1	E
D021	2	D

Symbol	X	Y
D022	3	C
D023	3	D
D024	1	D
D025	1	D
D027	2	D
D030	3	J
D040	5	I
D041	6	I
D043	6	I
D060	3	B
D061	3	B
D062	3	B
D063	5	A
D064	5	A
D065	5	B
D066	5	A
D067	4	B
D068	4	B
D069	4	B
D070	4	B
D1060	5	I
D703	9	C
D704	8	C
D719	6	A
D720	7	B
D728	8	A
D751	9	A
D752	9	A
D753	9	B
D754	9	B
D755	9	B
D756	8	B
D757	9	C
D758	8	C
D759	9	C
D760	8	C
D789	10	I
D790	9	I
F001	5	F
F002	6	H
F003	5	E
F101	7	H
F102	7	H
FW101	7	E
FW401	6	D
IC091	1	G
IC701	7	D
IC702	8	D
IC781	9	F
IC782	9	G
J091	1	J
K001	2	H
K002	2	I
K003	2	H
K004	2	I
K005	2	I
K006	2	H
K007	2	G
K008	2	F
K009	2	F
L701	7	B
L702	7	B
L781	10	H
L782	9	H
Q001	1	D
Q003	2	D
Q004	2	D
Q005	2	D
Q030	2	J
Q040	5	I
Q041	6	I

Symbol	X	Y
Q060	3	C
Q061	3	B
Q062	3	B
Q063	4	C
Q064	5	B
Q065	5	B
Q066	5	C
Q067	5	B
Q068	5	B
Q069	4	C
Q070	4	B
Q071	4	C
Q072	4	B
Q073	2	B
Q074	2	B
Q075	2	B
Q076	2	B
Q1057	8	B
Q701	6	A
Q702	7	A
Q726	8	A
Q727	8	B
Q728	8	A
Q733	6	A
Q734	6	A
Q735	6	A
Q736	6	A
Q737	6	B
Q751	9	B
Q752	8	B
Q753	9	B
Q754	8	B
Q755	9	C
Q756	8	C
Q757	9	D
Q758	8	D
Q781	10	I
Q782	9	I
Q901	1	G
R001	7	E
R002	3	D
R003	2	D
R004	1	D
R005	1	E
R006	1	E
R007	1	E
R008	3	D
R009	3	D
R010	2	C
R011	2	C
R012	1	D
R013	2	D
R014	2	D
R030	2	I
R031	2	I
R032	2	H
R033	2	H
R034	2	I
R037	2	I
R040	6	I
R041	5	I
R042	5	I
R043	6	I
R044	6	I
R045	5	I
R052A	5	A
R060	3	A
R060A	3	B
R061	3	A
R061A	3	B
R062	3	B

Symbol	X	Y
R063	3	B
R064	3	B
R065	3	A
R066	3	B
R067	3	B
R068	3	B
R069	5	A
R069A	5	A
R070	4	A
R070A	4	A
R071	5	B
R072	5	B
R073	5	B
R074	5	A
R074A	5	A
R075	5	A
R076	5	C
R077	5	B
R078	5	B
R079	4	A
R080	4	A
R081	4	B
R082	4	B
R083	4	A
R084	4	B
R085	4	A
R091	1	F
R092	1	G
R093	1	H
R1056	8	C
R1057	8	C
R1058	9	A
R1059	4	J
R1060	4	J
R1073	6	I
R1074	6	I
R1091	8	J
R1092	7	I
R1093	8	I
R701	7	C
R702	8	C
R703	7	C
R704	8	C
R705	7	C
R706	8	C
R707	7	C
R708	8	C
R709	6	B
R710	7	B
R711	6	B
R712	7	B
R713	6	A
R714	7	A
R715	7	A
R716	7	A
R717	6	B
R718	7	B
R719	6	A
R720	7	A
R721	6	A
R722	7	A
R723	7	B
R724	7	B
R725	9	A
R726	9	A
R727	8	B
R728	8	A
R729	8	B
R730	8	A
R733	6	B
R734	6	B

Symbol	X	Y
R735	6	B
R736	6	B
R737	6	B
R738	6	B
R739	6	B
R740	6	B
R741	10	F
R742	10	F
R743	10	I
R744	10	I
R745	10	I
R746	9	I
R747	9	I
R748	10	I
R749	9	G
R750	9	H
R751	9	B
R752	9	B
R753	9	B
R754	8	B
R755	9	B
R756	8	B
R757	9	B
R758	8	B
R759	9	B
R760	8	B
R761	9	B
R762	8	B
R763	9	C
R764	8	C
R765	9	B
R766	8	B
R767	9	C
R768	8	C
R769	9	C
R770	9	C
R771	9	B
R772	9	B
R773	8	B
R774	8	A
R775	7	C
R776	8	C
R777	8	A
R778	8	A
R781	9	G
R782	9	H
R783	10	G
R784	10	H
R785	10	G
R786	10	H
R787	10	F
R788	10	G
R789	10	H
R790	9	H
R791	10	H
R792	9	H
R793	10	H
R794	9	H
R795	10	I
R796	9	I
R797	10	H
R798	9	H
S001	7	I
TB001	6	G
TB002	5	F
TH002	3	D

■ Front & Control Board (ENB248)




6
7
8
9
10

Location List (ENB-248)

Symbol	X	Y
C051	10	F
C052	9	E
C053	10	F
C054	10	F
C055	10	E
C056	10	E
C057	10	D
C058	10	D
C059	10	D
C095	8	E
C096	8	E
C1112	8	B
C1113	9	A
C1114	7	B
C1115	8	B
C1116	9	A
C1117	9	A
C1118	9	A
C1119	9	A
C1120	9	A
C1121	10	A
C1122	10	A
C1123	10	A
C1124	10	A
C1125	10	B
C1126	10	B
C1127	9	B
C1128	9	B
C1129	9	B
C1130	10	B
C1131	9	A
C1132	9	B
C1133	10	A
C1134	8	A
C1135	8	A
C1136	8	A
C1137	8	A
C1138	7	A
C1139	8	B
C1140	8	B
C1141	8	B
C1142	7	B
C1143	7	B
C1144	8	B
C1145	8	B
C1146	7	C
C1147	8	B
C1148	7	B
C233	5	H
C234	5	H
C235	5	H
C236	5	H
C237	7	H
C238	7	H
C239	7	H
C240	6	H
C241	6	H
C242	7	H
C243	6	H
C244	6	H
C245	7	H
C246	7	H
C247	7	H
C251	4	H
C801	6	A
C802	6	A
C901	3	E
C902	3	E
C903	3	E
C904	7	D
C905	7	D
C906	3	D
C907	3	D
C908	7	F
C910	7	F
C911	7	F
C912	7	E
C914	7	E
C915	7	C
C916	3	G

Symbol	X	Y
C921	5	C
C922	6	C
C923	5	C
CH001	8	C
CH001	10	H
CH001	10	C
CH001	7	G
CH002	8	C
CH002	7	G
CH002	10	H
CH003	10	H
CH003	7	G
CH003	9	B
CH004	10	B
CH004	7	G
CH004	10	H
CH005	6	G
CH005	10	H
CH005	9	C
CH006	6	G
CH006	10	H
CH007	6	G
CH007	10	H
CH008	6	G
CH008	10	H
CH009	10	H
CH009	6	G
CH010	10	H
CH010	6	F
CH011	6	G
CH011	10	H
CH012	6	F
CH012	9	H
CH013	6	G
CH013	4	J
CH014	4	J
CH014	5	F
CH015	8	J
CH015	5	G
CH016	8	J
CH016	5	F
CH017	5	G
CH017	8	H
CH018	5	F
CH019	5	G
CH020	5	G
CH021	5	G
CH022	5	G
CH023	5	G
CH024	5	G
CH025	4	G
CH026	4	G
CH027	4	G
CH028	4	G
CH029	4	G
CH030	4	G
CH031	4	G
CH032	4	G
CH033	4	G
CH034	4	G
CH035	4	G
CH036	1	F
CH037	1	F
CH038	1	F
CH039	3	G
CH040	3	G
CH041	1	F
CH042	1	F
CH101	9	B
CH101	3	B
CH101	4	H
CH102	3	B
CH102	3	H
CH103	3	B
CH103	4	H
CH103	8	D
CH104	8	F
CH104	3	B
CH105	4	B
CH105	8	D

Symbol	X	Y
CH106	1	C
CH106	8	D
CH107	8	D
CH107	1	C
CH108	1	B
CH108	8	F
CH109	8	F
CH109	1	I
CH110	8	F
CH110	1	I
CH111	8	D
CH111	1	I
CH112	7	E
CH112	8	E
CH113	6	G
CH114	6	G
CH115	6	G
CH116	7	G
CH121	7	G
CH122	7	F
CH201	2	B
CN015A	9	C
CN015B	10	C
CN101	10	H
CN121	10	H
CN301	8	H
CN302	5	H
CN313	5	I
CN314	9	I
CN401	1	E
CN401A	1	E
CN402	2	I
CN403	6	E
CN412	7	A
CN713	8	F
CN714	8	D
D041	9	F
D042	9	E
D1101	7	A
D231	4	H
D232	5	J
D233	4	J
D234	4	J
D235	8	J
D236	8	J
D237	7	J
D801	7	B
D802	7	B
D803	3	A
D804	6	A
D805	5	A
D806	4	A
D901	4	F
D902	7	D
D904	3	D
D905	1	D
D906	1	D
D907	1	C
D908	1	C
D909	1	C
D910	1	C
D911	1	B
D912	1	B
D913	2	G
D914	2	F
D915	2	E
D916	3	F
D917	1	H
D918	1	I
D919	1	I
D920	7	D
D921	4	F
D922	7	F
D923	7	C
D924	7	C
D925	4	E
D931	6	C
D932	6	C
D933	6	C
D934	6	C

Symbol	X	Y
D935	6	C
D936	6	C
D937	6	C
D941	5	C
D1901	7	G
FW401A	3	B
FW401B	4	C
FW402	6	A
FW411	8	G
IC231	7	H
IC901	2	D
IC902	6	F
IC903	6	C
IC904	7	E
IC912	8	B
IC914	9	A
IC915	8	A
J081	10	E
J082	10	G
J083	10	D
J1101	8	C
J1102	7	C
J801	7	A
JS801	2	B
K801	6	A
L101	10	H
Q1101	10	B
Q1102	9	B
Q231	3	H
Q232	3	H
Q233	4	H
Q234	4	H
Q235	3	H
Q236	3	H
Q237	8	H
Q901	1	B
Q902	1	B
Q903	1	B
Q904	1	B
Q921	7	C
Q922	7	G
Q923	6	G
Q924	6	G
Q925	6	G
R047	10	G
R048	10	G
R049	10	G
R051	10	F
R052	10	F
R1101	7	B
R1102	7	B
R1103	7	B
R1104	7	A
R1105	7	A
R1111	10	B
R1112	10	B
R1113	10	B
R1114	9	B
R1115	10	B
R1116	9	A
R1117	9	A
R1118	9	A
R1119	10	A
R1120	10	A
R1121	8	A
R1122	10	A
R1123	10	A
R1124	10	B
R1129	8	A
R1131	9	A
R1132	8	A
R1133	9	B
R1134	8	B
R1135	7	B
R1136	8	B
R1137	7	B
R235	5	H
R236	5	H
R237	5	H
R238	5	H

Symbol	X	Y
R239	7	H
R240	7	H
R241	6	H
R242	7	H
R245	4	H
R246	3	H
R247	4	H
R248	4	H
R249	8	H
R250	8	H
R251	8	H
R255	4	H
R256	4	H
R257	4	H
R258	4	H
R259	3	H
R260	3	H
R261	3	H
R262	3	H
R263	5	H
R264	5	H
R265	5	H
R266	5	H
R267	5	H
R268	8	H
R269	9	H
R801	6	B
R802	6	B
R803	5	B
R804	5	B
R805	4	B
R806	3	A
R807	6	A
R808	5	A
R809	5	A
R810	4	A
R811	4	A
R812	7	B
R813	3	A
R814	6	B
R815	5	B
R816	4	B
R817	2	A
R818	2	A
R900	4	E
R901	3	E
R902	4	E
R903	4	E
R904	2	E
R905	3	E
R906	2	C
R907	2	C
R908	2	C
R909	1	E
R910	1	E
R911	1	E
R912	2	C
R913	2	C
R914	2	C
R915	5	C
R918	2	F
R919	1	H
R920	1	I
R921	1	I
R922	1	H
R923	1	H
R924	1	I
R925	3	F
R926	2	F
R927	1	H
R928	1	I
R929	2	J
R930	2	I
R931	2	H
R932	2	B
R933	2	C
R934	2	D
R935	1	E
R936	1	F
R937	1	F

Symbol	X	Y
R938	1	H
R939	4	D
R940	4	D
R941	4	D
R942	5	D
R943	5	D
R944	4	D
R945	1	D
R946	1	D
R947	1	C
R948	1	C
R949	1	C
R950	1	C
R951	2	B
R952	2	B
R953	2	G
R954	2	F
R955	2	F
R956	2	F
R957	1	H
R958	1	I
R959	1	I
R960	4	C
R961	4	C
R962	4	C
R963	4	C
R964	7	E
R965	7	E
R966	7	E
R967	5	F
R968	5	F
R970	7	C
R971	6	D
R972	6	C
R973	6	C
R974	6	C
R975	2	F
R976	7	G
R977	5	G
R978	5	G
R979	5	G
R980	5	C
R981	5	C
R982	6	C
R983	5	C
R984	5	C
R985	5	C
R986	5	C
R987	2	E
R988	1	E
R989	6	E
R991	3	F
R992	3	F
R993	3	F
R994	3	F
R995	3	F
RA901	3	D
RA902	7	G
RA903	5	G
RA904	4	G
RA905	4	G
RY001	9	G
RY002	9	E
S801	7	B
S802	6	B
S803	5	B
S804	5	B
S805	4	B
S806	4	B
S807	3	A
S808	6	A
S809	6	A
S810	5	A
S811	4	A
S812	4	A
S813	4	A
S901	2	F
S902	2	F
S903	1	H
S904	1	I

Symbol	X	Y
S905	1	I
S906	1	H
S907	1	I
S908	1	I
S909	3	F
S910	2	F
S911	2	G
S912	1	J
S913	1	J
S914	2	I
S915	2	I
S916	2	H
S917	2	B
S918	2	C
S919	2	C
S920	2	D
S921	1	F
S922	1	F
S923	1	G
S924	1	G
S925	2	B
S926	3	D
S927	4	D
S928	5	D
S929	5	D
S930	6	D
TC902	7	F
X1101	8	A
X901	3	D
X902	7	G

■ Source Select & SEA Board (ENC136)




5
6
7
8
9
10

Location List(ENC-136)

Symbol	X	Y
C201	4	H
C202	4	H
C203	4	H
C205	5	C
C206	5	C
C207	4	C
C208	4	C
C231	2	I
C232	2	I
C305	2	B
C306	2	C
C315	3	B
C316	3	C
C317	3	B
C318	3	B
C319	3	B
C320	3	C
C321	3	C
C322	3	C
C323	3	C
C324	2	B
C325	3	B
C326	3	B
C327	3	B
C328	3	B
C331	1	D
C332	2	C
C335	2	G
C336	2	H
C337	2	G
C338	2	H
C339	2	I
C340	1	G
C341	1	G
C342	2	H
C343	2	G
C344	2	H
C345	2	G
C346	2	H
C347	2	G
C348	3	G
C349	3	G
C350	3	G
C351	2	I
C352	2	I
C353	2	I
C365	1	C
C366	1	D
C367	2	C
C368	2	C
C369	2	C
C370	2	B
C371	2	C
C372	2	D
C373	1	G
C374	1	D
C375	1	C
C376	1	C
C377	1	C
C378	1	D
C379	1	B
C380	1	C
C381	1	C
C383	1	I
C384	1	H
C385	1	H
C386	1	I
C387	2	J
C388	1	I
C389	1	H
C390	1	I
C391	2	D
C392	1	H
C393	1	H
C394	1	I
C395	1	H
C396	1	I
C397	1	J

Symbol	X	Y
C398	1	J
C401	7	J
C402	7	I
C403	7	J
C404	7	I
C405	6	J
C406	6	I
C407	6	J
C408	6	I
C409	8	I
C410	8	I
C411	7	I
C412	7	I
C413	6	F
C414	6	F
C415	6	H
C416	6	G
C417	6	H
C418	7	H
C419	7	H
C420	7	H
C421	7	H
C422	6	H
C423	7	H
C424	7	H
C425	7	H
C426	6	H
C427	7	H
C428	6	H
C429	7	H
C430	8	H
C431	7	H
C432	7	G
C433	8	F
C434	8	F
C435	8	H
C436	8	H
C437	8	I
C438	8	I
C439	8	I
C440	9	I
C441	9	H
C442	9	H
C443	9	H
C444	10	H
C445	8	G
C446	8	G
C447	8	G
C448	8	G
C449	9	G
C450	9	G
C451	9	G
C452	9	G
C453	8	H
C454	8	H
C455	9	H
C457	9	E
C458	9	E
C459	9	F
C460	9	F
C461	9	F
C462	9	F
C463	8	F
C464	8	E
C465	8	F
C466	9	F
C467	9	E
C468	9	E
C469	8	F
C470	8	F
C471	7	E
C472	7	E
C473	8	E
C474	8	E
C475	8	F
C476	7	F
C477	6	G
C481	6	E

Symbol	X	Y
C482	6	E
C483	6	E
C484	6	E
C485	9	I
C486	9	I
C487	6	C
C488	6	D
C489	6	J
C490	7	J
C493	6	J
C494	7	I
C495	6	J
C496	7	J
C497	6	J
C498	7	J
C499	6	I
C501	9	C
C502	9	C
C503	7	D
C504	7	D
C505	7	D
C506	8	D
C507	8	D
C508	8	D
C509	8	D
C510	8	D
C511	9	D
C512	9	B
C513	9	D
C514	9	B
C515	9	C
C516	9	C
C517	9	C
C518	9	C
C519	9	D
C520	9	B
C521	9	D
C522	9	B
C523	9	D
C524	9	B
C525	9	D
C526	9	B
C527	9	D
C528	9	B
C529	8	B
C530	8	B
C531	7	B
C532	8	B
C533	8	B
C534	8	B
C535	8	B
C541	6	C
C542	7	C
C543	7	C
C544	7	B
C545	7	B
C546	7	B
C547	7	B
C548	7	B
C549	6	B
C550	6	B
C551	6	B
C552	6	C
C553	9	C
C554	9	C
C555	7	C
C556	7	C
C561	7	D
C562	7	D
C563	7	D
C564	7	C
C565	8	D
C566	8	D
C567	6	D
C568	6	C
C569	6	D
C570	6	D
CN016	7	A

Symbol	X	Y
CN017	9	A
CN131	9	J
CN311	3	I
CN312	3	D
CN322	5	H
CN331	1	D
CN332	1	H
CN402	4	B
CN411	10	I
CN412	10	G
CN422	4	J
CN613	8	J
CN614	5	I
CN701	6	G
CN811	4	I
D201	4	H
D202	4	E
D203	5	D
D290	4	C
D303	3	B
D305	1	E
D306	1	E
D307	4	E
D308	4	E
D401	9	H
D402	9	H
D481	6	E
D482	6	E
D483	6	E
D484	6	E
IC301	4	G
IC302	1	C
IC303	1	I
IC304	1	D
IC305	2	H
IC401	7	H
IC402	7	J
IC403	8	H
IC404	9	H
IC405	8	G
IC406	9	E
IC407	8	E
IC501	8	C
IC541	6	C
IC561	8	D
IC562	6	C
K301	4	C
K302	4	B
K303	5	D
K321	1	C
K392	1	H
L301	2	B
L305	2	B
L306	2	C
Q201	4	H
Q321	4	D
Q322	4	D
Q323	4	E
Q324	4	E
Q325	4	D
Q326	4	C
Q327	3	B
Q328	3	C
Q329	3	C
Q330	3	B
Q331	3	B
Q341	4	F
Q342	4	F
Q343	4	F
Q401	7	G
Q402	7	F
Q403	6	G
Q481	6	E
Q482	6	E
Q483	6	E
Q491	9	J
Q492	8	I
Q501	7	F

Symbol	X	Y
Q502	7	F
R202	4	H
R203	4	H
R204	4	H
R205	4	H
R206	4	H
R207	4	H
R208	4	H
R209	4	I
R211	4	E
R212	4	E
R213	4	E
R214	4	E
R215	4	E
R217	3	I
R218	4	I
R231	2	I
R232	2	I
R233	3	I
R234	2	J
R271	1	C
R272	1	D
R280	1	D
R281	1	H
R282	1	H
R283	1	C
R284	1	D
R285	3	C
R286	3	C
R287	3	C
R288	3	C
R290	4	C
R291	4	B
R292	4	B
R293	4	B
R294	4	B
R296	3	B
R297	4	B
R298	3	B
R335	1	F
R336	2	I
R337	1	G
R338	1	E
R339	3	G
R340	3	G
R341	2	G
R342	2	H
R343	2	I
R344	2	I
R345	2	I
R346	2	I
R347	1	E
R348	1	E
R349	4	E
R351	4	D
R352	4	D
R353	4	D
R354	4	D
R355	4	C
R356	4	D
R357	3	F
R358	3	F
R359	4	D
R360	4	E
R361	4	D
R362	4	E
R365	1	C
R366	1	D
R367	1	C
R368	2	C
R369	2	C
R370	1	C
R371	2	C
R372	1	C
R377	1	G
R378	2	D
R381	1	D
R382	1	G

Symbol	X	Y
R383	1	H
R384	1	I
R385	1	H
R386	1	I
R387	2	I
R388	1	I
R391	1	H
R392	1	I
R401	7	J
R402	7	I
R403	7	J
R404	7	I
R405	6	J
R406	6	I
R407	6	J
R408	6	I
R409	8	I
R410	8	J
R411	8	I
R412	8	J
R413	6	F
R414	6	F
R415	6	F
R416	6	F
R417	7	H
R418	7	H
R419	7	H
R420	6	H
R421	8	H
R422	8	H
R423	8	I
R424	8	I
R425	8	I
R426	8	I
R427	8	I
R428	9	I
R429	9	H
R430	9	H
R431	9	H
R432	9	H
R433	9	G
R434	9	G
R435	9	G
R436	9	G
R437	8	G
R438	8	G
R439	9	G
R440	9	G
R441	8	G
R442	8	G
R443	9	G
R444	9	G
R445	8	H
R446	8	H
R447	8	H
R448	9	I
R450	8	E
R451	8	F
R452	8	F
R453	8	E
R454	8	E
R455	7	F
R456	7	E
R457	8	E
R458	8	E
R459	8	F
R460	8	F
R461	7	G
R462	7	F
R463	7	F
R464	7	F
R465	6	G
R467	9	E
R468	9	E
R469	8	F
R470	8	F
R471	9	E
R472	9	E

Symbol	X	Y
R473	9	E
R481	7	E
R482	7	E
R483	6	E
R484	6	E
R485	7	F
R486	7	E
R490	6	I
R491	9	J
R492	8	I
R493	6	J
R494	7	I
R495	6	J
R496	6	J
R497	6	J
R498	6	J
R501	10	C
R502	10	C
R532	8	B
R533	8	B
R534	8	B
R541	6	C
R542	7	C
R543	7	C
R544	7	C
R545	7	C
R553	10	C
R554	10	C
R555	7	D
R556	7	D
R561	7	D
R562	7	C
R563	6	D
R564	6	C
R565	6	D
R566	6	C
R567	6	D
R568	6	D
R569	7	F
R570	7	F
R571	7	F
R572	7	F
S490	6	I
X201	4	H
X541	6	B

■ Tuner Board (ENA178)




R128
C130
R130
C109
C123
C121
FC121
X121
C133
D130
R134
R184
R181
C122
R121
Q123
Q121
D121
C180
C143
R126
C185
R191
D122
R133
C147
C148
C186
D124
C195
R143
C149
FL142
R162
R144
R145
C161
C182
R157
FL141
R158
C181
R182
C162
R183
C140
R166
R165
C136
R164
R163
C139
D123
CN111

6 7 8 9 10

Location List (ENA-178)

Symbol	X	Y
C101	3	E
C102	4	E
C103	3	E
C104	2	D
C105	4	D
C107	3	C
C109	6	E
C111	1	B
C112	1	B
C113	1	A
C117	3	B
C118	3	A
C121	5	E
C122	6	D
C123	5	E
C126	4	E
C128	5	E
C129	4	E
C130	5	E
C131	9	C
C132	9	B
C133	3	A
C135	4	A
C136	5	A
C137	4	B
C138	5	A
C139	6	B
C140	5	B
C141	4	B
C143	6	D
C144	4	B
C146	5	C
C147	6	C
C148	6	C
C149	5	C
C150	4	B
C153	6	B
C154	8	C
C155	5	A
C156	4	E
C157	3	B
C158	3	C
C159	7	C
C160	6	C
C161	6	B
C162	5	B
C163	5	C
C164	5	C
C165	7	E
C166	8	B
C167	9	B
C168	2	A
C170	8	C
C171	8	B
C172	9	B
C173	9	C
C174	9	C
C177	9	C
C178	10	C
C179	10	C
C180	7	D
C181	6	B
C182	6	B
C183	7	D
C184	4	C
C185	7	C
C186	6	C
C187	9	B
C188	10	C
C189	10	B
C190	9	B
C191	9	D
C192	10	D
C193	9	E
C194	9	E
C195	8	C
C196	9	D
C197	8	D
C199	10	E
CF101	3	D
CF102	3	C
CN111	6	B
CN112	9	E
D121	7	D
D122	8	C
D123	7	A
D124	7	C
D129	4	E
D130	7	E
D131	8	A
D132	9	D
D133	7	E
FL141	7	C
FL142	6	B
IC102	4	B
IC104	9	B
IC121	5	D
IC191	8	E
IC192	9	D
L111	2	A
Q101	3	D
Q102	3	D
Q103	4	D
Q111	2	B
Q112	2	C
Q113	1	C
Q114	1	A
Q121	5	D
Q123	7	D
Q131	8	C
Q132	6	B
Q133	7	D
Q134	7	E
R102	3	D
R103	3	D
R104	2	C
R105	3	D
R106	4	D
R107	4	D
R108	4	D
R109	3	C
R110	1	A
R111	3	B
R112	2	D
R113	2	D
R114	2	C
R115	1	C
R116	1	B
R119	2	D
R121	6	D
R122	5	E
R124	5	E
R126	5	C
R127	4	E
R128	5	E
R129	3	E
R130	6	E
R131	5	D
R132	4	D
R133	6	C
R134	6	E
R137	7	D
R138	5	B
R139	5	B
R140	4	A
R141	4	C
R142	5	C
R143	5	C
R144	5	C
R145	5	B
R146	3	B
R147	3	B
R148	3	B
R149	3	B
R150	4	C
R151	8	C
R152	8	B
R153	8	B
R155	8	C
R156	9	C
R157	6	B
R158	6	B
R159	7	C
R160	7	C
R161	7	C
R162	6	C
R163	6	B
R164	6	B
R165	6	B
R166	6	B
R167	7	E
R168	7	E
R170	9	B
R171	9	B
R172	8	B
R173	9	B
R176	9	C
R177	10	C
R178	9	B
R179	9	A
R181	7	D
R182	7	B
R183	7	B
R184	6	D
R191	10	D
RF101	2	E
T111	2	B
T141	4	C
T142	4	C
T151	8	A
TC101	8	B
X121	5	D
X191	10	D
X192	8	E

P1-76-a P1-76-b P1-76-c

CA-D661T

■ CD Servo Board (ENN-488)



■ IC301 µcom Modify Board (END-107)



■ Changer Mechanism Board (VMW1377)



■ CD Servo Board (ENN-488)




CN112
CN113
C681
C683
R681
C684
C666
R802
R801
R803
C685
R804
R805
R806
R807
C667
C686
C668
CN506
C669
C687
C682
C688
CN515
CN514
CN615
C699
D600
R670
FW601
FW712
FW600
Q610
C811
WM-3737/3747

r Mechanism Board (VMW1377)



PARTS LIST

* All printed circuit boards and its assemblies are not available as service parts.

The Marks for Designated Areas
J ・・・ the U.S.A.
C ・・・ Canada
No marks indicates all areas.

- Contents -

General Exploded View and Parts List ・・・・・・・・・・・・・・・・・・ 2-3
CD Changer Mechanism Ass'y and Parts List ・・・・・・・・・・・・・・・・ 2-5
■ Grease Point ・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-5
CD Mechanism Ass'y and Parts List ・・・・・・・・・・・・・・・・・・・・ 2-7
■ Grease Point ・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-7
Cassette Mechanism Ass'y and Parts List ・・・・・・・・・・・・・・・・・ 2-8
■ Grease Point ・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-8
Electrical Parts List ・・・・・・・・・・・・・・・・・・・・・・・・・ 2-10
(ENH-302) ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-10
(ENB-248) ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-12
(ENC-136) ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-14
(ENN-488) ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-17
(ENA-178) ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-18
(END-107) ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-19
(C3 Mecha.) ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-19
Accessories List ・・・・・・・・・・・・・・・・・・・・・・・・・・・・ 2-20
Packing Materials and Part Numbers ・・・・・・・・・・・・・・・・・・・ 2-21

General Exploded View and Parts List




47
49
48
36
58
36
85
87
50
97
57
52
56
20
96
36
59
91
90
89
16
88
53
55
36
14
15
6
88
4
5
ENB-248-1
ENB-248-2
93
16
12
41
7
13
1-1
39
8
40
1-2
11
10
9
31
*
18
92
3
23
25
35
17
1
19
30
31
24
26
16
END-107
2
20
21
22
63

■ Parts List

Block No. M1MM

⚠	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	EFP-CAD661TJ(S)	FRONT PANEL ASSY	1		
	1-1	E103259-010SM	FRONT PANEL	1		
	1-2	E406971-221	JVC MARK	1		
	2	E75896-001	SPACER	2		
	3	E209142-016SM	WINDOW SCREEN	1		
	4	E209144-001SM	PUSH BUTTON	1	SOUND	
	5	E310199-001SM	SELECT KNOB	1		
	6	E310192-001SM	PUSH BUTTON	1	DISC	
	7	E310189-001SM	INDICATOR LENS	1	JOY	
	8	E310194-001SM	PUSH BUTTON	1	SURR. ON/OFF	
	9	E409555-001SM	INDICATOR LENS	1	STANDBY	
	10	E310191-001SM	INDICATOR LENS	1	REC. A/B	
	11	E209146-001SM	PUSH BUTTON ASSY	1		
	12	E209149-001SM	PUSH BUTTON	1	SOURCE	
	13	E310190-001SM	PUSH BUTTON	1	DEMO	
	14	VWF1225-20TTB	FLAT WIRE	1		
	15	VWF1216-13TTB	FLAT WIRE ASSY	1		
	16	SDSF2608Z	SCREW	20		
	17	E310196-001SM	EJECT BUTTON	1		
	18	E310197-001SM	EJECT BUTTON	1		
	19	E208588-002SM	HOLDER BRACKET	1		
	20	SBSG3008Z	TAPPING SCREW	11		
	21	E103261-003SM	CASSETTE HOLDER	1		
	22	E209151-001SM	CASSETTE LENS	1		
	23	E406713-001	CASS.SPRING	4		
	24	E310204-001SM	INDICATOR LENS	2		
	25	E103263-003SM	CASSETTE HOLDER	1		
	26	E209152-001SM	CASSETTE LENS	1		
	29	E408933-001	HOLDER SPRING	1		
	30	E408934-001	HOLDER SPRING	1		
	31	VYH7779-00D	DAMPER	2		
	32	E309477-222	EJECT SAFETY	1		
	33	E309478-222	EJECT SAFETY	1		
	34	E407801-002	SPRING	1		
	35	E407802-002	SPRING	1		
	36	SBSF3008Z	TAPPING SCREW	12		
		SBSF3008Z	TAPPING SCREW	13		J
	37	----------	CASSETTE MECHANISM ASSY	1		
	38	SBST3006Z	TAPPING SCREW	4		
	39	E309479-001SS	EJECT LEVER	1		
	40	E309480-001SS	EJECT LEVER	1		
	41	E408742-001SS	SPRING	1		
	42	SBST2604Z	SCREW	2		
	43	VWF1217-10TTB	FLAT WIRE	1		
	44	----------	CD CHANGER MECHANISM ASSY	1		
	45	----------	CD MECHANISM ASS'Y	1		
	46	FMYH4003-001	INSULATOR	2		
	47	FMYH4003-002	INSULATOR	2		
	48	VKS3703-00FMM	CLAMPER ASSY	1		
	49	SPST2606Z	TAPPING SCREW	1		
	50	VKW5187-001	ROD	1		
	51	QUQ110-1509AJ	FLAT WIRE	1		
	52	VDM1001-M001A	SOCKET WIRE ASSY	1		
	53	VWF1207-07TTB	FLAT WIRE	1		

■ Parts List

Block No. M1MM

⚠	Item	Parts Number	Parts Name	Q'ty	Description	Area
	54	VWF1210-27TTB	FLAT WIRE ASSY	1	CN801-CN811	
	55	VWF1211-22TTB	FLAT WIRE ASSY	1		
	56	VYSA1R2-033	SPACER	1		
	57	E309662-001	DISK STOPPER	1		
	58	FMKL4008-001	LOD STOPPER	1		J
	59	E310198-001SM	P.W.BOARD BRACKET	1		
	60	E102616-230SM	CHASSIS BASE	1		
	61	E75896-006	FELT SPACER	2		
	62	E310075-001	COVER	1		
	63	SBST3008Z	TAPPING SCREW	2		
	64	E309789-001SM	HEAT SINK	1		
	65	E406969-002SM	SIDE BRACKET	1		
	66	FMPK4003-001	MICA SHEET	1		
	67	FMKL4007-001	HEAT SINK BRACKET	1		
	68	FMPK4004-001	MICA SHEET	1		
	69	SBSG3014CC	SCREW	6		
	70	JCE8005	TRANSISTOR KIT	1	Q757,Q758	
	72	QQT0156-001	POWER TRANSFORMER	1		
	73	E409015-001SM	SHIELD PLATE	1		
	74	E65389-002	SPECIAL SCREW	4		
⚠	75	QMF0007-4R0J1	FUSE	2	F101,102(T4.0A/125V)	
⚠	77	QMF0007-3R15J1	FUSE	1	F001(T3.15A/125V)	
	80	LE40252-201A	PROTECT SHEET	1		
	81	E310243-002	PLASTIC RIVET	2		
⚠	82	QMP1D00-200H	POWER CORD	1		
⚠	83	QHS3876-162	CORD STOPPER	1		
	84	E103265-010SM	REAR PANEL	1		J
		E103265-011SM	REAR PANEL	1		C
	85	E73273-003	SPECIAL SCREW	19		
	86	E207356-002SM	REAR COVER	1		
	87	E103267-003SM	METAL COVER	1		
	88	SDSG3006M	TAPPING SCREW	2		
	89	E209153-001SM	CD FITTING	1	DISC 1	
	90	E209155-001SM	CD FITTING	1	DISC 2	
	91	E209157-001SM	CD FITTING	1	DISC 3	
	92	E310080-224SM	VOLUME KNOB	1		
	93	E310195-001SM	STAY BRACKET	1		
	94	GBSG3008CC	SCREW	3		
	95	EX0150010H09S11	FELT SPACER	1		
	96	VKS2250-003	TOP BRACKET	1		
	97	SBSF2608Z	SCREW	3		
	-	E307570-001	NUMBER LABEL	1		J
		E406709-001	CAUTION LABEL	1		C

CD Changer Mechanism Ass'y and Parts List

■ Grease Point

Block No. M2MM



■ Parts List (Changer Mechanism Ass'y)

Block No. M2MM

⚠	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	VKS1144-003	CHASSIS BASE	1		
	2	VKS3698-003	TRAY GUIDE	2		
	3	VKS5532-003	PULLEY GEAR	2		
	4	VKB3000-164	DRIVE BELT	2		
	5	VKS5505-003	GEAR B	2		
	6	VKS5506-002	GEAR C	3		
	7	VKS5507-002	CROSS GEAR U	1		
	8	VKS5508-002	CROSS GEAR L	1		
	9	VKS5510-003	SELECT LEVER	1		
	10	VKH5769-001	GEAR STUD	1		
	11	VKS5511-002	SELECT GEAR	1		
	12	VKW5155-003	COMPRESS SPRING	1		
	13	VKM3846-002	GEAR BRACKET	1		
	14	VKS5509-002MM	CYLINDER GEAR	1		
	15	MSN5D257A-SA2	DC MOTOR ASSY	2		
	16	DPSP2616Z	SCREW	2		
	18	VKM3825-00A	CAM GEAR BASE ASSY	1		
	19	VKZ3172-00A	CAM SWITCH ASSY	1		
	20	VKZ3173-00A	CAM SWITCH ASSY	1		
	21	SPST2606Z	TAPPING SCREW	3		
	22	VKS2263-002MM	CAM R1	1		
	23	VKS2264-002MM	CAM R2	1		
	24	VKS2265-002MM	CAM GEAR L	1		
	25	WDL316050	SLIT WASHER	2		
	27	SBSF2608Z	TAPPING SCREW	15		
	28	VKS3702-00FMM	DRIVE UNIT	1		
	29	VKS2247-004	MECHA. HOLDER A	1		
	30	VKL7767-00B	MECHA. BRACKET ASSY	1		
	31	SBSF2606Z	TAPPING SCREW	3		
	32	VKM3860-00A	MECHA. HOLDER ASSY	1		
	33	VKL7802-00C	MECHA. HOLDER ASSY	1		
	34	SDST2604Z	SCREW	2		
	35	VKL7810-00A	LIFTER	1		
	36	VKL7811-00A	LIFTER	1		
	37	VKL7812-00A	LIFTER	1		
	38	VKL2732-002	LIFTER BASE	1		
	39	VKM3823-001	LIFTER BRACKET	1		
	40	SDST2604Z	SCREW	1		
	41	WDL266035-2	SLIT WASHER	1		
	43	VKS5514-002MM	LOCK LEVER	3		
	44	VKY3133-002MM	RETURN SPRING	1		
	46	VKY3134-003	SPRING	1		
	47	VKS2252-00D	TRAY ASSY	3		
	48	VKS2250-003	TOP BRACKET	1		
	49	VKS5515-002	S.TRAY STOPPER	1		
	50	VKW5156-004	TORSION SPRING	1		
	51	VKS3703-00FMM	CLAMPER ASSY	1		
	69	VMC0325-010	CONNECTOR	1		

CD Mechanism Ass'y and Parts List

Block No. M3MM

■ Grease Point



■ Parts List (CD Mechanism Ass'y)

⚠	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	EPB-002PK	MECHA. BASE ASSY	1		
	2	OPTIMA-150S	OPTICAL PICK UP	1		
	3	E406777-001	CD SHAFT	1		
	4	E307746-001	CD RACK	1		
	5	E307745-221SS	MECHA GEAR	1		
	6	SDSP2003N	SCREW	3		
	7	E406750-001	PINION GEAR	1		
	8	EPB309173A	TURN TABLE	1		
	9	E406784-001	FEED MOTOR	1		
	10	E406783-001	SPINDLE MOTOR	1		
	11	EMW10190-001(S)	P. C. BOARD	1		
	12	ESB1100-005	LEAF SWITCH	1		
	13	E75832-001	SCREW	1		
	14	EMV5109-006B	CONN. TERMINAL	1	6PIN	

Cassette Mechanism Ass'y and Parts List

■ Grease Point

Block No. M4MM



■ Parts List (Cassette Mechanism Ass'y)

Block No. M4MM

⚠	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	VKM3835-00A	FLYWHEEL BRACKET	1		
	2	MMI-6H2LWK	DC MOTOR	1		
	3	VKR4740-003	MOTOR PULLEY	1		
	4	SPSP2603Z	WOOD SCREW	2		
	5	VKW5177-002	SPRING	1		
	6	VKS5524-001	THRUST GUIDE	1		
	7	VKR4741-002	IDLER PULLEY	1		
	8	VKF3202-00A	F.WHEEL (L) ASY	2		
	9	VKF3200-00A	F.WHEEL (R) ASY	2		
	10	VKB3000-161	CAPSTAN BELT	1		
	11	VKB3000-162	CAPSTAN BELT	1		
	12	VKS5523-00C	MAIN PULLY ASSY	2		
	13	VKB3000-167	REEL BELT	2		
	14	VKS1150-001	CONTROL CAM	2		
	15	VKW5170-002	SPRING	2		
	16	SBSF2608Z	TAPPING SCREW	6		
	17	VKS3719-001	RING	2		
	18	VKS5525-00B	TRIGGER ARM ASSY	2		
	19	VKS1151-00A	CHASSIS BASE ASSY	2		
	20	VGP2401-00A	SOLENOID ASSY	2		
	21	SDST2612Z	SCREW	2		
	22	VKS3714-00B	F.F/REW.ARM	2		
	23	VKW5173-001	SPRING	2		
	24	VKW5202-002	SPRING	2		
	25	VKS5519-002	IDLER GEAR	2		
	26	VKZ4690-002	MAGNET	2		
	27	VKS3707-002	REEL GEAR	2		
	28	VKW5162-002	SPRING	4		
	29	VKS3708-002	REEL CAP	4		
	30	VKS2261-002	REEL STOPPER	2		
	31	VKW5178-001	BRAKE SPRING	2		
	32	VKS2255-001	DIRECTION LEVER	2		
	33	VKW5163-001	SPRING	2		
	34	VKP4232-00B	PINCH ROLLER	2		
	35	VKP4231-00B	PINCH ROLLER	4		
	36	VKY4670-001	CASSETTE SPRING	2		
	40	VKM3834-00F	HEAD MOUNT ASSY	1	A Mecha.	
		VKM3832-00F	HEAD MOUNT ASSY	1	B Mecha.	
	46	MXS00220MVL0	CASSETTE SWITCH	7		
	47	DN6851-HI	I.C(M)	2		
	48	VKS3630-001MM	I.C.PROTECTOR	2		
	49	VMC0314-P08	CONNECT TERMINAL	1	A Mecha.	
		VMC0314-P14	CONNECT TERMINAL	1	B Mecha.	
	50	QSEC001-E03	LEVER SWITCH	2		
	51	1SR139-400	SI DIODE	2		
	52	VWSC04-11A13K	FLAT WIRE ASSY	1		

■ Electrical Parts List (ENH-302)

⚠	Item	Parts Number	Description	Area
		I.C.S		
	IC701	TDA7294	I.C(M)	
	IC702	TDA7294	I.C(M)	
		DIODES		
	D001	1N5402M-20	DIODE	
	D002	1N5402M-20	DIODE	
	D003	1N5402M-20	DIODE	
	D004	1N5402M-20	DIODE	
	D011	30D2FC	GE.DIODE	
	D012	30D2FC	GE.DIODE	
	D013	30D2FC	GE.DIODE	
	D014	30D2FC	GE.DIODE	
	D015	30D2FC	GE.DIODE	
	D016	30D2FC	GE.DIODE	
	D017	1SR35-100	SI.DIODE	
	D018	1SR35-100	SI.DIODE	
	D019	MTZ30JC	ZENER DIODE	
	D020	MTZ5.6JC	ZENER DIODE	
	D021	MTZ5.1JB	ZENER DIODE	
	D022	1SS133	SI.DIODE	
	D023	1SS133	SI.DIODE	
	D024	1SS133	SI.DIODE	
	D025	1SS133	SI.DIODE	
	D027	1SR35-100	SI.DIODE	
	D030	MTZ9.1JC	ZENER DIODE	
	D060	MTZ5.1JB	ZENER DIODE	
	D061	MTZ11JC	ZENER DIODE	
	D062	MTZ13JC	ZENER DIODE	
	D063	MTZ11JC	ZENER DIODE	
	D064	MTZ13JC	ZENER DIODE	
	D065	MTZ8.2JC	ZENER DIODE	
	D066	MTZ13JC	ZENER DIODE	
	D067	MTZ13JC	ZENER DIODE	
	D068	MTZ13JC	ZENER DIODE	
	D069	MTZ13JC	ZENER DIODE	
	D070	MTZ13JC	ZENER DIODE	
	D703	1SS133	SI.DIODE	
	D704	1SS133	SI.DIODE	
	D719	1SS133	SI.DIODE	
	D720	1SS133	SI.DIODE	
	D728	1SS133	SI.DIODE	
	D751	1SS133	SI.DIODE	
	D752	1SS133	SI.DIODE	
	D753	1SS133	SI.DIODE	
	D754	1SS133	SI.DIODE	
	D755	1SS133	SI.DIODE	
	D756	1SS133	SI.DIODE	
	D757	MTZ3.9JB	ZENER DIODE	
	D758	MTZ3.9JB	ZENER DIODE	
	D759	1SS133	SI.DIODE	
	D760	1SS133	SI.DIODE	
	D1060	MTZ2.4JB	ZENER DIODE	
		TRANSISTORS		
	Q001	2SB1187(F,G)	SI.TRANSISTOR	
	Q003	KRC107M-T	DIGITAL TRANSISTOR	
	Q004	KRC107M-T	DIGITAL TRANSISTOR	
	Q005	KRC102M-T	DIGITAL TRANSISTOR	
	Q040	2SC945A	SI.TRANSISTOR	
	Q060	2SD2061(F,G)	SI.TRANSISTOR	
	Q061	2SC945A	SI.TRANSISTOR	
	Q062	2SC945A	SI.TRANSISTOR	
	Q063	2SD2061(F,G)	SI.TRANSISTOR	
	Q064	2SA933S(RS)	SI.TRANSISTOR	
	Q065	2SC945A	SI.TRANSISTOR	
	Q066	2SD2061(F,G)	SI.TRANSISTOR	
	Q067	2SA933S(RS)	SI.TRANSISTOR	
	Q068	2SC945A	SI.TRANSISTOR	
	Q069	2SD2061(F,G)	SI.TRANSISTOR	
	Q070	2SC945A	SI.TRANSISTOR	
	Q071	2SB1187(F,G)	SI.TRANSISTOR	
	Q072	2SA933S(RS)	SI.TRANSISTOR	
	Q073	KRA104M-T	DIGITAL TRANSISTOR	
	Q074	DTC144ES	DIGITAL TRANSISTOR	
	Q075	KRC104M-T	DIGITAL TRANSISTOR	
	Q076	DTA144ES	DIGITAL TRANSISTOR	
	Q701	2SA1038(R,S)	SI.TRANSISTOR	

⚠	Item	Parts Number	Description	Area
	Q702	2SA1038(R,S)	SI.TRANSISTOR	
	Q726	2SC2389(S,E)	SI.TRANSISTOR	
	Q727	2SA1038(R,S)	SI.TRANSISTOR	
	Q728	2SC1740S(R,S)	SI.TRANSISTOR	
	Q733	2SD2144S(VW)	SI.TRANSISTOR	
	Q734	2SD2144S(VW)	SI.TRANSISTOR	
	Q735	2SD2144S(VW)	SI.TRANSISTOR	
	Q736	2SD2144S(VW)	SI.TRANSISTOR	
	Q737	KRA111M-T	DIGITAL TRANSISTOR	
	Q751	2SC1685	SI.TRANSISTOR	
	Q752	2SA933S(RS)	SI.TRANSISTOR	
	Q753	2SC1685	SI.TRANSISTOR	
	Q754	2SA933S(RS)	SI.TRANSISTOR	
	Q755	2SA965(Y)	SI.TRANSISTOR	
	Q756	2SC2235(O,Y)	SI.TRANSISTOR	
	Q1057	2SK301(P,Q)	F.E.T.	
		CAPACITORS		
	C001	QFV82AJ-104	0.1MF 100V THIN FILM CAP.	
	C002	QFV82AJ-104	0.1MF 100V THIN FILM CAP.	
	C003	QFV82AJ-104	0.1MF 100V THIN FILM CAP.	
	C004	QETM1HM-228	2200MF 50V E.CAP.	
	C005	QETM1HM-228	2200MF 50V E.CAP.	
	C011	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	
	C012	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	
	C013	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	
	C014	QETM1VM-228J7	2200MF 35V E.CAP.	
	C015	QETM1VM-228J7	2200MF 35V E.CAP.	
	C016	QETN1VM-107Z	100MF 35V E.CAP.	
	C017	QETN1JM-476Z	47MF 63V E.CAP.	
	C018	QETN1HM-226Z	22MF 50V AL E.CAP.	
	C019	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C020	QETN1HM-226Z	22MF 50V AL E.CAP.	
	C021	QETN1HM-475Z	4.7MF 50V AL E.CAP.	
	C022	QETN1HM-475Z	4.7MF 50V AL E.CAP.	
	C023	QETN1HM-225Z	2.2MF 50V AL E.CAP.	
	C024	QETN1EM-106Z	10MF 25V E.CAP.	
	C032	QETN1AM-477Z	470MF 10V E.CAP.	
	C033	QFLB1HJ-103	0.01MF 50V MYLAR CAP.	
	C060	QETN1EM-226Z	22MF 25V E.CAP.	
	C061	QCF21HP-103A	0.01MF 50V CER.CAP.	
	C062	QETN1EM-226Z	22MF 25V E.CAP.	
	C063	QETN1EM-226Z	22MF 25V E.CAP.	
	C064	QCF21HP-103A	0.01MF 50V CER.CAP.	
	C065	QETN1EM-226Z	22MF 25V E.CAP.	
	C066	QETN1EM-226Z	22MF 25V E.CAP.	
	C067	QCF21HP-103A	0.01MF 50V CER.CAP.	
	C068	QETN1EM-226Z	22MF 25V E.CAP.	
	C069	QETN1EM-226Z	22MF 25V E.CAP.	
	C070	QCF21HP-103A	0.01MF 50V CER.CAP.	
	C071	QETN1EM-226Z	22MF 25V E.CAP.	
	C072	QETN1EM-226Z	22MF 25V E.CAP.	
	C073	QCF21HP-103A	0.01MF 50V CER.CAP.	
	C074	QETN1EM-226Z	22MF 25V E.CAP.	
	C103	QFLB1HJ-103	0.01MF 50V MYLAR CAP.	
	C703	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C704	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C705	QCBB1HK-181Y	180PF 50V CER.CAP.	
	C706	QCBB1HK-181Y	180PF 50V CER.CAP.	
	C707	QETN1EM-476Z	47MF 25V E.CAP.	
	C708	QETN1EM-476Z	47MF 25V E.CAP.	
	C709	QCSB1HJ-100Y	10PF 50V CER.CAP.	
	C710	QCSB1HJ-100Y	10PF 50V CER.CAP.	
	C711	QETN1HM-226Z	22MF 50V AL E.CAP.	
	C712	QETN1HM-226Z	22MF 50V AL E.CAP.	
	C713	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	C
	C714	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	C
	C715	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	C
	C716	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	C
	C717	QFLB1HJ-473	0.047MF 50V MYLAR CAP.	J
	C718	QFLB1HJ-473	0.047MF 50V MYLAR CAP.	J
	C721	QETN1HM-225Z	2.2MF 50V AL E.CAP.	
	C722	QETN1HM-225Z	2.2MF 50V AL E.CAP.	
	C726	QETN1EM-106Z	10MF 25V E.CAP.	
	C729	QETN1CM-476Z	47MF 16V AL E.CAP.	
	C751	QCY31HK-272Z	2700PF 50V CER.CAP.	
	C752	QCY31HK-272Z	2700PF 50V CER.CAP.	

■ Electrical Parts List (ENH-302)

⚠	Item	Parts Number	Description	Area
	C753	QCY31HK-472Z	4700PF 50V CER. CAP.	
	C754	QCY31HK-472Z	4700PF 50V CER. CAP.	
	C755	QFV81HJ-105	1MF 50V THIN FILM CAP.	
	C756	QFV81HJ-105	1MF 50V THIN FILM CAP.	
	C757	QCXB1CM-152Y	1500PF 16V CER. CAP.	
	C758	QCXB1CM-152Y	1500PF 16V CER. CAP.	
	C799	QCVB1CM-103Y	0.01MF 16V CER. CAP.	
	C1017	QFLB1HJ-823	0.082MF 50V MYLAR CAP.	
	C1018	QETN1HM-224Z	0.22MF 50V AL E. CAP.	
		RESISTORS		
⚠	R001	QRC128K-275EM	2.7M 1/2W COMPOSITION	
	R002	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON R	J
	R003	QRD167J-332	3.3K 1/6W CARBON RES.	
	R004	QRD167J-223	22K 1/6W CARBON RES.	
	R005	QRD161J-104	100K 1/6W CARBON RES.	
⚠	R006	QRD14CJ-2R2SX	2.2 1/4W UNF. CARBON R	
	R008	QRD161J-103	10K 1/6W CARBON RES.	
	R009	QRD161J-103	10K 1/6W CARBON RES.	
	R010	QRD161J-472	4.7K 1/6W CARBON RES.	
	R011	QRD161J-102	1K 1/6W CARBON RES.	
	R012	QRD167J-223	22K 1/6W CARBON RES.	
	R013	QRD161J-103	10K 1/6W CARBON RES.	
	R014	QRD161J-104	100K 1/6W CARBON RES.	
⚠	R030	QRD14CJ-221S	220 1/4W UNF. CARBON R	
	R040	QRD12CJ-471SX	470 1/2W UNF. CARBON R	
	R041	QRD12CJ-471SX	470 1/2W UNF. CARBON R	
	R042	QRD161J-222	2.2K 1/6W CARBON RES.	
	R045	QRD161J-222	2.2K 1/6W CARBON RES.	
	R060	QRG01DJ-180X	18 1W OXIDE METAL	
	R061	QRG01DJ-180X	18 1W OXIDE METAL	
	R062	QRD161J-331	330 1/6W CARBON RES.	
	R063	QRD161J-331	330 1/6W CARBON RES.	
	R064	QRD161J-122	1.2K 1/6W CARBON RES.	
	R065	QRD161J-561	560 1/6W CARBON RES.	
	R066	QRD161J-561	560 1/6W CARBON RES.	
	R067	QRD161J-122	1.2K 1/6W CARBON RES.	
	R068	QRD161J-331	330 1/6W CARBON RES.	
⚠	R069	QRD125J-220	22 1/2W UNF. CARBON R	
⚠	R070	QRD12CJ-330S	33 1/2W UNF. CARBON R	
	R071	QRD161J-221	220 1/6W CARBON RES.	
	R072	QRD161J-681	680 1/6W CARBON RES.	
	R073	QRD161J-182	1.8K 1/6W CARBON RES.	
⚠	R074	QRD125J-180	18 1/2W UNF. CARBON R	
⚠	R075	QRD125J-220	22 1/2W UNF. CARBON R	
	R076	QRD161J-221	220 1/6W CARBON RES.	
	R077	QRD161J-681	680 1/6W CARBON RES.	
	R078	QRD161J-182	1.8K 1/6W CARBON RES.	
	R079	QRG022J-120A	12 2W OXIDE METAL	
	R081	QRD167J-272	2.7K 1/6W CARBON RES.	
	R082	QRD167J-562	5.6K 1/6W CARBON RES.	
	R083	QRG01DJ-150X	15 1W O.M.FILM	
	R084	QRD167J-272	2.7K 1/6W CARBON RES.	
	R085	QRD167J-562	5.6K 1/6W CARBON RES.	
⚠	R701	QRD14CJ-100SX	10 1/4W UNF. CARBON R	
⚠	R702	QRD14CJ-100SX	10 1/4W UNF. CARBON R	
	R703	QRD161J-563	56K 1/6W CARBON RES.	
	R704	QRD161J-563	56K 1/6W CARBON RES.	
⚠	R705	QRD14CJ-182SX	1.8K 1/4W UNF. CARBON R	
⚠	R706	QRD14CJ-182SX	1.8K 1/4W UNF. CARBON R	
	R707	QRD161J-563	56K 1/6W CARBON RES.	
	R708	QRD161J-563	56K 1/6W CARBON RES.	
⚠	R709	QRX014J-R22	0.22 1W METAL FILM R	
⚠	R710	QRX014J-R22	0.22 1W METAL FILM R	
⚠	R711	QRX014J-R22	0.22 1W METAL FILM R	
⚠	R712	QRX014J-R22	0.22 1W METAL FILM R	
⚠	R713	QRD14CJ-100SX	10 1/4W UNF. CARBON R	
⚠	R714	QRD14CJ-100SX	10 1/4W UNF. CARBON R	
⚠	R715	QRD14CJ-100SX	10 1/4W UNF. CARBON R	
⚠	R716	QRD14CJ-100SX	10 1/4W UNF. CARBON R	
	R717	QRD161J-122	1.2K 1/6W CARBON RES.	
	R718	QRD161J-122	1.2K 1/6W CARBON RES.	
	R719	QRD167J-223	22K 1/6W CARBON RES.	
	R720	QRD167J-223	22K 1/6W CARBON RES.	
	R721	QRD161J-103	10K 1/6W CARBON RES.	
	R722	QRD161J-103	10K 1/6W CARBON RES.	
	R723	QRD161J-473	47K 1/6W CARBON RES.	

⚠	Item	Parts Number	Description	Area
	R724	QRD161J-473	47K 1/6W CARBON RES.	
	R725	QRD161J-104	100K 1/6W CARBON RES.	
	R726	QRD161J-823	82K 1/6W CARBON RES.	
	R727	QRD161J-104	100K 1/6W CARBON RES.	
	R728	QRD161J-103	10K 1/6W CARBON RES.	
	R729	QRD161J-104	100K 1/6W CARBON RES.	
	R730	QRD161J-103	10K 1/6W CARBON RES.	
	R733	QRD161J-473	47K 1/6W CARBON RES.	
	R734	QRD161J-473	47K 1/6W CARBON RES.	
	R735	QRD161J-473	47K 1/6W CARBON RES.	
	R736	QRD161J-473	47K 1/6W CARBON RES.	
	R739	QRG01DJ-821X	820 1W OXIDE METAL	
	R740	QRG01DJ-821X	820 1W OXIDE METAL	
	R751	QRD167J-223	22K 1/6W CARBON RES.	
	R752	QRD167J-223	22K 1/6W CARBON RES.	
	R753	QRD161J-222	2.2K 1/6W CARBON RES.	
	R754	QRD161J-222	2.2K 1/6W CARBON RES.	
	R755	QRD161J-221	220 1/6W CARBON RES.	
	R756	QRD161J-221	220 1/6W CARBON RES.	
	R757	QRD167J-223	22K 1/6W CARBON RES.	
	R758	QRD167J-223	22K 1/6W CARBON RES.	
	R759	QRD167J-682	6.8K 1/6W CARBON RES.	
	R760	QRD167J-682	6.8K 1/6W CARBON RES.	
	R761	QRD161J-222	2.2K 1/6W CARBON RES.	
	R762	QRD161J-222	2.2K 1/6W CARBON RES.	
	R763	QRD167J-223	22K 1/6W CARBON RES.	
	R764	QRD167J-223	22K 1/6W CARBON RES.	
	R765	QRG01DJ-182X	1.8K 1W OXIDE METAL	
	R766	QRG01DJ-182X	1.8K 1W OXIDE METAL	
⚠	R767	QRD14CJ-681SX	680 1/4W UNF. CARBON R	
⚠	R768	QRD14CJ-681SX	680 1/4W UNF. CARBON R	
	R769	QRD14CJ-821SX	820 1/4W CARBON RES.	
	R770	QRD14CJ-821SX	820 1/4W CARBON RES.	
	R771	QRD161J-821	820 1/6W CARBON RES.	
	R772	QRD161J-821	820 1/6W CARBON RES.	
⚠	R773	QRD14CJ-101S	100 1/4W UNF. CARBON R	
⚠	R774	QRD14CJ-101S	100 1/4W UNF. CARBON R	
	R775	QRD161J-471	470 1/6W CARBON RES.	
	R776	QRD161J-471	470 1/6W CARBON RES.	
	R777	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON R	
	R778	QRD14CJ-4R7SX	4.7 1/4W UNF. CARBON R	
	R1056	QRD161J-392	3.9K 1/6W CARBON RES.	
	R1057	QRD161J-105	1M 1/6W CARBON RES.	
	R1058	QRD161J-475	4.7M 1/6W CARBON RES.	
	R1059	QRD161J-473	47K 1/6W CARBON RES.	
	R1060	QRD167J-153	15K 1/6W CARBON RES.	
		OTHERS		
		EMW10687-102	PRINTED BOARD	
		QWE880-12RR	VINYL WIRE	
	L701	EQL0011-R45J1	INDUCTOR	
	L702	EQL0011-R45J1	INDUCTOR	
	CN002	EMV7163-011	CONNECT TERMINAL	
	CN003	EMV7163-010	CONNECT TERMINAL	
	CN005	EMV7163-006	CONNECT TERMINAL	
	CN006	EMV7163-010	CONNECT TERMINAL	
	CN007	EMV7163-009	CONNECT TERMINAL	
	CN009	EMV5138-005	CONNECT TERMINAL	
	CN012	EMV5163-011R	CONNECT TERMINAL	
	CN013	EMV5163-010R	CONNECT TERMINAL	
	CN019	EWS285-002J	SOCKET WIRE ASSY	
	CN111	EMV7145-004Z	SOCKET ASSY	
	CN915	EMV7145-003Z	SOCKET ASSY	
	EP001	EMZ4002-002Z	EARTH PLATE	
	EP002	EMZ4002-002Z	EARTH PLATE	
	FT011	EMG7331-003Z	FUSE CLIP	
	FT012	EMG7331-003Z	FUSE CLIP	
	FT511	EMG7331-003Z	FUSE CLIP	
	FT512	EMG7331-003Z	FUSE CLIP	
	FT521	EMG7331-003Z	FUSE CLIP	
	FT522	EMG7331-003Z	FUSE CLIP	
	FW101	EWR34D-13LS	FLAT WIRE	
	FW401	EWR34D-16LS	FLAT WIRE	
	TB001	EMZ4001-002Z	TAB	
	TB002	EMZ4001-002Z	TAB	
	TH002	QAD0095-4R7Z	POSITIVE THERMISTOR	C
	TW799	EWT015-019	TERMINAL WIRE	

■ Electrical Part List (ENB-248)

⚠	Item	Parts Number	Description	Area
		I.C.S		
	IC231	HA12136A	I.C(MONO-ANALOG)	
	IC901	HD404719A71FS	I.C(MICRO-COMPUTER)	
	IC902	MN172412JAAW	I.C(MICRO-COMPUTER)	
	IC903	XR1099CP	I.C(MONO-ANALOG)	
	IC904	GP1U271X	INFRARED DETECT UNIT	
		DIODES		
	D041	1SS133	SI.DIODE	
	D231	1SR35-100	SI.DIODE	
	D232	SLR-342MCA47	L.E.D.	
	D233	SLR-342MCA47	L.E.D.	
	D234	SLR-342MCA47	L.E.D.	
	D235	SLR-342MCA47	L.E.D.	
	D236	SLR-342MCA47	L.E.D.	
	D237	SLR-342MCA47	L.E.D.	
	D801	MTZ2.4JB	ZENER DIODE	
	D802	SLR-342VC3F	L.E.D.	
	D803	SLR-342VC3F	L.E.D.	
	D804	SLR-342VC3F	L.E.D.	
	D805	SLR-342VC3F	L.E.D.	
	D806	SLR-342VC3F	L.E.D.	
	D901	1SS119	SI.DIODE	
	D902	1SS133	SI.DIODE	
	D904	SLR-342DCA47	L.E.D.	
	D905	SLR-342MCA47	L.E.D.	
	D906	SLR-342MCA47	L.E.D.	
	D907	SLR-342MCA47	L.E.D.	
	D908	SLR-342MCA47	L.E.D.	
	D909	SLR-342MCA47	L.E.D.	
	D910	SLR-342MCA47	L.E.D.	
	D911	SLR-342MCA47	L.E.D.	
	D912	SLR-342MCA47	L.E.D.	
	D917	SLR-342MCA47	L.E.D.	
	D918	SLR-342MCA47	L.E.D.	
	D919	SLR-342MCA47	L.E.D.	
	D920	1SS133	SI.DIODE	
	D921	1SS133	SI.DIODE	
	D922	1SS133	SI.DIODE	
	D923	MTZ5.6JC	ZENER DIODE	
	D924	MTZ5.6JC	ZENER DIODE	
	D925	MTZ5.6JC	ZENER DIODE	
	D932	1SS133	SI.DIODE	
	D933	1SS133	SI.DIODE	
	D934	1SS133	SI.DIODE	
	D935	1SS133	SI.DIODE	
	D941	MTZ5.1JB	ZENER DIODE	
		TRANSISTORS		
	Q231	2SA934(Q,R)	SI.TRANSISTOR	
	Q232	DTC123YS	SI.TRANSISTOR	
	Q233	2SA934(Q,R)	SI.TRANSISTOR	
	Q234	DTC123YS	SI.TRANSISTOR	
	Q235	2SA933S(RS)	SI.TRANSISTOR	
	Q236	KRC107M-T	DIGITAL TRANSISTOR	
	Q237	KRC107M-T	DIGITAL TRANSISTOR	
	Q901	KRC102M-T	DIGITAL TRANSISTOR	
	Q902	KRC102M-T	DIGITAL TRANSISTOR	
	Q903	KRC102M-T	DIGITAL TRANSISTOR	
	Q904	KRC102M-T	DIGITAL TRANSISTOR	
	Q921	KRC107M-T	DIGITAL TRANSISTOR	
	Q922	DTC114ES	DIGITAL TRANSISTOR	
	Q923	DTC114ES	DIGITAL TRANSISTOR	
	Q924	DTC114ES	DIGITAL TRANSISTOR	
	Q925	DTC114ES	DIGITAL TRANSISTOR	
		CAPACITORS		
	C051	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
	C052	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
	C053	QCXB1CM-222Y	2200PF 16V CER.CAP.	
	C054	QCXB1CM-222Y	2200PF 16V CER.CAP.	
	C055	QFLB1HJ-393	0.039MF 50V MYLAR CAP.	
	C056	QFLB1HJ-393	0.039MF 50V MYLAR CAP.	
	C233	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C234	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C235	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C236	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C237	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C238	QETC1HM-225ZM	2.2MF 50V E.CAP.	

⚠	Item	Parts Number	Description	Area
	C239	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C240	QCBB1HK-221Y	220PF 50V CER.CAP.	
	C241	QCBB1HK-221Y	220PF 50V CER.CAP.	
	C242	EETB1HM-475E	4.7MF 50V E.CAP.	
	C243	QFV81HJ-224	0.22MF 50V THIN FILM CAP.	
	C244	QFV81HJ-224	0.22MF 50V THIN FILM CAP.	
	C245	QCBB1HK-561Y	560PF 50V CER.CAP.	
	C246	QCBB1HK-561Y	560PF 50V CER.CAP.	
	C247	EETB1CM-476	47MF 16V E.CAP.	
	C251	QETN1CM-107Z	100MF 16V E.CAP.	
	C801	QCBB1HK-471Y	470PF 50V CER.CAP.	
	C802	QCBB1HK-471Y	470PF 50V CER.CAP.	
	C901	EETB1AM-107E	100MF 10V E.CAP.	
	C902	QCZ0205-155	1.5MF 25V C.CAP.	
	C903	QEADQHZ-479ZM	47000MF E.CAP.	
	C904	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C905	QER50JM-107	100MF 6.3V AL E.CAP.	
	C910	QCT26CH-330	33PF 50V CER.CAP.	
	C911	QEADQHZ-479ZM	47000MF E.CAP.	
	C912	EETB1AM-476E	47MF 10V E.CAP.	
	C914	QCZ0205-155	1.5MF 25V C.CAP.	
	C915	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C916	QER51HM-474G	0.47MF 50V AL E.CAP.	
	C921	QER50JM-107	100MF 6.3V AL E.CAP.	
	C922	QER50JM-107	100MF 6.3V AL E.CAP.	
	C923	QCGB1HK-102	1000PF 50V CER.CAP.	
	TC902	ENZ1003-015	0.1MF TRIMMER CAPA	
		RESISTORS		
	R047	QRD161J-333	33K 1/6W CARBON RES.	
	R048	QRD161J-333	33K 1/6W CARBON RES.	
	R049	QRD161J-102	1K 1/6W CARBON RES.	
	R051	QRD14CJ-4R7SX	4.7 1/4W UNF.CARBON R	
	R052	QRD14CJ-4R7SX	4.7 1/4W UNF.CARBON R	
	R235	QRD167J-153	15K 1/6W CARBON RES.	
	R236	QRD167J-153	15K 1/6W CARBON RES.	
	R237	QRD161J-681	680 1/6W CARBON RES.	
	R238	QRD161J-681	680 1/6W CARBON RES.	
⚠	R239	QRD14CJ-220S	22 1/4W UNF.CARBON R	
	R240	QRD161J-103	10K 1/6W CARBON RES.	
	R241	QRD161J-183	18K 1/6W CARBON RES.	
	R242	QRD161J-183	18K 1/6W CARBON RES.	
	R245	QRD167J-751	750 1/6W CARBON RES.	
	R246	QRD167J-751	750 1/6W CARBON RES.	
	R247	QRD161J-471	470 1/6W CARBON RES.	
⚠	R248	QRX022J-3R3A	3.3 2W METAL FILM R	
	R249	QRD161J-103	10K 1/6W CARBON RES.	
	R250	QRD161J-103	10K 1/6W CARBON RES.	
	R251	QRD161J-103	10K 1/6W CARBON RES.	
	R255	QRD167J-751	750 1/6W CARBON RES.	
	R256	QRD167J-751	750 1/6W CARBON RES.	
	R257	QRD161J-471	470 1/6W CARBON RES.	
⚠	R258	QRX022J-3R3A	3.3 2W METAL FILM R	
	R259	QRD161J-224	220K 1/6W CARBON RES.	
	R260	QRD161J-103	10K 1/6W CARBON RES.	
	R261	QRD161J-473	47K 1/6W CARBON RES.	
	R262	QRD161J-273	27K 1/6W CARBON RES.	
	R263	QRD161J-102	1K 1/6W CARBON RES.	
	R264	QRD161J-103	10K 1/6W CARBON RES.	
	R265	QRD161J-103	10K 1/6W CARBON RES.	
	R266	QRD161J-103	10K 1/6W CARBON RES.	
	R267	QRD161J-103	10K 1/6W CARBON RES.	
	R268	QRD161J-221	220 1/6W CARBON RES.	
	R269	QRD161J-221	220 1/6W CARBON RES.	
	R801	QRD167J-431	430 1/6W CARBON RES.	
	R802	QRD167J-431	430 1/6W CARBON RES.	
	R803	QRD161J-561	560 1/6W CARBON RES.	
	R804	QRD167J-751	750 1/6W CARBON RES.	
	R805	QRD161J-132	1.3K 1/6W CARBON RES.	
	R806	QRD161J-222	2.2K 1/6W CARBON RES.	
	R807	QRD167J-431	430 1/6W CARBON RES.	
	R808	QRD167J-431	430 1/6W CARBON RES.	
	R809	QRD161J-561	560 1/6W CARBON RES.	
	R810	QRD167J-751	750 1/6W CARBON RES.	
	R811	QRD161J-132	1.3K 1/6W CARBON RES.	
	R812	QRD161J-331	330 1/6W CARBON RES.	
	R813	QRD161J-331	330 1/6W CARBON RES.	

■ Electrical Part List (ENB-248)

⚠	Item	Parts Number	Description	Area
	R814	QRD161J-331	330 1/6W CARBON RES.	
	R815	QRD161J-331	330 1/6W CARBON RES.	
	R816	QRD161J-331	330 1/6W CARBON RES.	
	R817	QRD161J-103	10K 1/6W CARBON RES.	
	R818	QRD161J-103	10K 1/6W CARBON RES.	
	R900	QRD161J-103	10K 1/6W CARBON RES.	
	R901	QRD161J-105	1M 1/6W CARBON RES.	
	R902	QRD161J-103	10K 1/6W CARBON RES.	
	R903	QRD161J-220	22 1/6W CARBON RES.	
	R904	QRD161J-222	2.2K 1/6W CARBON RES.	
	R905	QRD161J-103	10K 1/6W CARBON RES.	
	R906	QRD161J-221	220 1/6W CARBON RES.	
	R907	QRD161J-221	220 1/6W CARBON RES.	
	R915	QRD161J-222	2.2K 1/6W CARBON RES.	
	R918	QRD167J-431	430 1/6W CARBON RES.	
	R919	QRD167J-431	430 1/6W CARBON RES.	
	R920	QRD161J-561	560 1/6W CARBON RES.	
	R921	QRD167J-751	750 1/6W CARBON RES.	
	R922	QRD161J-132	1.3K 1/6W CARBON RES.	
	R923	QRD161J-222	2.2K 1/6W CARBON RES.	
	R924	QRD161J-512	5.1K 1/6W CARBON RES.	
	R925	QRD167J-431	430 1/6W CARBON RES.	
	R926	QRD167J-431	430 1/6W CARBON RES.	
	R927	QRD161J-561	560 1/6W CARBON RES.	
	R928	QRD167J-751	750 1/6W CARBON RES.	
	R929	QRD161J-132	1.3K 1/6W CARBON RES.	
	R930	QRD161J-222	2.2K 1/6W CARBON RES.	
	R931	QRD161J-512	5.1K 1/6W CARBON RES.	
	R932	QRD167J-431	430 1/6W CARBON RES.	
	R933	QRD167J-431	430 1/6W CARBON RES.	
	R934	QRD161J-561	560 1/6W CARBON RES.	
	R935	QRD167J-751	750 1/6W CARBON RES.	
	R936	QRD161J-132	1.3K 1/6W CARBON RES.	
	R937	QRD161J-222	2.2K 1/6W CARBON RES.	
	R938	QRD161J-512	5.1K 1/6W CARBON RES.	
	R939	QRD167J-431	430 1/6W CARBON RES.	
	R944	QRD161J-181	180 1/6W CARBON RES.	
	R945	QRD161J-181	180 1/6W CARBON RES.	
	R946	QRD161J-181	180 1/6W CARBON RES.	
	R947	QRD161J-181	180 1/6W CARBON RES.	
	R948	QRD161J-181	180 1/6W CARBON RES.	
	R949	QRD161J-181	180 1/6W CARBON RES.	
	R950	QRD161J-181	180 1/6W CARBON RES.	
	R951	QRD161J-181	180 1/6W CARBON RES.	
	R952	QRD161J-181	180 1/6W CARBON RES.	
	R957	QRD161J-181	180 1/6W CARBON RES.	
	R958	QRD161J-181	180 1/6W CARBON RES.	
	R959	QRD161J-181	180 1/6W CARBON RES.	
	R960	QRD161J-102	1K 1/6W CARBON RES.	
	R961	QRD161J-221	220 1/6W CARBON RES.	
	R962	QRD161J-102	1K 1/6W CARBON RES.	
	R963	QRD161J-222	2.2K 1/6W CARBON RES.	
	R964	QRD161J-221	220 1/6W CARBON RES.	
	R965	QRD161J-221	220 1/6W CARBON RES.	
	R966	QRD161J-221	220 1/6W CARBON RES.	
	R967	QRD161J-221	220 1/6W CARBON RES.	
	R968	QRD161J-221	220 1/6W CARBON RES.	
	R970	QRD167J-223	22K 1/6W CARBON RES.	
	R971	QRD161J-472	4.7K 1/6W CARBON RES.	
	R972	QRD161J-472	4.7K 1/6W CARBON RES.	
	R973	QRD161J-472	4.7K 1/6W CARBON RES.	
	R974	QRD161J-472	4.7K 1/6W CARBON RES.	
	R975	QRD161J-473	47K 1/6W CARBON RES.	
	R976	QRD161J-104	100K 1/6W CARBON RES.	
	R977	QRD161J-104	100K 1/6W CARBON RES.	
	R978	QRD161J-104	100K 1/6W CARBON RES.	
	R979	QRD161J-104	100K 1/6W CARBON RES.	
	R980	QRD167J-562	5.6K 1/6W CARBON RES.	
	R981	QRD161J-331	330 1/6W CARBON RES.	
	R982	QRD161J-103	10K 1/6W CARBON RES.	
	R983	QRD161J-103	10K 1/6W CARBON RES.	
	R984	QRD161J-103	10K 1/6W CARBON RES.	
	R985	QRD167J-152	1.5K 1/6W CARBON RES.	
	R986	QRD161J-331	330 1/6W CARBON RES.	
	R987	QRD161J-103	10K 1/6W CARBON RES.	
	R989	QRD161J-103	10K 1/6W CARBON RES.	

⚠	Item	Parts Number	Description	Area
	RA901	QRB069J-222	2.2K 1/10WNETWORK RES.	
	VR233	QVPA603-103A	10K TRIMMER RES.	
		OTHERS		
		EMW10685-002	PRINTED BOARD	
	J081	EMB10TV-401AJ3	SPEAKER TERMINAL	
	J082	EMN00TV-119AJ4	PIN JACK	
	J801	QMS3R80-EE0S	HEADPHONE JACK	
	K801	ENZ8101-007	INDUCTOR	
	S801	ESP0001-023M	TACT SWITCH	
	S802	ESP0001-023M	TACT SWITCH	
	S803	ESP0001-023M	TACT SWITCH	
	S804	ESP0001-023M	TACT SWITCH	
	S805	ESP0001-023M	TACT SWITCH	
	S806	ESP0001-023M	TACT SWITCH	
	S807	ESP0001-023M	TACT SWITCH	
	S808	ESP0001-023M	TACT SWITCH	
	S809	ESP0001-023M	TACT SWITCH	
	S810	ESP0001-023M	TACT SWITCH	
	S811	ESP0001-023M	TACT SWITCH	
	S812	ESP0001-023M	TACT SWITCH	
	S813	ESP0001-023M	TACT SWITCH	
	S901	ESP0001-023M	TACT SWITCH	
	S902	ESP0001-023M	TACT SWITCH	
	S903	ESP0001-023M	TACT SWITCH	
	S904	ESP0001-023M	TACT SWITCH	
	S905	ESP0001-023M	TACT SWITCH	
	S906	ESP0001-023M	TACT SWITCH	
	S907	ESP0001-023M	TACT SWITCH	
	S908	ESP0001-023M	TACT SWITCH	
	S909	ESP0001-023M	TACT SWITCH	
	S910	ESP0001-023M	TACT SWITCH	
	S911	ESP0001-023M	TACT SWITCH	
	S912	ESP0001-023M	TACT SWITCH	
	S913	ESP0001-023M	TACT SWITCH	
	S914	ESP0001-023M	TACT SWITCH	
	S915	ESP0001-023M	TACT SWITCH	
	S916	ESP0001-023M	TACT SWITCH	
	S917	ESP0001-023M	TACT SWITCH	
	S918	ESP0001-023M	TACT SWITCH	
	S919	ESP0001-023M	TACT SWITCH	
	S920	ESP0001-023M	TACT SWITCH	
	S921	ESP0001-023M	TACT SWITCH	
	S922	ESP0001-023M	TACT SWITCH	
	S923	ESP0001-023M	TACT SWITCH	
	S924	ESP0001-023M	TACT SWITCH	
	S925	ESP0001-023M	TACT SWITCH	
	S926	ESP0001-023M	TACT SWITCH	
	X901	ECX0004-194KM	CERAMIC RESONATOR	
	X902	ECX0006-000KNJ	CRYSTAL	
	BK901	E309782-002SM	P.W.BOARD BRACKET	
	BK902	E310200-001SM	L.E.D.HOLDER	
	CN015	EMV5163-006R	CONNECT TERMINAL	
	CN101	EMV7163-012	CONNECT TERMINAL	
	CN121	EWS26C-A408	FLAT WIRE ASSY	
	CN301	EMV7172-014R	CONNECT TERMINAL	
	CN302	EMV7172-014R	CONNECT TERMINAL	
	CN313	VMC0314-S14	CONNECT TERMINAL	
	CN314	VMC0314-S08	CONNECT TERMINAL	
	CN401	VMC0163-R25	CONNECT TERMINAL	
	CN403	EMV7160-016	CONNECT TERMINAL	
	DI901	QLF0012-001	FLUORESCENT DISPLAY TUBE	
	FS901	E3400-439	FELT SPACER	
	FS902	E3400-439	FELT SPACER	
	FW401	VWSC12-083K3K	FLAT WIRE ASSY	
	FW402	EWR33D-25LS	FLAT WIRE	
	JS801	QSJ4003-E01	PUSH SWITCH	
	RY001	ESK7D24-213R	RELAY	
	SP901	VYH7653-001	LEAF SPRING	
	SP902	VYH7653-001	LEAF SPRING	
	TW001	EWT015-001	TERMINAL WIRE	
	TW003	EWT015-018	TERMINAL WIRE	
	TW333	QWE353-144K4K	WIRE	

■ Electrical Parts List (ENC-136)

⚠	Item	Parts Number	Description	Area
		I.C.S		
	IC301	MN173222JAAX1	I.C.	
	IC302	BA15218N	I.C(MONO-ANALOG)	
	IC303	BA15218N	I.C(MONO-ANALOG)	
	IC304	BA3126N	I.C(MONO-ANALOG)	
	IC305	HA12206NT	I.C(MONO-ANALOG)	
	IC401	TDA7439	I.C(M)	
	IC402	BA15218	I.C(MONO-ANALOG)	
	IC403	BA15218	I.C(MONO-ANALOG)	
	IC405	BA15218	I.C(MONO-ANALOG)	
	IC407	BA15218	I.C(MONO-ANALOG)	
		DIODES		
	D201	1SS133	SI.DIODE	
	D202	1SS133	SI.DIODE	
	D203	1SS133	SI.DIODE	
	D290	1SS133	SI.DIODE	
	D305	MTZ7.5JC	ZENER DIODE	
	D306	MTZ7.5JC	ZENER DIODE	
	D307	1SS133	SI.DIODE	
	D308	1SS133	SI.DIODE	
	D481	1SS133	SI.DIODE	
	D482	1SS133	SI.DIODE	
		TRANSISTORS		
	Q201	KRC107M-T	DIGITAL TRANSISTOR	
	Q321	2SD2144S(VW)	SI.TRANSISTOR	
	Q322	2SD2144S(VW)	SI.TRANSISTOR	
	Q323	KRA107M-T	DIGITAL TRANSISTOR	
	Q324	2SD2144S(VW)	SI.TRANSISTOR	
	Q325	2SD2144S(VW)	SI.TRANSISTOR	
	Q326	2SC1740S(R,S)	SI.TRANSISTOR	
	Q327	2SC1740S(R,S)	SI.TRANSISTOR	
	Q328	2SC1740S(R,S)	SI.TRANSISTOR	
	Q329	2SC1740S(R,S)	SI.TRANSISTOR	
	Q341	KRC107M-T	DIGITAL TRANSISTOR	
	Q342	KRC107M-T	DIGITAL TRANSISTOR	
	Q343	KRC107M-T	DIGITAL TRANSISTOR	
	Q401	2SD2144S(VW)	SI.TRANSISTOR	
	Q402	2SD2144S(VW)	SI.TRANSISTOR	
	Q403	KRA102M-T	DIGITAL TRANSISTOR	
	Q481	2SD2144S(VW)	SI.TRANSISTOR	
	Q482	2SD2144S(VW)	SI.TRANSISTOR	
	Q483	KRA102M-T	DIGITAL TRANSISTOR	
	Q491	KRC102M-T	DIGITAL TRANSISTOR	
	Q492	2SB1565(E,F)	SI.TRANSISTOR	
		CAPACITORS		
	C201	QETN1AM-227Z	220MF 10V E.CAP.	
	C202	QCZ0205-155	1.5MF 25V C.CAP.	
	C203	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C205	QCBB1HK-221Y	220PF 50V CER.CAP.	
	C206	QCBB1HK-221Y	220PF 50V CER.CAP.	
	C211	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C231	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C232	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C305	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C306	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C315	EETB1HM-105E	1MF 50V E.CAP.	
	C316	EETB1HM-105E	1MF 50V E.CAP.	
	C317	EETB1EM-106E	10MF 25V E.CAP.	
	C318	QETN1CM-107Z	100MF 16V E.CAP.	
	C320	QFLB1HJ-682	6800PF 50V MYLAR CAP.	
	C321	QFLB1HJ-332	3300PF 50V MYLAR CAP.	
	C322	QFLB1HJ-332	3300PF 50V MYLAR CAP.	
	C323	QFLB1HJ-183	0.018MF 50V MYLAR CAP.	
	C324	QFP31HG-472	4700PF 50V POLYPROPY.FILM	
	C325	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C326	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C335	QCF21HP-472	4700PF 50V CER.CAP.	
	C336	QCF21HP-472	4700PF 50V CER.CAP.	
	C339	EETB1CM-476	47MF 16V E.CAP.	
	C340	EETB1CM-476	47MF 16V E.CAP.	

⚠	Item	Parts Number	Description	Area
	C341	QFLB1HJ-472	4700PF 50V MYLAR CAP.	
	C342	QFLB1HJ-472	4700PF 50V MYLAR CAP.	
	C343	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C344	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C345	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C346	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C347	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C348	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C351	QCBB1HK-821Y	820PF 50V CER.CAP.	
	C352	QETN1HM-474Z	0.47MF 50V AL E.CAP.	
	C353	QETN1HM-476Z	47MF 50V E.CAP.	
	C365	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C366	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C367	QFLB1HJ-822	8200PF 50V MYLAR CAP.	
	C368	QFLB1HJ-822	8200PF 50V MYLAR CAP.	
	C369	EETB1AM-107E	100MF 10V E.CAP.	
	C370	EETB1AM-107E	100MF 10V E.CAP.	
	C371	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C372	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C373	EETB1CM-476	47MF 16V E.CAP.	
	C374	QETC1EM-476ZM	47MF 25V E.CAP.	
	C375	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C376	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C377	QCXB1CM-122	1200PF 16V POLYPROPY.FILM	
	C378	QCXB1CM-122	1200PF 16V POLYPROPY.FILM	
	C379	QCBB1HK-331Y	330PF 50V CER.CAP.	
	C380	QCBB1HK-331Y	330PF 50V CER.CAP.	
	C381	EETB1CM-476	47MF 16V E.CAP.	
	C385	QFLB1HJ-822	8200PF 50V MYLAR CAP.	
	C386	QFLB1HJ-822	8200PF 50V MYLAR CAP.	
	C387	EETB1AM-107E	100MF 10V E.CAP.	
	C388	EETB1AM-107E	100MF 10V E.CAP.	
	C389	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C390	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C391	EETB1CM-476	47MF 16V E.CAP.	
	C392	EETB1CM-476	47MF 16V E.CAP.	
	C393	QCS21HJ-101A	100PF 50V CER.CAP.	
	C394	QCS21HJ-101A	100PF 50V CER.CAP.	
	C395	QCXB1CM-152Y	1500PF 16V CER.CAP.	
	C396	QCXB1CM-152Y	1500PF 16V CER.CAP.	
	C397	QCBB1HK-391Y	390PF 50V CER.CAP.	
	C398	QCBB1HK-391Y	390PF 50V CER.CAP.	
	C401	QFLB1HJ-472	4700PF 50V MYLAR CAP.	
	C402	QFLB1HJ-472	4700PF 50V MYLAR CAP.	
	C403	QFLB1HJ-102	1000PF 50V MYLAR CAP.	
	C404	QFLB1HJ-102	1000PF 50V MYLAR CAP.	
	C405	EETB1EM-106E	10MF 25V E.CAP.	
	C406	EETB1EM-106E	10MF 25V E.CAP.	
	C407	EETB1EM-106E	10MF 25V E.CAP.	
	C408	EETB1EM-106E	10MF 25V E.CAP.	
	C411	EETB1EM-106E	10MF 25V E.CAP.	
	C412	EETB1EM-106E	10MF 25V E.CAP.	
	C413	QCBB1HK-471Y	470PF 50V CER.CAP.	
	C414	QCBB1HK-471Y	470PF 50V CER.CAP.	
	C415	EETB1EM-106E	10MF 25V E.CAP.	
	C416	EETB1EM-106E	10MF 25V E.CAP.	
	C417	EETB1EM-106E	10MF 25V E.CAP.	
	C418	EETB1EM-106E	10MF 25V E.CAP.	
	C419	EETB1EM-106E	10MF 25V E.CAP.	
	C420	QETC1EM-476ZM	47MF 25V E.CAP.	
	C421	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C422	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C423	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C424	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C425	QFLB1HJ-183	0.018MF 50V MYLAR CAP.	
	C426	QFLB1HJ-183	0.018MF 50V MYLAR CAP.	
	C427	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
	C428	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
	C429	QFLB1HJ-562	5600PF 50V MYLAR CAP.	
	C430	QFLB1HJ-562	5600PF 50V MYLAR CAP.	

■ Electrical Parts List (ENC-136)

⚠	Item	Parts Number	Description	Area
	C431	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C432	QETC1HM-225ZM	2.2MF 50V E.CAP.	
	C433	EETB1HM-105E	1MF 50V E.CAP.	
	C434	EETB1HM-105E	1MF 50V E.CAP.	
	C435	EETB1EM-106E	10MF 25V E.CAP.	
	C436	EETB1EM-106E	10MF 25V E.CAP.	
	C443	EETB1EM-106E	10MF 25V E.CAP.	
	C444	EETB1EM-106E	10MF 25V E.CAP.	
	C445	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C446	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C447	EETB1EM-106E	10MF 25V E.CAP.	
	C448	EETB1EM-106E	10MF 25V E.CAP.	
	C453	EETB1EM-106E	10MF 25V E.CAP.	
	C454	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C455	EETB1EM-106E	10MF 25V E.CAP.	
	C471	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C472	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C473	QETC1EM-476ZM	47MF 25V E.CAP.	
	C474	QETC1EM-476ZM	47MF 25V E.CAP.	
	C475	EETB1EM-106E	10MF 25V E.CAP.	
	C476	EETB1EM-106E	10MF 25V E.CAP.	
	C477	EETB1HM-475E	4.7MF 50V E.CAP.	
	C481	QCBB1HK-221Y	220PF 50V CER.CAP.	
	C482	QCBB1HK-221Y	220PF 50V CER.CAP.	
	C483	QCXB1CM-222Y	2200PF 16V CER.CAP.	
	C484	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C489	QETB1CM-476	47MF 16V AL E.CAP.	
	C490	QETB1CM-476	47MF 16V AL E.CAP.	
	C493	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C494	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C495	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C496	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
		RESISTORS		
	R202	QRD161J-102	1K 1/6W CARBON RES.	
	R203	QRD161J-102	1K 1/6W CARBON RES.	
	R204	QRD161J-102	1K 1/6W CARBON RES.	
	R205	QRD161J-102	1K 1/6W CARBON RES.	
	R206	QRD161J-103	10K 1/6W CARBON RES.	
	R207	QRD161J-103	10K 1/6W CARBON RES.	
	R208	QRD161J-472	4.7K 1/6W CARBON RES.	
	R209	QRD167J-223	22K 1/6W CARBON RES.	
	R211	QRD161J-103	10K 1/6W CARBON RES.	
	R213	QRD161J-472	4.7K 1/6W CARBON RES.	
	R214	QRD161J-103	10K 1/6W CARBON RES.	
	R217	QRD161J-103	10K 1/6W CARBON RES.	
	R218	QRD161J-221	220 1/6W CARBON RES.	
	R231	QRD161J-183	18K 1/6W CARBON RES.	
	R232	QRD161J-183	18K 1/6W CARBON RES.	
	R233	QRD167J-153	15K 1/6W CARBON RES.	
	R234	QRD167J-153	15K 1/6W CARBON RES.	
	R271	QRD161J-104	100K 1/6W CARBON RES.	
	R272	QRD161J-104	100K 1/6W CARBON RES.	
	R280	QRD161J-221	220 1/6W CARBON RES.	
	R281	QRD161J-224	220K 1/6W CARBON RES.	
	R282	QRD161J-224	220K 1/6W CARBON RES.	
	R283	QRD161J-100	10 1/6W CARBON RES.	
	R284	QRD161J-100	10 1/6W CARBON RES.	
	R285	QRD161J-393	39K 1/6W CARBON RES.	
	R286	QRD161J-393	39K 1/6W CARBON RES.	
	R287	QRD14CJ-6R8SX	6.8 1/4W UNF.CARBON R	
⚠	R288	QRD14CJ-100SX	10 1/4W UNF.CARBON R	
	R290	QRD167J-332	3.3K 1/6W CARBON RES.	
	R292	QRD161J-181	180 1/6W CARBON RES.	
	R293	QRD167J-511	510 1/6W CARBON RES.	
	R294	QRD161J-561	560 1/6W CARBON RES.	
	R296	QRD161J-104	100K 1/6W CARBON RES.	
	R297	QRD161J-222	2.2K 1/6W CARBON RES.	
	R335	QRD161J-102	1K 1/6W CARBON RES.	
	R336	QRD161J-102	1K 1/6W CARBON RES.	
	R337	QRD161J-102	1K 1/6W CARBON RES.	

⚠	Item	Parts Number	Description	Area
	R338	QRD161J-102	1K 1/6W CARBON RES.	
	R339	QRD161J-393	39K 1/6W CARBON RES.	
	R340	QRD161J-393	39K 1/6W CARBON RES.	
	R341	QRD167J-272	2.7K 1/6W CARBON RES.	
	R342	QRD167J-272	2.7K 1/6W CARBON RES.	
	R343	QRD167J-223	22K 1/6W CARBON RES.	
	R344	QRD161J-563	56K 1/6W CARBON RES.	
	R345	QRD161J-184	180K 1/6W CARBON RES.	
	R346	QRD161J-105	1M 1/6W CARBON RES.	
	R347	QRD161J-221	220 1/6W CARBON RES.	
	R348	QRD161J-221	220 1/6W CARBON RES.	
	R349	QRD161J-102	1K 1/6W CARBON RES.	
	R351	QRD161J-472	4.7K 1/6W CARBON RES.	
	R352	QRD161J-472	4.7K 1/6W CARBON RES.	
	R353	QRD167J-223	22K 1/6W CARBON RES.	
	R354	QRD167J-223	22K 1/6W CARBON RES.	
	R355	QRD161J-103	10K 1/6W CARBON RES.	
	R356	QRD161J-103	10K 1/6W CARBON RES.	
	R357	QRD167J-223	22K 1/6W CARBON RES.	
	R358	QRD167J-223	22K 1/6W CARBON RES.	
	R359	QRD161J-103	10K 1/6W CARBON RES.	
	R360	QRD161J-103	10K 1/6W CARBON RES.	
	R361	QRD167J-562	5.6K 1/6W CARBON RES.	
	R362	QRD167J-562	5.6K 1/6W CARBON RES.	
	R367	QRD161J-224	220K 1/6W CARBON RES.	
	R368	QRD161J-224	220K 1/6W CARBON RES.	
	R371	QRD161J-163	16K 1/6W CARBON RES.	
	R372	QRD161J-163	16K 1/6W CARBON RES.	
	R377	QRD161J-221	220 1/6W CARBON RES.	
	R378	QRD161J-221	220 1/6W CARBON RES.	
	R381	QRD161J-221	220 1/6W CARBON RES.	
	R382	QRD161J-221	220 1/6W CARBON RES.	
	R385	QRD161J-224	220K 1/6W CARBON RES.	
	R386	QRD161J-224	220K 1/6W CARBON RES.	
	R391	QRD161J-163	16K 1/6W CARBON RES.	
	R392	QRD161J-163	16K 1/6W CARBON RES.	
	R401	QRD161J-222	2.2K 1/6W CARBON RES.	
	R402	QRD161J-222	2.2K 1/6W CARBON RES.	
	R403	QRD161J-222	2.2K 1/6W CARBON RES.	
	R404	QRD161J-222	2.2K 1/6W CARBON RES.	
	R405	QRD167J-152	1.5K 1/6W CARBON RES.	
	R406	QRD167J-152	1.5K 1/6W CARBON RES.	
	R407	QRD167J-562	5.6K 1/6W CARBON RES.	
	R408	QRD167J-562	5.6K 1/6W CARBON RES.	
	R409	QRD161J-472	4.7K 1/6W CARBON RES.	
	R410	QRD161J-472	4.7K 1/6W CARBON RES.	
	R411	QRD167J-562	5.6K 1/6W CARBON RES.	
	R412	QRD167J-562	5.6K 1/6W CARBON RES.	
	R413	QRD161J-102	1K 1/6W CARBON RES.	
	R414	QRD161J-102	1K 1/6W CARBON RES.	
	R415	QRD161J-823	82K 1/6W CARBON RES.	
	R416	QRD161J-823	82K 1/6W CARBON RES.	
	R417	QRD167J-562	5.6K 1/6W CARBON RES.	
	R418	QRD167J-562	5.6K 1/6W CARBON RES.	
	R419	QRD167J-272	2.7K 1/6W CARBON RES.	
	R420	QRD167J-272	2.7K 1/6W CARBON RES.	
	R421	QRD161J-104	100K 1/6W CARBON RES.	
	R422	QRD161J-104	100K 1/6W CARBON RES.	
	R431	QRD161J-104	100K 1/6W CARBON RES.	
	R432	QRD161J-104	100K 1/6W CARBON RES.	
	R433	QRD167J-562	5.6K 1/6W CARBON RES.	
	R434	QRD167J-562	5.6K 1/6W CARBON RES.	
	R435	QRD161J-392	3.9K 1/6W CARBON RES.	
	R436	QRD161J-392	3.9K 1/6W CARBON RES.	
	R437	QRD161J-472	4.7K 1/6W CARBON RES.	
	R438	QRD161J-472	4.7K 1/6W CARBON RES.	
	R439	QRD161J-432	4.3K 1/6W CARBON RES.	
	R440	QRD161J-432	4.3K 1/6W CARBON RES.	
	R441	QRD161J-104	100K 1/6W CARBON RES.	
	R442	QRD161J-104	100K 1/6W CARBON RES.	

■ Electrical Parts List (ENC-136)

⚠	Item	Parts Number	Description	Area
	R445	QRD161J-303Y	30K 1/6W CARBON RES.	
	R446	QRD161J-303Y	30K 1/6W CARBON RES.	
	R447	QRD167J-153	15K 1/6W CARBON RES.	
	R448	QRD161J-104	100K 1/6W CARBON RES.	
	R453	QRD161J-104	100K 1/6W CARBON RES.	
	R454	QRD161J-104	100K 1/6W CARBON RES.	
	R455	QRD161J-103	10K 1/6W CARBON RES.	
	R456	QRD161J-103	10K 1/6W CARBON RES.	
	R457	QRD167J-562	5.6K 1/6W CARBON RES.	
	R458	QRD167J-562	5.6K 1/6W CARBON RES.	
	R459	QRD161J-104	100K 1/6W CARBON RES.	
	R460	QRD161J-104	100K 1/6W CARBON RES.	
	R461	QRD161J-221	220 1/6W CARBON RES.	
	R462	QRD161J-221	220 1/6W CARBON RES.	
	R463	QRD161J-103	10K 1/6W CARBON RES.	
	R464	QRD161J-103	10K 1/6W CARBON RES.	
	R465	QRD161J-102	1K 1/6W CARBON RES.	
	R481	QRD161J-222	2.2K 1/6W CARBON RES.	
	R482	QRD161J-222	2.2K 1/6W CARBON RES.	
	R483	QRD161J-221	220 1/6W CARBON RES.	
	R484	QRD161J-221	220 1/6W CARBON RES.	
	R485	QRD161J-103	10K 1/6W CARBON RES.	
	R486	QRD161J-103	10K 1/6W CARBON RES.	
	R491	QRD161J-471	470 1/6W CARBON RES.	
	R492	QRD161J-103	10K 1/6W CARBON RES.	
	R493	QRD167J-113	11K 1/6W CARBON RES.	
	R494	QRD167J-113	11K 1/6W CARBON RES.	
	R497	QRD161J-104	100K 1/6W CARBON RES.	
	R498	QRD161J-104	100K 1/6W CARBON RES.	
	VR231	QVPA603-503A	50K VARIABLE RES.	
	VR232	QVPA603-503A	50K VARIABLE RES.	
	VR301	QVPA603-102AZA	1K TRIMMER RES.	
	VR302	QVPA603-102AZA	1K TRIMMER RES.	
	VR303	QVPA603-102AZA	1K TRIMMER RES.	
	VR304	QVPA603-102AZA	1K TRIMMER RES.	
	VR305	QVPA603-104A	100K TRIMMER RES.	
	VR306	QVPA603-104A	100K TRIMMER RES.	
	VR307	QVPA603-104A	100K TRIMMER RES.	
	VR308	QVPA603-104A	100K TRIMMER RES.	
	VR309	QVPA603-104A	100K TRIMMER RES.	
	VR310	QVPA603-104A	100K TRIMMER RES.	
		OTHERS		
		EMW10686-002	PRINTED BOARD	
		QWE350-09RR	VINYL WIRE	
	J401	EMN00TV-414AJ2	4P PIN JACK	
	J701	EMV7145-004Z	SOCKET ASSY	
	L301	ENZ6002-012	OSCILLATOR COIL	
	L305	EQL2106-223	INDUCTOR	
	L306	EQL2106-223	INDUCTOR	
	X201	ECX0060-000EM	CERAMIC RESONATOR	
	CN016	EMV5163-010R	CONNECT TERMINAL	
	CN017	EMV5163-009R	CONNECT TERMINAL	
	CN131	EMV5109-012A	MALE CONNECTOR	
	CN311	EMV5172-014B	CONNECT TERMINAL	
	CN312	EMV5172-014B	CONNECT TERMINAL	
	CN322	VMC0163-016	CONNECT TERMINAL	
	CN331	EMV7155-106R	CONNECT TERMINAL	
	CN332	EMV7155-106R	CONNECT TERMINAL	
	CN402	VMC0163-017	CONNECT TERMINAL	
	CN411	VMC0163-025	CONNECT TERMINAL	
	CN412	VMC0163-017	CONNECT TERMINAL	
	CN613	VMC0163-007	CONNECT TERMINAL	
	CN614	VMC0163-011	CONNECT TERMINAL	
	CN811	VMC0163-010	AC CONNECTOR	
	EP003	E40918Z-001SM	EARTH TERMINAL	
	SP301	VYH7653-001	LEAF SPRING	

■ Electrical Parts List (ENN-488)

⚠	Item	Parts Number	Description	Area
		I.C.S		
	IC601	AN8806SB	I.C(MONO-ANALOG)	
	IC602	BA6897FPW	I.C(MONO-ANALOG)	
	IC603	MN35510-S	I.C(M)	
		DIODES		
	D631	MTZ5.6JB	ZENER DIODE	
		TRANSISTORS		
	Q601	2SA952(L,K)	SI.TRANSISTOR	
	Q632	2SC2060(Q,R)	SI.TRANSISTOR	
		CAPACITORS		
	C602	QCZ0205-155	1.5MF 25V C.CAP.	
	C603	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C605	EETB1EM-106E	10MF 25V E.CAP.	
	C606	QCBB1HK-102Y	1000PF 50V CER.CAP.	
	C607	QCBB1HK-102Y	1000PF 50V CER.CAP.	
	C608	EETB1HM-105E	1MF 50V E.CAP.	
	C609	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C610	QFLB1HJ-273	0.027MF 50V MYLAR CAP.	
	C611	QCXB1CM-472Y	4700PF 16V CER.CAP.	
	C612	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C613	QCBB1HK-331Y	330PF 50V CER.CAP.	
	C614	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C615	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C616	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C617	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C618	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C619	QCBB1HK-271Y	270PF 50V CER.CAP.	
	C620	QCSB1HJ-470	47PF 50V CER.CAP.	
	C621	QCBB1HK-102Y	1000PF 50V CER.CAP.	
	C622	QCF21HP-223A	0.022MF 50V CER.CAP.	
	C623	QFLB1HJ-104	0.1MF 50V MYLAR CAP.	
	C625	QCZ0205-155	1.5MF 25V C.CAP.	
	C630	QETN1AM-226ZS	22MF 10V E.CAP.	
	C631	QETN1AM-477Z	470MF 10V E.CAP.	
	C632	QEK61AM-227ZM	220MF 10V AL E.CAP.	
	C636	EETB1AM-107E	100MF 10V E.CAP.	
	C641	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C642	QFLB1HJ-103	0.01MF 50V MYLAR CAP.	
	C651	QCSB1HJ-120Y	12PF 50V CER.CAP.	
	C652	QCSB1HJ-120Y	12PF 50V CER.CAP.	
	C653	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C655	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	
	C661	QCBB1HK-471Y	470PF 50V CER.CAP.	
	C662	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	
	C663	QFLB1HJ-223	0.022MF 50V MYLAR CAP.	
	C664	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C665	QFV81HJ-104	0.1MF 50V THIN FILM CAP.	
	C671	QCXB1CM-222Y	2200PF 16V CER.CAP.	
	C672	QCXB1CM-222Y	2200PF 16V CER.CAP.	
	C674	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C675	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C679	QEK51AM-107	100MF 10V AL E.CAP.	
	C693	QEK61AM-227ZM	220MF 10V AL E.CAP.	
	C694	QCHB1EZ-223	0.022MF 25V CER.CAP.	
		RESISTORS		
	R601	QRD161J-123	12K 1/6W CARBON RES.	
	R603	QRD161J-125	1.2M 1/6W CARBON RES.	
	R605	QRD161J-274	270K 1/6W CARBON RES.	
	R606	QRD167J-154	150K 1/6W CARBON RES.	
	R607	QRD161J-273	27K 1/6W CARBON RES.	
	R609	QRD161J-114	110K 1/6W CARBON RES.	
	R610	QRD161J-104	100K 1/6W CARBON RES.	
	R611	QRD161J-473	47K 1/6W CARBON RES.	
	R612	QRD167J-822	8.2K 1/6W CARBON RES.	
	R613	QRD167J-121	120 1/6W CARBON RES.	
	R614	QRD161J-100	10 1/6W CARBON RES.	
	R615	QRD161J-120	12 1/6W CARBON RES.	
	R616	QRD161J-910Y	91 1/6W CARBON RES.	
	R632	QRD167J-151	150 1/6W CARBON RES.	
	R641	QRD161J-683	68K 1/6W CARBON RES.	

⚠	Item	Parts Number	Description	Area
	R642	QRD161J-222	2.2K 1/6W CARBON RES.	
	R643	QRD167J-822	8.2K 1/6W CARBON RES.	
	R644	QRD167J-223	22K 1/6W CARBON RES.	
	R645	QRD167J-223	22K 1/6W CARBON RES.	
	R646	QRD161J-222	2.2K 1/6W CARBON RES.	
	R647	QRD161J-472	4.7K 1/6W CARBON RES.	
	R650	QRD161J-182	1.8K 1/6W CARBON RES.	
	R651	QRD161J-102	1K 1/6W CARBON RES.	
	R652	QRD161J-102	1K 1/6W CARBON RES.	
	R653	QRD161J-102	1K 1/6W CARBON RES.	
	R660	QRD161J-102	1K 1/6W CARBON RES.	
	R661	QRD161J-683	68K 1/6W CARBON RES.	
	R662	QRD167J-275	2.7M 1/6W CARBON RES.	
	R663	QRD161J-124	120K 1/6W CARBON RES.	
	R664	QRD161J-471	470 1/6W CARBON RES.	
	R666	QRD161J-220	22 1/6W CARBON RES.	
	R667	QRD161J-220	22 1/6W CARBON RES.	
	R671	QRD161J-102	1K 1/6W CARBON RES.	
	R672	QRD161J-102	1K 1/6W CARBON RES.	
	R692	QRD161J-271	270 1/6W CARBON RES.	
		OTHERS		
		EMW10688-002A	PRINTED BOARD	
	X651	ECX0169-344EF	CRYSTAL	
	CN601	EMV7171-115R	CONNECT TERMINAL	
	CN602	EMV5109-006A	CONNECT TERMINAL	
	CN603	VMC0163-R07	CONNECT TERMINAL	
	CN604	VMC0163-R11	CONNECT TERMINAL	
	SP601	VYH7237-001SS	I.C.COVER	
	SP602	VYH7237-003	I.C.COVER	
	SP603	VYH7237-003	I.C.COVER	
	TP601	QMV5004-002K	PLUG ASSY	
	TW601	EWF102-047	TERMINAL WIRE	

■ Electrical Parts List (ENA-178)

⚠	Item	Parts Number	Description	Area
		I.C.S		
	IC102	LA1837	I.C(MONO-ANALOG)	
	IC121	LC72131	I.C(M)	
		DIODES		
	D121	1SS133	SI.DIODE	
	D123	1SS133	SI.DIODE	
	D129	1SS133	SI.DIODE	
	D130	MTZ10JC	ZENER DIODE	
		TRANSISTORS		
	Q101	2SC461	SI.TRANSISTOR	
	Q102	2SC535	SI.TRANSISTOR	
	Q103	2SC461	SI.TRANSISTOR	
	Q121	DTA124ES	DIGITAL TRANSISTOR	
	Q123	2SC2060(Q,R)	SI.TRANSISTOR	
		CAPACITORS		
	C101	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C102	QETN1EM-107Z	100MF 25V E.CAP.	
	C103	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C104	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C105	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C107	QETN1EM-226Z	22MF 25V E.CAP.	
	C109	QETN1EM-226Z	22MF 25V E.CAP.	
	C111	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C112	QCT30CH-120Y	12PF 50V CER.CAP.	
	C117	QCSB1HK-5R6Y	5.6PF 50V CER.CAP.	
	C118	QCSB1HJ-150Y	15PF 50V CER.CAP.	
	C121	QCT30CH-180Y	18PF 50V CER.CAP.	
	C122	QCT30CH-180Y	18PF 50V CER.CAP.	
	C123	QCC21EM-473	0.047MF 25V CER.CAP.	
	C126	QCBB1HK-101Y	100PF 50V CER.CAP.	
	C128	QENB1HM-474	0.47MF 50V NP E.CAP.	
	C129	QCGB1HK-102	1000PF 50V CER.CAP.	
	C130	QETN1EM-107Z	100MF 25V E.CAP.	
	C133	QETN1EM-226Z	22MF 25V E.CAP.	
	C135	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C136	QETN1HM-105Z	1MF 50V AL E.CAP.	
	C137	QCBB1HK-681Y	680PF 50V CER.CAP.	
	C139	QFLB1HJ-333	0.033MF 50V MYLAR CAP.	
	C140	QFLB1HJ-333	0.033MF 50V MYLAR CAP.	
	C141	QCC21EM-473	0.047MF 25V CER.CAP.	
	C143	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C144	QCC21EM-473	0.047MF 25V CER.CAP.	
	C146	QETN1HM-105Z	1MF 50V AL E.CAP.	
	C147	QETN1HM-105Z	1MF 50V AL E.CAP.	
	C148	QETN1HM-474Z	0.47MF 50V AL E.CAP.	
	C149	QETN1HM-105Z	1MF 50V AL E.CAP.	
	C150	QETN1EM-226Z	22MF 25V E.CAP.	
	C156	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C157	QCC21EM-473	0.047MF 25V CER.CAP.	
	C158	QETN1EM-226Z	22MF 25V E.CAP.	
	C161	QETN1HM-105Z	1MF 50V AL E.CAP.	
	C162	QETN1HM-105Z	1MF 50V AL E.CAP.	
	C163	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C164	QCC21EM-473	0.047MF 25V CER.CAP.	
	C168	QFV81HJ-274	0.27MF 50V THIN FILM CAP.	
	C180	QETN1EM-107Z	100MF 25V E.CAP.	
	C181	QFLB1HJ-562	5600PF 50V MYLAR CAP.	
	C182	QFLB1HJ-562	5600PF 50V MYLAR CAP.	
	C183	QCHB1EZ-223	0.022MF 25V CER.CAP.	
	C184	QETN1EM-107Z	100MF 25V E.CAP.	
	C185	QETN1HM-105Z	1MF 50V AL E.CAP.	
	C186	QETN1HM-105Z	1MF 50V AL E.CAP.	
		RESISTORS		
	R102	QRD167J-332	3.3K 1/6W CARBON RES.	
	R103	QRD161J-221	220 1/6W CARBON RES.	
	R104	QRD167J-272	2.7K 1/6W CARBON RES.	
	R105	QRD161J-391	390 1/6W CARBON RES.	
	R106	QRD161J-102	1K 1/6W CARBON RES.	
	R107	QRD161J-561	560 1/6W CARBON RES.	
	R108	QRD167J-332	3.3K 1/6W CARBON RES.	

⚠	Item	Parts Number	Description	Area
	R109	QRD161J-221	220 1/6W CARBON RES.	
	R115	QRD161J-104	100K 1/6W CARBON RES.	
	R119	QRD161J-103	10K 1/6W CARBON RES.	
	R121	QRD161J-473	47K 1/6W CARBON RES.	
	R122	QRD161J-472	4.7K 1/6W CARBON RES.	
	R124	QRD161J-222	2.2K 1/6W CARBON RES.	
	R126	QRD167J-562	5.6K 1/6W CARBON RES.	
	R127	QRD167J-822	8.2K 1/6W CARBON RES.	
	R128	QRD161J-472	4.7K 1/6W CARBON RES.	
	R129	QRD161J-222	2.2K 1/6W CARBON RES.	
⚠	R130	QRD14CJ-680SX	68 1/4W UNF.CARBON R	
	R132	QRD161J-102	1K 1/6W CARBON RES.	
	R133	QRD167J-822	8.2K 1/6W CARBON RES.	
	R134	QRD161J-102	1K 1/6W CARBON RES.	
	R140	QRD161J-183	18K 1/6W CARBON RES.	
	R141	QRD161J-472	4.7K 1/6W CARBON RES.	
	R142	QRD161J-470	47 1/6W CARBON RES.	
	R143	QRD167J-562	5.6K 1/6W CARBON RES.	
	R144	QRD167J-332	3.3K 1/6W CARBON RES.	
	R145	QRD161J-103	10K 1/6W CARBON RES.	
	R146	QRD167J-332	3.3K 1/6W CARBON RES.	
	R147	QRD167J-153	15K 1/6W CARBON RES.	
	R148	QRD161J-561	560 1/6W CARBON RES.	
	R150	QRD161J-101	100 1/6W CARBON RES.	
	R157	QRD167J-682	6.8K 1/6W CARBON RES.	
	R158	QRD167J-682	6.8K 1/6W CARBON RES.	
	R161	QRD161J-102	1K 1/6W CARBON RES.	
	R162	QRD161J-102	1K 1/6W CARBON RES.	
	R163	QRD161J-472	4.7K 1/6W CARBON RES.	
	R164	QRD161J-472	4.7K 1/6W CARBON RES.	
	R181	QRD161J-102	1K 1/6W CARBON RES.	
	R182	QRD161J-103	10K 1/6W CARBON RES.	
	R183	QRD161J-103	10K 1/6W CARBON RES.	
	R184	QRD161J-103	10K 1/6W CARBON RES.	
		OTHERS		
		EMW10684-002A	PRINTED BOARD	
	L111	EQL4007-150T	INDUCTOR	
	T111	EQR7121-007	RF COIL	
	T141	QQR0613-001	I.F.TRANSFORMER	
	T142	QAX0303-001	CERAMIC FILTER	
	X121	ECX0007-200KWJ1	CRYSTAL	
	AT101	FMMB10YV-401K	ANTENNA TERMINAL	
	CF101	QAX0285-001Z	CERAMIC FILTER	
	CF102	QAX0285-001Z	CERAMIC FILTER	
	CN111	EMV5163-012R	CONNECT TERMINAL	
	FL141	EQF0101-013	LOWPASS FILTER	
	FL142	EQF0101-013	LOWPASS FILTER	
	RF101	EAF2207-001	FRONT END	

■ Electrical Parts List (END-107)

⚠	Item	Parts Number	Description	Area
		DIODES		
	D2001	1SS133	SI.DIODE	
	D2002	1SS133	SI.DIODE	
	D2003	1SS133	SI.DIODE	
	D2004	1SS133	SI.DIODE	
	D2005	1SS133	SI.DIODE	
		TRANSISTORS		
	Q2001	DTC114YS	DIGITAL TRANSISTOR	
	Q2001	KRC107M-T	DIGITAL TRANSISTOR	
	Q2002	DTC114YS	DIGITAL TRANSISTOR	
	Q2003	DTC114YS	DIGITAL TRANSISTOR	
		CAPACITORS		
	C2001	QETN1EM-226Z	22MF 25V E.CAP.	
	C2002	QETN1EM-106Z	10MF 25V E.CAP.	
		RESISTORS		
	R2001	QRD161J-103	10K 1/6W CARBON RES.	
	R2002	QRD167J-223	22K 1/6W CARBON RES.	
	R2003	QRD161J-103	10K 1/6W CARBON RES.	
	R2004	QRD167J-223	22K 1/6W CARBON RES.	
		OTHERS		
		EMW10723-001	CIR.BORAD	
	CN291	EMV7145-003Z	SOCKET ASSY	
	CN292	EMV7145-003Z	SOCKET ASSY	
		I.C.S		
	IC802	TA8409S	I.C(MONO-ANALOG)	
	IC803	TA8409S	I.C(MONO-ANALOG)	
		CAPACITORS		
	C803	QFLB1HJ-102	1000PF 50V MYLAR CAP.	
	C804	QCFB1HZ-104Y	0.1MF 50V CER.CAP.	
	C805	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C808	QFLB1HJ-102	1000PF 50V MYLAR CAP.	
	C810	QCZ0205-155	1.5MF 25V C.CAP.	
	C811	QCZ0205-155	1.5MF 25V C.CAP.	
	C813	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C821	QCBB1HK-102Y	1000PF 50V CER.CAP.	

■ Electrical Parts List (Changer Control P.C.Board)

⚠	Item	Parts Number	Description	Area
		I.C.S		
	IC802	TA8409S	I.C(MONO-ANALOG)	
	IC803	TA8409S	I.C(MONO-ANALOG)	
		CAPACITORS		
	C803	QFLB1HJ-102	1000PF 50V MYLAR CAP.	
	C804	QCFB1HZ-104Y	0.1MF 50V CER.CAP.	
	C805	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C808	QFLB1HJ-102	1000PF 50V MYLAR CAP.	
	C810	QCZ0205-155	1.5MF 25V C.CAP.	
	C811	QCZ0205-155	1.5MF 25V C.CAP.	
	C813	QCVB1CM-103Y	0.01MF 16V CER.CAP.	
	C821	QCBB1HK-102Y	1000PF 50V CER.CAP.	
		RESISTORS		
	R805	QRD161J-102	1K 1/6W CARBON RES.	
	R806	QRD161J-471	470 1/6W CARBON RES.	
	R807	QRD161J-471	470 1/6W CARBON RES.	
	R808	QRD161J-102	1K 1/6W CARBON RES.	
	R810	QRD161J-684	680K 1/6W CARBON RES.	
	R811	QRD161J-105	1M 1/6W CARBON RES.	
	R813	QRD161J-102	1K 1/6W CARBON RES.	
	R814	QRD161J-102	1K 1/6W CARBON RES.	
	R815	QRD161J-102	1K 1/6W CARBON RES.	
	R816	QRD161J-102	1K 1/6W CARBON RES.	
	R817	QRD161J-102	1K 1/6W CARBON RES.	
	R818	QRD161J-102	1K 1/6W CARBON RES.	
	R819	QRD161J-102	1K 1/6W CARBON RES.	
	R820	QRD161J-102	1K 1/6W CARBON RES.	
	R821	QRD161J-102	1K 1/6W CARBON RES.	
	R822	QRD161J-102	1K 1/6W CARBON RES.	
	R823	QRD161J-102	1K 1/6W CARBON RES.	
	R824	QRD161J-102	1K 1/6W CARBON RES.	
	R825	QRD161J-102	1K 1/6W CARBON RES.	
	R826	QRD161J-102	1K 1/6W CARBON RES.	
	R827	QRD161J-102	1K 1/6W CARBON RES.	
	R828	QRD161J-102	1K 1/6W CARBON RES.	
	R829	QRD161J-102	1K 1/6W CARBON RES.	
	R830	QRD161J-102	1K 1/6W CARBON RES.	
	R832	QRD161J-181	180 1/6W CARBON RES.	
	R833	QRD161J-102	1K 1/6W CARBON RES.	
	R834	QRD161J-102	1K 1/6W CARBON RES.	
	R839	QRD167J-332	3.3K 1/6W CARBON RES.	
	R840	QRD167J-562	5.6K 1/6W CARBON RES.	
		OTHERS		
		QEK51AM-107	AL E.CAP.	
		QEK51CM-476	AL E.CAP.	
		QEK51EM-475	AL E.CAP.	
		SBSF2608Z	TAPPING SCREW	
		UPD65612GB-208	I.C(M)	
		VMW1377-004X	PW BOARD	
		VYH7237-001SS	IC HOLDER	
	L801	VQP0018-100	INDUCTOR	
	L802	VQP0033-100Z	INDUCTOR	
	L803	VQP0033-100Z	INDUCTOR	
	L804	VQP0033-100Z	INDUCTOR	
	CN801	VMC0163-R10	CONNECT TERMINAL	
	CN802	VMC0289-P07	CONNECT TERMINAL	
	CN803	VMC0324-12310	CONNECT TERMINAL	
	CN804	VMC0289-S07K	CONNECTOR	

Accessories List

Block No. M5MM

⚠	Item	Parts Number	Parts Name	Q'ty	Description	Area
	1	E30580-2538A	INSTRUCTION BOOK	1		J
		E30580-2539A	INSTRUCTION BOOK	1		C
	2	E309758-003	POLY BAG	1		
	3	EQB4001-015	LOOP ANTENNA	1		
	4	BT-20071B	SERVICE NETWORK	1		C
	5	BT-51006-1	REGISTER CARD	1		J
	6	BT-52002-1	WARRANTY CARD	1		C
	7	EWP201-011	ANTENNA WIRE	1		
	8	BT-20044G	SAFETY SHEET	1		J
	9	RM-SED60TU	WIRE-LESS REMOTE CONTROL	1		
	10	R6PRPA-2STSA	DRY CELL	1		

Packing Materials and Part Numbers

Block No. M6MM



JVC

VICTOR COMPANY OF JAPAN. LIMITED
AUDIO PRODUCT DIVISION 1644, SHIMOTURUMA, YAMATO-SHI, KANAGAWA-KEN, 242, JAPAN

Printed in japan
9702(S)